

[manuals.plus](#) /

› [Salter](#) /

› [Salter BW12947EU7 Gravity Salt and Pepper Shaker Set Instruction Manual](#)

Salter BW12947EU7

Salter BW12947EU7 Gravity Salt and Pepper Shaker Set Instruction Manual

Brand: Salter | **Model:** BW12947EU7

1. INTRODUCTION

Thank you for choosing the Salter Gravity Salt and Pepper Shaker Set. This set features a smart gravity-activated design, allowing for easy and spill-free seasoning. The seasoning holes open when tilted for dispensing and close automatically when upright. This manual provides essential information for the safe and effective use of your new shakers.



Image: The Salter Gravity Salt and Pepper Shaker Set, featuring a white and a black shaker with stainless steel tops.

2. SETUP AND FILLING

1. **Unpack:** Carefully remove the shakers from their packaging.
2. **Clean:** Before first use, wipe the exterior of the shakers with a damp cloth. Do not immerse in water.
3. **Fill:** To fill, hold the shaker upright. Gently twist and pull off the stainless steel top. Fill the transparent body with your desired ground spice (e.g., salt, pepper, cumin, cinnamon, turmeric, garlic). Do not overfill.
4. **Secure Top:** Align the stainless steel top with the body and push it firmly back into place until secure. Ensure it is properly sealed to prevent spills.



Image: Top view of the Salter Gravity Shakers, highlighting the removable stainless steel caps for filling.

3. OPERATING INSTRUCTIONS

The Salter Gravity Shakers are designed for simple, one-handed operation:

1. **Activate:** To dispense seasoning, simply tilt the shaker downwards over your food. The internal gravity mechanism will cause the seasoning holes on the top to open automatically.
2. **Season:** Shake gently to dispense the desired amount of spice.
3. **Deactivate:** Once you return the shaker to an upright position, the seasoning holes will automatically close, preventing spills and keeping your kitchen tidy.



Image: A hand demonstrating the use of the black Salter Gravity Shaker over a meal.



Image: Close-up of the black shaker tilted, showing the open dispensing holes at the top.

4. CARE AND MAINTENANCE

- **Cleaning:** Wipe the exterior of the shakers with a soft, damp cloth. Do not use abrasive cleaners or immerse the shakers in water, as this can damage the internal mechanism.
- **Drying:** Ensure the shakers are completely dry before refilling or storing.
- **Storage:** Store in a cool, dry place away from direct sunlight and excessive humidity to preserve the quality of your spices.

5. TROUBLESHOOTING

If you encounter any issues with your Salter Gravity Shakers, please refer to the following:

- **Shaker not dispensing:**
 - Ensure the shaker is tilted sufficiently for the gravity mechanism to activate.
 - Check if the spice holes are clogged. Gently tap the shaker or use a small, dry brush to clear any blockages.
 - Verify that the shaker is not empty.

- **Spices leaking when upright:**

- Ensure the stainless steel top is securely attached and properly aligned.
- Check for any spice residue around the sealing area that might prevent a complete closure. Clean if necessary.
- Avoid overfilling the shaker, as this can interfere with the closing mechanism.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	BW12947EU7
Brand	Salter
Product Dimensions	5.2 x 5.2 x 11.3 cm (each shaker)
Weight	210 grams (total for set)
Number of Pieces	2
Batteries Required	No
Material	Durable Plastic, Stainless Steel
Color	Grey (Monochrome design)
Operating Mode	Manual (Gravity-activated)
Recommended Use	Kitchen and Dining

7. WARRANTY AND SUPPORT

The Salter BW12947EU7 Gravity Salt and Pepper Shaker Set comes with a **2-year guarantee** from the date of purchase. Please retain your proof of purchase for warranty claims.

For further assistance, product information, or to register your product, please visit the official Salter website or contact their customer support. Contact details can typically be found on the product packaging or the manufacturer's website.



Image: Salter brand logo, established 1760.