Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anweller P10BF

Anweller P10BF Fingerprint Padlock User Manual

Model: P10BF

Overview Components Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Anweller P10BF Fingerprint Padlock is a versatile smart locking solution designed for various applications, including outdoor fences, gates, sheds, pools, yards, gym lockers, and trucks. It offers multiple unlocking methods for convenience and enhanced security. The padlock features a durable construction and is designed to withstand various weather conditions.



Image 1.1: Anweller P10BF Fingerprint Padlock, front view.

Key Features:

- **Fingerprint Unlock:** Advanced biometric technology for quick access in 0.2 seconds.
- **App Control:** Manage fingerprints, view unlock records, and share access remotely via Bluetooth.
- **Durable Construction:** Made from alloy steel and zinc alloy with a hardened steel shackle for cut resistance.
- **Weatherproof Design:** Features a pushable weatherproof cover for water and dust resistance.
- **Long Battery Life:** Built-in 160mAh rechargeable lithium battery provides up to 9 months standby or 3000 unlocks on a full charge.
- **Key Backup:** Includes physical keys for alternative unlocking.

2. Package Contents

Verify that all items are present in the package:

- 1 x P10BF Smart Padlock
- 1 x Silicone Case
- 1 x USB-C Charge Cable
- 1 x User Manual (This Document)
- 2 x Backup Keys

3. Initial Setup

3.1 Charging the Padlock

Before first use, fully charge the padlock. The padlock is equipped with a 160mAh rechargeable lithium battery.

1. Locate the USB-C charging port on the padlock, usually protected by a weatherproof cover.
2. Open the cover and connect the provided USB-C cable to the padlock and a standard USB power source (e.g., computer, wall adapter).
3. The LED indicator will show charging status. It will typically turn green or off when fully charged.



Image 3.1: The padlock connected to a power source via USB-C for charging. The image also illustrates the long battery life and number of unlocks per charge.

3.2 App Installation and Bluetooth Connection

The Anweller P10BF padlock can be controlled via a mobile application.

1. Download the official Anweller smart lock application from your device's app store (available for Android and iOS).
2. Enable Bluetooth on your mobile device.
3. Open the Anweller app and follow the on-screen instructions to register an account and add your P10BF padlock. You may need to press the fingerprint sensor to wake the lock during pairing.

3.3 Fingerprint Registration

Registering your fingerprint allows for quick and keyless access.

1. Within the Anweller app, navigate to the fingerprint management section for your P10BF padlock.
2. Follow the app's prompts to add a new fingerprint. You will typically be asked to place your finger on the sensor multiple times

from different angles to ensure accurate recognition.

3. The padlock can store up to 20 fingerprints.



Image 3.2: The padlock features an upgraded 3D fingerprint sensor for faster and more accurate identification, capable of storing up to 20 fingerprints.

4. Operating Instructions

4.1 Unlocking Methods

The Anweller P10BF padlock offers four primary ways to unlock:

Image 4.1: Visual representation of the four unlocking methods: Fingerprint, Mobile App, Apple Watch, and Spare Key.

4.1.1 Fingerprint Unlock

1. Place your registered finger firmly on the fingerprint sensor.
2. The LED indicator will flash green, and the shackle will automatically unlock.



Image 4.2: A finger being placed on the fingerprint sensor to unlock the padlock.

4.1.2 Mobile App Unlock

1. Ensure Bluetooth is enabled on your mobile device and the padlock is within range.
2. Open the Anweller app and select your P10BF padlock.
3. Tap the 'Unlock' button within the app. The padlock will unlock.



Image 4.3: A mobile phone displaying the Anweller app's unlock interface, and an Apple Watch showing the unlock function, both interacting with the padlock.

4.1.3 Key Unlock

In case of battery depletion or other issues, the backup keys can be used.

1. Locate the keyhole on the side of the padlock, usually protected by a cover.
2. Insert one of the provided backup keys into the keyhole.
3. Turn the key to unlock the shackle.



Image 4.4: A close-up of a key being inserted into the padlock's keyhole for manual unlocking.

4.2 Locking the Padlock

To lock the padlock, simply push the shackle down until it clicks into place. The padlock will automatically lock.

5. Maintenance

5.1 Battery Management

The padlock features an energy-saving design and a battery indicator.

- The padlock enters a sleep state to conserve energy. Touch the fingerprint sensor once to wake it up or connect to the app.
- Monitor the battery level via the LED indicators on the padlock or through the Anweller app.
- When the battery is low, recharge the padlock using the provided USB-C cable as described in Section 3.1.



Image 5.1: The padlock's LED battery indicator showing different charge levels, and the app displaying a low battery reminder.

5.2 Weather Resistance

The Anweller P10BF padlock is designed to be weatherproof (IP67 rated).

- The pushable cover protects the charging port and keyhole from water and dust. Ensure this cover is properly closed when not in use.
- While designed for outdoor use, avoid prolonged submersion in water.
- Regularly clean the fingerprint sensor with a soft, dry cloth to ensure optimal performance.



Image 5.2: The padlock shown in rain, demonstrating its weatherproof design with a pushable cover for protection.

6. Troubleshooting

Problem	Possible Cause	Solution
Padlock does not unlock with fingerprint.	Unregistered fingerprint, dirty sensor, low battery, incorrect finger placement.	Ensure your fingerprint is registered. Clean the sensor. Recharge the padlock. Place your finger firmly and completely on the sensor. Try re-registering your fingerprint.
Padlock does not connect to the app.	Bluetooth off, padlock out of range, app not updated, low battery.	Ensure Bluetooth is on. Bring your phone closer to the padlock. Update the app. Recharge the padlock. Restart your phone and the app.
Padlock is unresponsive.	Battery is completely depleted.	Charge the padlock using the USB-C cable. If it still doesn't respond, use the backup key to unlock.
Key does not unlock the padlock.	Incorrect key, obstruction in keyhole.	Ensure you are using the correct backup key. Check for any debris in the keyhole.

7. Product Specifications

Feature	Detail
Brand	Anweller
Model Number	P10BF
Lock Type	Fingerprint, Smart, Key, Biometric
Unlocking Ways	Fingerprint, Mobile App, Apple Watch, Key
Material	Alloy Steel, Stainless Steel, Zinc
Item Dimensions (L x W x H)	5 x 2.4 x 0.9 inches
Item Weight	12.5 ounces
Battery	160mAh Lithium Ion (rechargeable via USB-C)
Standby Time	Up to 9 months
Unlocks per Charge	Approximately 3000 times
Connectivity Protocol	Bluetooth
Controller Type	Android, iOS
Weather Resistance	IP67 Weatherproof
Included Components	P10BF Smart Padlock, Silicone Case, USB-C Charge Cable, User Manual, 2 Backup Keys

Image 7.1: Dimensions of the Anweller P10BF padlock (2.7" shackle) shown in comparison to a smartphone.

8. Warranty and Support

Anweller provides comprehensive customer support for the P10BF Fingerprint Padlock.

- **Free Trial Period:** Enjoy a 6-month free trial period.
- **Replacement/Refund:** Hassle-free replacement or refund available within 6 months of purchase.
- **Technical Support:** Free lifetime technical support is provided.

For any queries or assistance, please contact Anweller customer support.

9. Product Video Guide

Video 9.1: An official product video demonstrating the features and operation of the Anweller P10 Large Fingerprint Padlock.

© 2023 Anweller. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQQCK418

More documents and user manuals: **https://manuals.plus/**