

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AVACOM](#) /

› [AVACOM K-1096 Squishy Duck Night Light User Manual](#)

AVACOM K-1096

AVACOM K-1096 Squishy Duck Night Light User Manual

Model: K-1096

1. INTRODUCTION

Thank you for choosing the AVACOM K-1096 Squishy Duck Night Light. This manual provides essential information for the safe and efficient operation of your device. Please read these instructions thoroughly before use and retain them for future reference.



Image 1.1: The AVACOM Squishy Duck Night Light in an illuminated state.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Soft Silicone Material:** Constructed from BPA-free and non-toxic silicone rubber.
- **3-Level Dimmable Brightness:** Adjustable light intensity via touch control.
- **Rechargeable Battery:** Integrated Lithium Ion battery for cordless operation.
- **Touch Control:** Tap the light to change brightness levels.
- **30-Minute Timer:** Optional automatic shut-off function.
- **Integrated Phone Holder:** Designed to support a smartphone.
- **Water Resistant:** Suitable for indoor use.

2.2 What's in the Box

- AVACOM K-1096 Squishy Duck Night Light
- USB Type-C Charging Cable
- User Manual
- Lithium Ion Battery (pre-installed)



Image 2.1: Included components: night light, charging cable, and documentation.

3. SETUP

3.1 Initial Charging

1. Locate the Type-C charging port at the rear of the duck night light.
2. Connect the provided USB Type-C cable to the charging port.
3. Connect the other end of the USB cable to a standard USB power adapter (not included) or a computer USB port.
4. Allow the device to charge fully before first use. The charging indicator (if present, not specified) will typically change color or turn off when charging is complete.




Image 3.1: Detail of the Type-C charging port.

3.2 Powering On/Off

- Locate the ON/OFF switch on the bottom of the night light.
- Slide the switch to the "ON" position to power on the device.
- Slide the switch to the "OFF" position to power off the device.



Image 3.2: Location of the power and timer switch.

4. OPERATING INSTRUCTIONS

4.1 Adjusting Brightness

The night light features three brightness levels: Low, Middle, and High. To cycle through these levels:

- With the light on, gently tap the silicone body of the duck.
- Each tap will switch to the next brightness level.
- Continue tapping to cycle through Low, Middle, High, and Off.

Three Brightness Adjustments

Tap To Dim Design



Image 4.1: Demonstrating touch control for brightness adjustment.



Image 4.2: Visual representation of the three brightness levels.

4.2 Using the 30-Minute Timer

The night light includes an optional 30-minute timer function for automatic shut-off.

- Locate the switch on the bottom of the night light.
- Slide the switch to the "30" position to activate the timer. The light will automatically turn off after 30 minutes.
- To disable the timer, slide the switch back to the "ON" position.

4.3 Smartphone Holder Function

The duck's feet are designed to function as a smartphone holder.

- Position the night light on a flat surface.
- Place your smartphone between the duck's feet for hands-free viewing.



Image 4.3: The night light functioning as a smartphone holder.



Image 4.4: Detail of the phone holder feature.

5. MAINTENANCE

5.1 Cleaning

- Ensure the night light is turned off and unplugged before cleaning.
- Wipe the silicone surface with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the material.
- Allow the device to dry completely before next use.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in constant use.
- Store the device in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Battery is discharged. Power switch is OFF.	Charge the night light. Slide the power switch to the "ON" position.
Light does not respond to tapping.	Battery is low. Device is OFF.	Charge the night light. Ensure the power switch is in the "ON" position.
Light turns off automatically after a short period.	30-minute timer is activated.	Slide the timer switch to the "ON" position to disable the timer.
Device is not charging.	Charging cable is not properly connected. USB power source is faulty.	Ensure the Type-C cable is securely connected to both the light and the power source. Try a different USB power adapter or port.

7. SPECIFICATIONS

Feature	Detail

Feature	Detail
Model Number	K-1096
Brand	AVACOM
Material	Silicone Rubber
Product Dimensions (L x W x H)	8.27" x 4" x 2.44"
Item Weight	7.8 ounces
Power Source	Battery Powered (1 Lithium Ion battery included)
Battery Life	Up to 48 Hours
Light Source Type	LED
Control Method	Touch
Special Features	Rechargeable, Touch Control, 30-Minute Timer, Phone Holder
Water Resistance Level	Waterproof (for silicone body, avoid submerging electronic components)
Recommended Age	3 years and up

8. SAFETY INFORMATION

- This product is intended for indoor use.
- Keep out of reach of infants and young children unless supervised, especially during charging.
- Do not disassemble or attempt to repair the device yourself. This may void any warranty and pose a safety risk.
- Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods.
- While the silicone body is water-resistant, avoid submerging the electronic components (charging port, switch) in water.
- Use only the provided charging cable or a certified equivalent.

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Specific warranty details for the AVACOM K-1096 are not provided in this manual. Please refer to the product packaging or contact the retailer for warranty terms and conditions. Standard return policies typically allow for returns within 30 days of purchase.

9.2 Customer Support

For any questions, concerns, or technical assistance, please contact AVACOM customer support through the retailer's platform or visit the official AVACOM store page on Amazon: [AVACOM Store](#).

