

ETA ETA412890030

ETA Gustus IV Maximus Kitchen Robot Instruction Manual

Model: ETA412890030 | Brand: ETA

1. INTRODUCTION

Thank you for purchasing the ETA Gustus IV Maximus Kitchen Robot. This versatile appliance is designed to assist you with a wide range of culinary tasks, including kneading, beating, mixing, grating, chopping, meat grinding, and blending. Featuring a powerful 1200W motor with a stabilizer, an all-metal gearbox, and a planetary mixing system, it ensures efficient and consistent performance even under heavy loads.

Please read this instruction manual carefully before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

Safety Information

- Always unplug the appliance from the power outlet before cleaning, assembling, or disassembling parts.
- Do not immerse the motor unit in water or any other liquid.
- Keep hands and utensils out of the mixing bowl during operation to prevent injury.
- Ensure all attachments are securely in place before operating the appliance.
- The appliance is equipped with safety features, including a thermal fuse to protect the motor from damage due to overload and a safety system on the swivel arm to prevent unintended startup when the arm is tilted.
- Use only original ETA accessories and spare parts.
- This appliance is for household use only.

2. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main components and accessories of your ETA Gustus IV Maximus Kitchen Robot.



Figure 2.1: ETA Gustus IV Maximus Kitchen Robot with all included accessories, including the main unit, two stainless steel bowls, various beaters, a meat grinder attachment, a glass blender, and grating drums.

Main Unit Features:

- Powerful 1200W Motor with Stabilizer
- All-Metal Gearbox
- Planetary Mixing System
- Continuous Speed Control with Pulse Function
- Swivel Arm Safety System
- Non-slip Feet

Included Accessories:

- **2 x 5.5L Stainless Steel Bowls:** For mixing ingredients.



Figure 2.2: The two included 5.5L stainless steel mixing bowls, each marked with "GUSTUS 1200 W".

- **Kneading Hook:** Ideal for preparing yeast dough, bread, and solid doughs.
- **Beater:** Suitable for creams, whipped cream, and spreads.
- **Whisk:** Perfect for preparing cakes and pastries.



Figure 2.3: The kitchen robot demonstrating the whisk, beater, and kneading hook attachments in use with the mixing bowl.

- **1.5L Glass Blender:** For blending liquids, smoothies, and sauces.



Figure 2.4: The ETA Gustus IV Maximus with the 1.5L glass blender attachment securely mounted on top of the main unit.

- **Grater Attachment with 4 Drums:** For grating various ingredients.



Figure 2.5: The ETA Gustus IV Maximus with the grater attachment, showing the feed tube and output chute.

- **Meat Grinder (54mm diameter) with 3 Perforated Plates:** For grinding meat.
- **Sausage Stuffer Attachment:** For making sausages.
- **Knife Sharpener:** For sharpening knives.



Figure 2.6: The ETA Gustus IV Maximus with the meat grinder attachment, ready for use.

3. SETUP AND FIRST USE

Unpacking and Initial Cleaning:

1. Carefully remove all components from the packaging.
2. Wash all removable parts (bowls, attachments, blender jug, grater drums, meat grinder components) in warm soapy water, rinse thoroughly, and dry completely before first use. The main motor unit should only be wiped with a damp

cloth.

3. Place the main unit on a stable, flat, and dry surface. Ensure the non-slip feet are firmly gripping the countertop.



Figure 3.1: Side view of the main unit of the ETA Gustus IV Maximus, showing the control dial and attachment points.

Assembling for Use:

1. **Attaching the Mixing Bowl:** Place a 5.5L stainless steel bowl onto the base of the main unit and twist clockwise until it locks into place.
2. **Lifting the Swivel Arm:** Press the release button (usually located on the side or back of the head) and lift the swivel arm upwards until it locks into the tilted position.



Figure 3.2: The main unit with its head tilted upwards, revealing the attachment point for the mixing tools.

3. **Attaching Mixing Tools (Kneading Hook, Beater, Whisk):** Insert the desired mixing tool into the attachment shaft on the underside of the swivel arm. Push upwards and twist until it clicks securely into place.
4. **Lowering the Swivel Arm:** Press the release button again and gently lower the swivel arm until it locks into the operating position. Ensure it is fully lowered before starting the appliance.
5. **Attaching Other Accessories (Blender, Grater, Meat Grinder):** These accessories attach to specific ports on the main unit, typically on the top or front. Refer to the specific operating instructions for each accessory in the next section.

4. OPERATING INSTRUCTIONS

The ETA Gustus IV Maximus features continuous speed control and a Pulse function for optimal processing of various ingredients.

General Operation:

1. Ensure the appliance is properly assembled and the desired attachment is securely in place.

2. Add ingredients to the mixing bowl or accessory.
3. Plug the appliance into a suitable power outlet.
4. Turn the speed control dial to the desired setting (1-6). Start with a lower speed and gradually increase as needed.
5. For short bursts of maximum power, turn the dial to the "PULSE" setting and hold. Release to stop.
6. When finished, turn the speed dial to "0" and unplug the appliance.

Using Mixing Tools (Kneading Hook, Beater, Whisk):

- **Kneading Hook:** Use for heavy doughs like bread or pizza dough. Start at a low speed (1-2) until ingredients are combined, then increase to medium (3-4) for thorough kneading.
- **Beater:** Ideal for medium-consistency mixtures such as cake batters, cookie doughs, and frostings. Use speeds 2-4.
- **Whisk:** Best for light mixtures like egg whites, whipped cream, and light batters. Use higher speeds (4-6) for aeration.

Using the Glass Blender:

1. Ensure the blender jug is securely attached to its port on the main unit.
2. Add liquids and ingredients to the blender jug. Do not exceed the MAX fill line.
3. Secure the lid firmly.
4. Select a speed setting (1-6) or use the PULSE function for quick blending.
5. Always unplug before removing the jug or lid.

Using the Grater Attachment:

1. Attach the grater housing to its designated port.
2. Insert the desired grating drum into the housing.
3. Secure the pusher.
4. Turn on the appliance to a medium speed (3-5).
5. Feed ingredients through the feed tube using the pusher. Do not use fingers or other utensils.

Using the Meat Grinder:

1. Assemble the meat grinder components (screw, blade, perforated plate, ring nut) and attach the assembled unit to its port.
2. Ensure meat is cut into appropriate sizes and free of bones or excessive sinew.
3. Turn on the appliance to a medium speed (3-4).
4. Feed meat into the hopper using the food pusher.
5. For sausage stuffing, replace the perforated plate and blade with the sausage stuffer attachment.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your appliance.

1. **Always unplug the appliance before cleaning.**
2. **Motor Unit:** Wipe the main motor unit with a soft, damp cloth. Do not immerse it in water or spray it with liquids.
3. **Stainless Steel Bowls and Mixing Tools:** These can be washed in warm soapy water or placed in a dishwasher (check manufacturer's guidelines for specific parts if available, otherwise hand wash is recommended for longevity). Rinse thoroughly and dry immediately to prevent water spots.
4. **Glass Blender Jug:** Disassemble the blade assembly from the jug. Wash all parts in warm soapy water. The jug can often be cleaned by filling it with warm water and a drop of dish soap, then running the blender on a low speed

for a few seconds. Rinse thoroughly.

- 5. **Grater and Meat Grinder Attachments:** Disassemble all parts. Wash immediately after use in warm soapy water to prevent food residue from drying. Use a brush to clean small crevices. Dry thoroughly.
- 6. **Storage:** Store the appliance and its accessories in a clean, dry place.

6. TROUBLESHOOTING

If you encounter issues with your ETA Gustus IV Maximus, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; swivel arm not fully lowered; thermal fuse activated; speed dial not at '0' before starting.	Check power connection; ensure swivel arm is locked down; allow appliance to cool down if overheated; ensure speed dial is at '0' before turning on.
Motor sounds strained or stops during operation.	Overload (too much/too thick ingredients); thermal fuse activated.	Reduce quantity of ingredients; add more liquid if mixture is too thick; turn off and allow to cool for 20-30 minutes before restarting.
Attachments not fitting securely.	Incorrect attachment for the port; not twisted/pushed firmly into place.	Refer to "Setup and First Use" section for correct attachment points; ensure a firm push and twist until it clicks.
Excessive vibration or noise.	Appliance not on a stable surface; uneven load in the bowl; damaged attachment.	Place on a flat, stable surface; redistribute ingredients in the bowl; inspect attachments for damage and replace if necessary.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	ETA412890030
Brand	ETA
Power	1200 Watts
Bowl Capacity	2 x 5.5 Liters (Stainless Steel)
Blender Capacity	1.5 Liters (Glass)
Dimensions (L x W x H)	28 x 41.5 x 36 cm
Weight	12.7 Kilograms
Material	Metal (gearbox), Glass (blender), Stainless Steel (bowls)
Special Features	Adjustable Speed Control, Planetary Mixing System, Pulse Function, Safety Lock, Thermal Protection







8. WARRANTY AND SUPPORT

Your ETA Gustus IV Maximus Kitchen Robot is designed for durability and performance. For information regarding warranty coverage, please refer to the warranty card included with your purchase or contact your retailer.

For technical support, spare parts, or service inquiries, please visit the official ETA website or contact their customer service department. Information regarding spare parts availability is not provided in this manual; please inquire directly with the manufacturer or authorized service centers.

For returns, please adhere to the return policy of your place of purchase, typically within 30 days for refund/replacement.

Related Documents

<div> <div> Wskazówki i instrukcje obsługi - NÁVOD K OBSLUZE </div> <div> Instrukcja obsługi robota - NÁVOD NA OBSLUHU </div> <div> Instrukcja w języku angielskim - INSTRUCTIONS FOR USE </div> <div> Instrukcja w języku niemieckim - INSTRUCCJA OBSŁUGI </div> <div> Instrukcja w języku francuskim - INSTRUCTIONS D'UTILISATION </div> </div> <div> <div> GUSTUS IV </div> <div>  </div> <div>  </div> </div>	<div> <div> ETA Gustus IV Návod k obsluze multifunkčního kuchyňského robota </div> <div> Kompletní návod k obsluze pro multifunkční kuchyňský robot ETA Gustus IV. Zahrnuje bezpečnostní pokyny, návod k použití, údržbu a technické specifikace pro optimální výkon. </div> </div>
<div> <div> Wskazówki i instrukcje obsługi - NÁVOD K OBSLUZE </div> <div> Instrukcja obsługi robota - NÁVOD NA OBSLUHU </div> <div> Instrukcja w języku angielskim - INSTRUCTIONS FOR USE </div> <div> Instrukcja w języku niemieckim - INSTRUCCJA OBSŁUGI </div> <div> Instrukcja w języku francuskim - INSTRUCTIONS D'UTILISATION </div> </div> <div> <div> GUSTUS IV </div> <div>  </div> <div>  </div> </div>	<div> <div> ETA Gustus IV Kitchen Machine Manual </div> <div> Comprehensive user manual for the ETA Gustus IV kitchen machine (model 4128). Includes safety instructions, usage guides for attachments like whisks, mincers, graters, blenders, maintenance, and technical specifications. </div> </div>
<div> <div> Wskazówki i instrukcje obsługi - NÁVOD K OBSLUZE </div> <div> Instrukcja obsługi robota - NÁVOD NA OBSLUHU </div> <div> Instrukcja w języku angielskim - INSTRUCTIONS FOR USE </div> <div> Instrukcja w języku niemieckim - INSTRUCCJA OBSŁUGI </div> <div> Instrukcja w języku francuskim - INSTRUCTIONS D'UTILISATION </div> </div> <div> <div> ETA 2075 Ambo </div> <div>  </div> <div>  </div> </div>	<div> <div> ETA 2075 Ambo: Návod k obsluze mlýnku na maso </div> <div> Podrobný návod k obsluze a bezpečnému používání mlýnku na maso ETA 2075 Ambo od značky ETA. Obsahuje informace o příslušenství, postupech mletí masa, výrobě uzenin, tvarování těsta, údržbě a technických údajích. </div> </div>
<div> <div> Wskazówki i instrukcje obsługi - NÁVOD K OBSLUZE </div> <div> Instrukcja obsługi robota - NÁVOD NA OBSLUHU </div> <div> Instrukcja w języku angielskim - INSTRUCTIONS FOR USE </div> <div> Instrukcja w języku niemieckim - INSTRUCCJA OBSŁUGI </div> <div> Instrukcja w języku francuskim - INSTRUCTIONS D'UTILISATION </div> </div> <div> <div> GRATUS </div> <div>  </div> <div>  </div> </div>	<div> <div> ETA Gratus Robot Kuchenny - Instrukcja Obsługi i Bezpieczeństwa </div> <div> Kompletna instrukcja obsługi robota kuchennego ETA Gratus (model 0028). Dowiedz się, jak bezpiecznie używać, konserwować i wykorzystywać wszystkie funkcje i akcesoria. </div> </div>

[illegible]

KATALOG PRODUKTÓW ETA Z PRZEDZIAŁU GWARANCJI

stan na 1 stycznia 2017 r.

RAMY RUCHOME

Przebieg choroby	Opis choroby	Wiek	Wzrost
Przebieg choroby 1	1. Przewlekłe zapalenie trzustki w stadium I	1	1,000
Przebieg choroby 2	2. Przewlekłe zapalenie trzustki w stadium II	2	1,000
Przebieg choroby 3	3. Przewlekłe zapalenie trzustki w stadium III	3	1,000
Przebieg choroby 4	4. Przewlekłe zapalenie trzustki w stadium IV	4	1,000
Przebieg choroby 5	5. Przewlekłe zapalenie trzustki w stadium V	5	1,000
Przebieg choroby 6	6. Przewlekłe zapalenie trzustki w stadium VI	6	1,000
Przebieg choroby 7	7. Przewlekłe zapalenie trzustki w stadium VII	7	1,000
Przebieg choroby 8	8. Przewlekłe zapalenie trzustki w stadium VIII	8	1,000
Przebieg choroby 9	9. Przewlekłe zapalenie trzustki w stadium IX	9	1,000
Przebieg choroby 10	10. Przewlekłe zapalenie trzustki w stadium X	10	1,000
Przebieg choroby 11	11. Przewlekłe zapalenie trzustki w stadium XI	11	1,000
Przebieg choroby 12	12. Przewlekłe zapalenie trzustki w stadium XII	12	1,000
Przebieg choroby 13	13. Przewlekłe zapalenie trzustki w stadium XIII	13	1,000
Przebieg choroby 14	14. Przewlekłe zapalenie trzustki w stadium XIV	14	1,000
Przebieg choroby 15	15. Przewlekłe zapalenie trzustki w stadium XV	15	1,000
Przebieg choroby 16	16. Przewlekłe zapalenie trzustki w stadium XVI	16	1,000
Przebieg choroby 17	17. Przewlekłe zapalenie trzustki w stadium XVII	17	1,000
Przebieg choroby 18	18. Przewlekłe zapalenie trzustki w stadium XVIII	18	1,000
Przebieg choroby 19	19. Przewlekłe zapalenie trzustki w stadium XIX	19	1,000
Przebieg choroby 20	20. Przewlekłe zapalenie trzustki w stadium XX	20	1,000
Przebieg choroby 21	21. Przewlekłe zapalenie trzustki w stadium XXI	21	1,000
Przebieg choroby 22	22. Przewlekłe zapalenie trzustki w stadium XXII	22	1,000
Przebieg choroby 23	23. Przewlekłe zapalenie trzustki w stadium XXIII	23	1,000
Przebieg choroby 24	24. Przewlekłe zapalenie trzustki w stadium XXIV	24	1,000
Przebieg choroby 25	25. Przewlekłe zapalenie trzustki w stadium XXV	25	1,000
Przebieg choroby 26	26. Przewlekłe zapalenie trzustki w stadium XXVI	26	1,000
Przebieg choroby 27	27. Przewlekłe zapalenie trzustki w stadium XXVII	27	1,000
Przebieg choroby 28	28. Przewlekłe zapalenie trzustki w stadium XXVIII	28	1,000
Przebieg choroby 29	29. Przewlekłe zapalenie trzustki w stadium XXIX	29	1,000
Przebieg choroby 30	30. Przewlekłe zapalenie trzustki w stadium XXX	30	1,000
Przebieg choroby 31	31. Przewlekłe zapalenie trzustki w stadium XXXI	31	1,000
Przebieg choroby 32	32. Przewlekłe zapalenie trzustki w stadium XXXII	32	1,000
Przebieg choroby 33	33. Przewlekłe zapalenie trzustki w stadium XXXIII	33	1,000
Przebieg choroby 34	34. Przewlekłe zapalenie trzustki w stadium XXXIV	34	1,000
Przebieg choroby 35	35. Przewlekłe zapalenie trzustki w stadium XXXV	35	1,000
Przebieg choroby 36	36. Przewlekłe zapalenie trzustki w stadium XXXVI	36	1,000
Przebieg choroby 37	37. Przewlekłe zapalenie trzustki w stadium XXXVII	37	1,000
Przebieg choroby 38	38. Przewlekłe zapalenie trzustki w stadium XXXVIII	38	1,000
Przebieg choroby 39	39. Przewlekłe zapalenie trzustki w stadium XXXIX	39	1,000
Przebieg choroby 40	40. Przewlekłe zapalenie trzustki w stadium XL	40	1,000
Przebieg choroby 41	41. Przewlekłe zapalenie trzustki w stadium XLI	41	1,000
Przebieg choroby 42	42. Przewlekłe zapalenie trzustki w stadium XLII	42	1,000
Przebieg choroby 43	43. Przewlekłe zapalenie trzustki w stadium XLIII	43	1,000
Przebieg choroby 44	44. Przewlekłe zapalenie trzustki w stadium XLIV	44	1,000
Przebieg choroby 45	45. Przewlekłe zapalenie trzustki w stadium XLV	45	1,000
Przebieg choroby 46	46. Przewlekłe zapalenie trzustki w stadium XLVI	46	1,000
Przebieg choroby 47	47. Przewlekłe zapalenie trzustki w stadium XLVII	47	1,000
Przebieg choroby 48	48. Przewlekłe zapalenie trzustki w stadium XLVIII	48	1,000
Przebieg choroby 49	49. Przewlekłe zapalenie trzustki w stadium XLIX	49	1,000
Przebieg choroby 50	50. Przewlekłe zapalenie trzustki w stadium L	50	1,000
Przebieg choroby 51	51. Przewlekłe zapalenie trzustki w stadium LI	51	1,000
Przebieg choroby 52	52. Przewlekłe zapalenie trzustki w stadium LII	52	1,000
Przebieg choroby 53	53. Przewlekłe zapalenie trzustki w stadium LIII	53	1,000
Przebieg choroby 54	54. Przewlekłe zapalenie trzustki w stadium LIV	54	1,000
Przebieg choroby 55	55. Przewlekłe zapalenie trzustki w stadium LV	55	1,000
Przebieg choroby 56	56. Przewlekłe zapalenie trzustki w stadium LVI	56	1,000
Przebieg choroby 57	57. Przewlekłe zapalenie trzustki w stadium LVII	57	1,000
Przebieg choroby 58	58. Przewlekłe zapalenie trzustki w stadium LVIII	58	1,000
Przebieg choroby 59	59. Przewlekłe zapalenie trzustki w stadium LIX	59	1,000
Przebieg choroby 60	60. Przewlekłe zapalenie trzustki w stadium LX	60	1,000
Przebieg choroby 61	61. Przewlekłe zapalenie trzustki w stadium LXI	61	1,000
Przebieg choroby 62	62. Przewlekłe zapalenie trzustki w stadium LXII	62	1,000
Przebieg choroby 63	63. Przewlekłe zapalenie trzustki w stadium LXIII	63	1,000
Przebieg choroby 64	64. Przewlekłe zapalenie trzustki w stadium LXIV	64	1,000
Przebieg choroby 65	65. Przewlekłe zapalenie trzustki w stadium LXV	65	1,000
Przebieg choroby 66	66. Przewlekłe zapalenie trzustki w stadium LXVI	66	1,000
Przebieg choroby 67	67. Przewlekłe zapalenie trzustki w stadium LXVII	67	1,000
Przebieg choroby 68	68. Przewlekłe zapalenie trzustki		



GUSTUS MAXIMUS IV
Illustration

Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Parma Schöngut
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



GUSTUS MAXIMUS IV
Illustration

Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Parma Schöngut
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



GUSTUS MAXIMUS IV
Illustration

Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Parma Schöngut
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



GUSTUS MAXIMUS IV
Illustration

Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Parma Schöngut
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



GUSTUS MAXIMUS IV
Illustration

Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Parma Schöngut
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



GUSTUS MAXIMUS IV
Illustration

Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration



Handvoll köstlicher
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Parma Schöngut
Brotchen, Braten und Backen
mit dem GUSTUS MAXIMUS IV
Illustration

Poulíková Lenka KATALOG PRODUKTÓW ETA Z PRZEDŁUŻONĄ GWARANCJĄ ETA342390000
Odkurzacz Verto II 3 Silnik ETA344290000 Li ion ETA344790000 Dasty Przedłużenie gwarancji eta
polska pl images uploader files ||

lang:it score:18 filesize: 977.01 K page_count: 12 document date: 2024-11-18

Pouličková Lenka Lista produktów z przedłużoną gwarancjąNacznice do miksowania ETA 0021 30011
PolskaPrzedluzenie 20gwarancji 20ETA 1cdn shopify s files 1 0960 3452 1417 Przedluzenie v
1753185368 |||

lang:it score:17 filesize: 534.7 K page count: 12 document date: 2024-11-18

Produktdatenblatt eta Küchenmaschine GUSTUS MAXIMUS IV ETA412890030 1200 W 5 l Schüssel
615d097f 11a0 5f6a 8ce5 36338401cb0e d otto de files |||

lang:de score:12 filesize: 599.59 K page count: 2 document date: 2023-09-25