## HIGH GODO 7855

# HIGH GODO Cherry Blossom Bonsai Tree Micro Building Set Instruction Manual

Model: 7855 | Brand: HIGH GODO

Introduction Safety Information Package Contents Assembly Usage & Display Maintenance Troubleshooting Specifications Warranty & Support

## 1. Introduction

Thank you for choosing the HIGH GODO Cherry Blossom Bonsai Tree Micro Building Set. This intricate 2200-piece micro block kit allows you to construct a detailed Japanese Sakura tree house model. Designed for enthusiasts aged 14 and up, this set offers a rewarding building experience, culminating in a beautiful display piece.

Please read this manual carefully before beginning assembly to ensure a smooth and enjoyable building process. Keep this manual for future reference.



Figure 1: The completed Cherry Blossom Bonsai Tree model.

## 2. Safety Information

**WARNING: CHOKING HAZARD - Small Parts.** Not for children under 3 years. This building set contains micro-sized blocks which are significantly smaller than traditional building blocks. Keep all parts away from young children and pets to prevent accidental ingestion.

- Recommended age: 14 years and up.
- Always build in a well-lit area.
- Keep parts organized to avoid loss.
- Dispose of packaging materials responsibly.

## 3. Package Contents

Before starting assembly, verify that all components are present. The package should contain:

- Approximately 2200 micro building blocks (various shapes and colors).
- 1 x Instruction Manual (this document).
- 1 x Brick Separator (may be included for easier disassembly).




Figure 2: Example of package contents including micro blocks and manual.




Figure 3: Micro block size comparison. Note that these blocks are significantly smaller than standard building blocks.

## 4. Assembly Instructions

The assembly of the Cherry Blossom Bonsai Tree is a detailed process. Follow the step-by-step pictorial instructions provided in the printed manual carefully. Due to the small size of the micro blocks, patience and precision are key.

### 4.1 General Tips for Assembly

- **Organize Parts:** Before starting, sort the blocks by color and shape. This will significantly speed up the building process.
- **Work Surface:** Use a clean, flat, and well-lit surface to prevent losing small pieces.
- **Follow Steps Sequentially:** Do not skip steps. Each step builds upon the previous one.
- **Gentle Pressure:** Apply gentle, firm pressure to connect blocks. Avoid excessive force, which can damage pieces.
- **Refer to Images:** Pay close attention to the images in the instruction manual for correct placement and orientation of blocks.

### 4.2 Key Building Areas

The model features several distinct sections:

- **Base and Water Feature:** Construct the foundation and the blue water elements first.
- **Tree Trunk and Branches:** Build the central tree structure, ensuring stability for the upper sections.
- **Treehouse and Swing:** Integrate the treehouse and swing components into the main tree structure.
- **Stairs and Pathways:** Assemble the stairs leading up to the treehouse and any surrounding pathways.
- **Cherry Blossoms and Foliage:** Attach the numerous small flower pieces to create the dense cherry blossom canopy and ground foliage.




Figure 4: Detailed views of the treehouse, swing, dining area, and stairs.

### 4.3 Assembly Video Guide

For a visual guide to the assembly process, please refer to the official product video below. This video demonstrates key steps and provides a clearer understanding of the model's construction.

Your browser does not support the video tag.

Video 1: Official HIGH GODO Cherry Blossom Tree Set Assembly Overview. This video provides a visual demonstration of the completed model and its various features, offering insight into the building process.

## 5. Usage and Display

Once assembled, your HIGH GODO Cherry Blossom Bonsai Tree is designed as a decorative display piece. It is not intended for rough play due to the delicate nature of micro blocks and intricate connections.

- **Display Location:** Place the model on a stable, flat surface away from direct sunlight, excessive heat, or high humidity to prevent material degradation.
- **Handling:** Handle the model gently, preferably by its base, to avoid dislodging small pieces.
- **Interaction:** While some elements like the swing may have slight movement, avoid excessive manipulation to maintain structural integrity.



Figure 5: Gentle handling during assembly and display is recommended.

## 6. Maintenance

To keep your Cherry Blossom Bonsai Tree model looking its best:

- **Dusting:** Use a soft, dry brush or a can of compressed air to gently remove dust from the model. Avoid using wet cloths or harsh cleaning agents.
- **Storage:** If disassembling for storage, keep all pieces in a sealed container to prevent loss and protect them from dust.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Missing parts | Small size of micro blocks; accidental loss during unboxing or assembly. | Carefully check all packaging materials. If parts are genuinely missing, contact HIGH GODO customer support with details of the missing pieces (refer to the parts list in the manual). |
| Model is unstable or parts fall off easily | Blocks not fully connected; incorrect placement; structural weakness in certain sections (e.g., stairs, branches). | Review the assembly steps for the unstable section. Ensure all blocks are firmly pressed together. For known delicate areas like stairs, apply extra care during assembly and handling. |
| Difficulty connecting blocks | Incorrect block orientation; burrs on blocks; insufficient pressure. | Ensure blocks are oriented correctly as per the instructions. Use gentle, firm pressure. If a block has a burr, carefully remove it with a small file or knife (adult supervision recommended). |

## 8. Specifications

**Model Number:** 7855

**Product Dimensions:** 5.7 x 7 x 5.9 inches (assembled)

**Item Weight:** 13.1 ounces

**Number of Pieces:** Approximately 2200 micro blocks

**Material:** Original ABS plastic

**Recommended Age:** 14 years and up

**Manufacturer:** HIGH GODO

## 9. Warranty and Customer Support

HIGH GODO is committed to providing high-quality products. If you encounter any issues with your building set, such as missing parts or manufacturing defects, please contact our customer support team.
For assistance, please refer to the contact information provided on the product packaging or the official HIGH GODO website. Please have your model number (7855) and purchase details ready when contacting support.

© 2024 HIGH GODO. All rights reserved.