

[Manuals.plus](#) /

› [Samsonite](#) /

› Samsonite Framelock Max 29" Large Checked Hardshell Zipperless Luggage Instruction Manual

Samsonite Framelock Max 29" Large Spinner

Samsonite Framelock Max 29" Large Checked Hardshell Zipperless Luggage Instruction Manual

Brand: Samsonite | Model: Framelock Max 29" Large Spinner

INTRODUCTION

The Samsonite Framelock Max 29" Large Checked Hardshell Zipperless Luggage is engineered for secure and effortless travel. Its innovative design combines durability with modern functionality, ensuring your belongings are protected and easily accessible. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new luggage.

KEY FEATURES

- **Zipper-Less Security:** Innovative Eazylock centralized slide puller ensures effortless locking and unlocking with keyless TSA-approved security.
- **Sleek & Durable Design:** Sophisticated polycarbonate shell with an eye-catching logo plate for a modern, premium look.
- **RightHeight Handle System:** Designed for ultimate comfort and ease, the adjustable RightHeight handle system features multiple 1-inch incremental height adjustments, allowing travelers to find their ideal handle height.
- **360° Dual Spinner Wheels:** Navigate busy terminals and city streets with ease thanks to the smooth-gliding 360° dual spinner wheels. Engineered for superior stability and effortless movement, these high-performance wheels allow the suitcase to glide seamlessly in any direction, minimizing drag and reducing the need for tilting or lifting.

SETUP & FIRST USE

Eazylock Mechanism

Your Framelock Max luggage features a secure zipperless design with an integrated Eazylock mechanism. To open, locate the centralized slide puller on the side of the luggage and pull it to release the latches. To close, align the two halves of the luggage and push them together firmly until the latches engage. Then, slide the puller to lock the case.



Image: A detailed view of the integrated Eazylock mechanism and TSA-approved combination lock on the side of the Samsonite Framelock Max luggage, highlighting its zipperless security feature.

Setting Your Combination Lock

The luggage comes with a TSA-approved combination lock preset to 0-0-0. To set your personal combination:

1. Open the lock by sliding the puller.
2. Locate the small reset button (often recessed) next to the dials. Use a pen or pointed object to push and hold this button.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set.
5. Test your new combination by scrambling the dials and then entering your set combination to open the lock.

Your browser does not support the video tag.

Video: Official video demonstrating the key features and functionality of the Samsonite Framelock Max luggage, including its zipperless design and interior organization. This video also shows the lock mechanism.

OPERATING INSTRUCTIONS

RightHeight Handle System

The RightHeight handle system offers multiple incremental height adjustments for personalized comfort. To extend or retract the handle, press the button located on the handle grip and pull or push the handle to your desired height. Release the button to lock it in place.



Image: The Samsonite Framelock Max luggage in blue teal with its adjustable RightHeight handle fully extended, showcasing its sleek hardshell design and spinner wheels.

360° Dual Spinner Wheels

Your luggage is equipped with 360° dual spinner wheels for superior maneuverability. These wheels allow the suitcase to glide effortlessly in any direction, making it easy to navigate through airports and crowded spaces. You can push, pull, or roll the luggage alongside you with minimal effort.



Image: A detailed view of the durable 360-degree spinner wheels on the Samsonite Framelock Max luggage, designed for smooth and effortless maneuverability.

Interior Organization

The interior of your Framelock Max luggage is designed for maximum packing capacity and organization. It features two interior zippered dividers made with Recyclex® material, along with additional zippered pockets to keep your belongings neatly separated and secure during transit.



Image: The spacious interior of the Samsonite Framelock Max luggage, showing two main compartments with zippered dividers made from Recyclex®, and additional zippered pockets for organized packing.

MAINTENANCE

- **Cleaning the Exterior:** Wipe the polycarbonate hardshell with a soft, damp cloth and mild soap. Avoid abrasive cleaners that may scratch the surface.
- **Wheel Care:** Periodically check the spinner wheels for any debris or hair that may hinder their smooth operation. Clean as needed.
- **Interior Cleaning:** The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing the luggage.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Lock Not Engaging:** Ensure the two halves of the luggage are perfectly aligned and pressed firmly together before attempting to slide the Eazylock mechanism. Overstuffing the luggage can prevent proper closure.
- **Stuck Handle:** If the RightHeight handle becomes difficult to extend or retract, check for any

obstructions in the telescoping tubes. Apply a silicone-based lubricant if necessary.

- **Wheels Not Rolling Smoothly:** Clean any accumulated dirt, lint, or hair from around the wheel axles. If the issue persists, the wheels may require professional servicing.
- **Combination Lock Issues:** If you forget your combination, contact Samsonite customer support for assistance. Do not attempt to force the lock open, as this may damage the mechanism.

SPECIFICATIONS

Wheel Type	Spinner
Number of Wheels	8
Lock Type	TSA Approved Keyless Lock
Water Resistance Level	Water Resistant
Handle Type	Telescopic Extendable Handle (RightHeight System)
Item Dimensions (L x W x H)	21"L x 13"W x 29"H
Item Weight	11.4 Pounds
Material Type	Polypropylene (PP)
Shell Type	Hard
Model Number	149619-4127
UPC	043202987090



Image: An image illustrating the external dimensions of the Samsonite Framelock Max 29-inch large spinner luggage, measuring 21 inches in length, 13 inches in width, and 29 inches in height.

WARRANTY AND SUPPORT

Samsonite products are rigorously tested to ensure they meet stringent standards. This luggage comes with a limited warranty against defects in materials and workmanship. For detailed warranty information, service inquiries, or to contact customer support, please visit the official Samsonite website or refer to the warranty

card included with your purchase.

For further assistance, you may also visit the [Samsonite Store on Amazon](#).