

[Manuals.plus](#) /

› [Chihee](#) /

› Chihee CHZP/SD180190 4-Person Tunnel Camping Tent Instruction Manual

Chihee CHZP/SD180190


Chihee 4-Person Tunnel Camping Tent

MODEL: CHZP/SD180190

[Introduction](#) [Safety Information](#) [Package](#)
[Contents](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your Chihee CHZP/SD180190 4-Person Tunnel Camping Tent. This tent is designed for various outdoor activities including camping, hiking, backpacking, and more, offering weather resistance and ample space.



The tent features a PU2000mm waterproof outer tent and inner tent groundsheets for reliable protection against rain and moisture. Its curved pole structure enhances wind resistance, and sloping walls facilitate efficient shedding of rain and snow. The design maximizes usable space, providing comfortable sleeping areas and additional room for storage or cooking.

2. Safety Information

Read and understand all instructions before setting up and using the tent. Failure to follow these instructions may result in injury or damage to the product.

- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The tent is made of flammable

material and will burn if exposed to an open flame.

- **Ventilation:** Ensure adequate ventilation to prevent suffocation and condensation buildup. Do not use fuel-burning devices inside the tent.
- **Weather Conditions:** While designed for various seasons, extreme weather conditions (e.g., severe storms, heavy snow, strong winds) may exceed the tent's capabilities. Seek appropriate shelter in such conditions.
- **Site Selection:** Choose a level, clear area free of sharp objects, rocks, and debris. Avoid setting up under trees with dead branches.
- **Children:** Keep children away from the tent during setup and takedown. Adult supervision is required when children are inside or near the tent.

3. Package Contents

Verify that all components are present before beginning assembly:

--

- Outer Tent x 1
- Inner Tent x 1
- Tent Pole x 3 (Fiberglass)
- Guy Line x 8
- Ground Peg x 18 (Aluminum)
- Door Pole x 2 (for porch setup)
- Storage Bag x 1

4. Setup Instructions

The Chihee Tunnel Tent is designed for effortless setup, typically taking approximately 5 minutes for the main structure. Follow these steps for assembly:

1. **Unpack Components:** Lay out the outer tent on a clear, flat surface. Unpack all poles, pegs, and guy lines from the storage bag.
2. **Assemble Tent Poles:** The three main tent poles are connected by elastic cords. Extend each pole fully until all sections are securely joined.
3. **Insert Poles:** Slide the assembled poles through the sleeves on the outer tent. The curved design of the poles will help form the tunnel shape.
4. **Secure Poles:** Attach the ends of the poles to the designated clip mechanisms at the base of the tent.
5. **Stake the Tent:** Secure the four corners of the tent to the ground using the aluminum ground pegs. This provides initial stability.
6. **Attach Guy Lines:** Extend and stake out the eight guy lines to further stabilize the tent, especially in windy conditions. Adjust tension as needed.
7. **Install Inner Tent:** Once the outer tent is pitched, attach the inner tent to the hanging loops inside the outer tent. Secure the inner tent's groundsheet to the floor of the outer tent.
8. **Porch Setup (Optional):** If desired, use the two door poles to create a porch at one of the entrances. Secure with additional guy lines and pegs.

CAMPING TENT DETAILS



Hooded Apertures
can be opened & closed
for well ventilation



Double-sided Zipper
for easy entry and exit



Hook & Loop
for effortless hanging
of inner tents



Sleeves & Hooks
fix poles forming the
structure, strong & reliable.



Collapsible Poles
are connected by an elasticated
cord for ease of folding and packing



Tape Closure
for enhanced wind
& rain protection

For a visual guide, please refer to the official setup video:

Your browser does not support the video tag. This video demonstrates the step-by-step assembly of the Chihee 4-Person Tunnel Camping Tent, including pole insertion, staking, and inner tent setup.

5. Operating the Tent Features


The tent is equipped with several features to enhance your camping experience:

- **Doors:** The tent features two entrances for convenient access. Each door has a double-sided zipper for easy entry and exit.
- **Ventilation:** The inner tent incorporates B3 mesh to facilitate airflow and prevent condensation. Two windows also feature fine mesh for additional ventilation while keeping insects out.
- **Storage Pockets:** Internal storage pockets are provided for organizing small items like headlamps, phones, or glasses.
- **Porch Area:** The front porch provides a transitional area, offering shelter from the sun or a space for gear


storage.



DOUBLE LAYERED DOOR
can be closed simultaneously or individually



Densified Net



Multiple Large Storage Bags



Foldable Door Curtain



Mesh Window



Inner Tent Utilizes a Hanging Design



Internal Storage Pouches



Mesh Ventilation Windows



Double-sized Zippers



Hook & Loop Storage for Rolled Up Curtains



Sleeves & Hooks for Tent Poles Attachment



Each Tent Pole is Connected by an Elasticated Cord

6. Maintenance

Proper care and maintenance will extend the life of your tent:

- **Cleaning:** Clean the tent with a soft brush or sponge and mild soap. Do not use harsh detergents or bleach. Rinse thoroughly with water.
- **Drying:** Always ensure the tent is completely dry before packing it away to prevent mildew and odor. Air dry in a shaded area.
- **Storage:** Store the tent in its carry bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Seam Sealing:** Periodically inspect seams for wear. Applying a seam sealer can help maintain the tent's waterproof integrity over time.
- **Pole Care:** Inspect poles for damage before and after each use. Replace any bent or broken sections promptly.



7. Troubleshooting

Here are solutions to common issues you might encounter:

- **Tent Instability:** Ensure all poles are correctly inserted and secured. Fully extend and properly stake all guy lines. Adjust tension to make the tent taut.
- **Water Leakage:** Check for any tears or punctures in the fabric. Ensure all zippers are fully closed. Apply seam sealer to worn seams if necessary.
- **Condensation Inside:** Increase ventilation by opening doors (mesh only) and windows. Ensure the tent is not pitched in a low-lying, damp area.
- **Difficulty Packing:** Ensure all air is expelled from the tent fabric before folding. Fold neatly and roll tightly to fit into the carry bag.

8. Specifications

Feature	Detail
Brand	Chihee
Model Name	CHZP/SD180190
Product Dimensions (L x W x H)	145.7"L x 86.6"W x 51.2"H (370cm x 220cm x 130cm)
Item Weight	5.16 Kilograms (11.38 lbs)

Feature	Detail
Occupancy	4 Person
Seasons	4 Season
Water Resistance Technology	PU2000mm
Material Type	100% Polyester (Fabric), Fiberglass (Poles), Aluminum (Stakes)
Number Of Doors	2
Number Of Windows	2
Number Of Poles	3
Assembly Time	5 Minutes (approx.)
UV Protection	Yes

9. Warranty and Support

This Chihee tent comes with a manufacturer's warranty valid for 2 years from the date of purchase. For warranty claims, technical support, or any questions regarding your product, please contact Chihee customer service through the retailer where the product was purchased or visit the official Chihee website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CQS99MRV>

More documents and user manuals: <https://manuals.plus/>