

[Manuals.plus](#) /

› [Jzones](#) /

› Jzones CT11 Open Ear Headphones User Manual

Jzones CT11

Jzones CT11 Open Ear Headphones User Manual

Model: CT11

INTRODUCTION

Welcome to the Jzones CT11 Open Ear Headphones user manual. These wireless Bluetooth 5.3 earbuds are designed to provide a superior audio experience while maintaining awareness of your surroundings. Featuring dual 16.2mm dynamic drivers, a secure and comfortable open-ear fit, and extended battery life, the CT11 is ideal for sports, daily commutes, and various activities.

WHAT'S IN THE BOX

- Wearable Stereo Earbuds (Left and Right)
- 1x 1000mAh Charging Case
- 1x Type-C Cable
- User Manual

Long Battery Life

1000mAH
Charging Case

60Hrs
Listening Time

12Hrs
Listen Time with
Single Charging



60Hrs
Listening Time

12Hrs
Listen Time with Single Charging

1000mAH
Charging Case



Image: Contents of the Jzones CT11 Open Ear Headphones package, including the earbuds, charging case, USB-C cable, and user manual.

SETUP

1. Initial Charging

Before first use, fully charge the charging case and earbuds. Connect the provided Type-C cable to the charging port on

the back of the case and to a 5V/1A power source. The LED indicator on the front of the case will show charging status.

Open Ear Headphones

Extreme comfort without hearing loss



Image: The Jzones CT11 charging case with a glowing LED indicator, showing it is charging.

2. Pairing with Your Device

1. Ensure the earbuds are in the charging case and the case is open.
2. Activate Bluetooth on your smartphone or other compatible device.
3. In your device's Bluetooth settings, search for "CT11" and select it to pair.

4. Once paired, the earbuds are ready for use. They will automatically connect to the last paired device when removed from the case.



Image: A smartphone screen showing "CT11" as a connected Bluetooth device, with the earbuds and case nearby.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The Jzones CT11 features an open-ear design with ergonomic silicone earhooks. Place the earbuds over your ears, ensuring the earhooks sit securely behind your ear. The audio drivers rest outside the ear canal, allowing you to hear your audio while remaining aware of ambient sounds.

Hi-Fi Sound Quality

Delivers clear sound, powerful volume,
and best audio experience



HD

High-Fidelity Audio



16.2mm Premium Drivers



Crystal Clear Call

Image: A person wearing the Jzones CT11 Open Ear Headphones, demonstrating the secure fit with the earhooks.

Touch Controls

The earbuds are equipped with smart touch controls for easy management of music and calls:

- **Play/Pause:** Tap once.
- **Next/Previous Track:** Tap twice (Left for previous, Right for next).
- **Answer/Hang Up Call:** Tap twice.

- **Reject Call:** Long press for 2 seconds.
- **Voice Assistant:** Tap three times.
- **Volume Up/Down:** Hold on (specific earbud for up/down).





Image: A visual guide detailing the touch control functions for the Jzones CT11 earbuds.

Audio Experience

Equipped with dual 16.2mm dynamic drivers, these headphones deliver crystal-clear HD stereo sound. The open-ear design allows for situational awareness, making them suitable for outdoor activities where hearing your surroundings is important.



Image: Individuals engaged in physical activity, wearing Jzones CT11 Open Ear Headphones, highlighting their suitability for active use while maintaining environmental awareness.

MAINTENANCE

Water Resistance

The Jzones CT11 headphones are IPX5 waterproof, meaning they are resistant to water splashes and sweat. This makes them suitable for workouts and outdoor sports. However, they are not designed for submersion in water (e.g., swimming).

IPX5 Waterproof

Water splash and sweat resistance, ready for all sports.



Image: Jzones CT11 Open Ear Headphones shown with water droplets, illustrating their IPX5 water resistance.

Cleaning and Storage

Wipe the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals. Store the headphones in their charging case when not in use to protect them and ensure they remain charged.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, the case is open, and your device's Bluetooth is on. Forget "CT11" from your device's Bluetooth list and try pairing again.
- **No sound:** Check the volume levels on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Intermittent connection:** Move closer to your paired device. Ensure there are no significant obstructions between the earbuds and your device.
- **Earbuds not charging:** Ensure the charging cable is securely connected to both the case and the power source. Check the charging port for any debris.

SPECIFICATIONS

Feature	Detail
Model Name	CT11
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Size	16.2mm Dynamic Drivers
Battery Life (Earbuds)	Up to 12 hours (music), 10 hours (talk time)
Total Playtime (with Charging Case)	Up to 60 hours
Charging Case Battery Capacity	1000mAh
Charging Time	1.5 Hours
Water Resistance Level	IPX5 (Splashproof, Sweatproof)
Bluetooth Range	Up to 100 meters (33 feet standard)
Control Type	Touch Control

OFFICIAL PRODUCT VIDEOS

Your browser does not support the video tag.

Video: An overview of the Jzones CT11 Open Ear Headphones, highlighting key features such as Bluetooth 5.3, Hi-Fi Stereo, IPX5 Waterproofing, 60 hours playtime, comfort design, and touch control.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided in the packaging or visit the official Jzones website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question