

[Manuals.plus](#) /

> [John Deere](#) /

> John Deere Bubble Leaf Blower Toy Instruction Manual

John Deere 470146

John Deere Bubble Leaf Blower Toy Instruction Manual

PRODUCT OVERVIEW

The John Deere Bubble Leaf Blower Toy is designed to provide an engaging outdoor play experience for children aged 3 and up. This motorized toy features a realistic design and mechanical sounds to encourage imaginative play and role-playing activities, such as helping with yard work. It produces a continuous stream of bubbles with a simple trigger press and includes a refillable gas can for bubble solution.

**ENCOURAGE IMAGINATION
& ACTIVE PLAY!**



Image: A child happily operating the John Deere Bubble Leaf Blower Toy, creating numerous bubbles in an outdoor setting.

PACKAGE CONTENTS

Verify that all items are present in the package:

- John Deere Bubble Leaf Blower
- 44oz Bubble Refill Gas Can (pre-filled with bubble solution)



Image: The John Deere Bubble Leaf Blower and its accompanying bubble solution gas can, displayed within their retail packaging.

SETUP INSTRUCTIONS

1. Battery Installation

The John Deere Bubble Leaf Blower requires 3 AA batteries (not included). Ensure batteries are inserted with correct polarity.

2. Filling the Bubble Solution

The toy comes with a 44oz Bubble Refill Gas Can. To fill the bubble blower:

1. Unscrew the cap on the bubble solution reservoir located on the top of the leaf blower.
2. Carefully pour the bubble solution from the refill gas can into the reservoir. Do not overfill.
3. Securely screw the cap back onto the reservoir.



Image: A close-up view of the bubble solution being poured from the John Deere-themed gas can into the toy leaf blower's reservoir.



Image: A detailed shot showing the bubble solution filling the designated reservoir on the toy, ensuring it is ready for use.

OPERATING INSTRUCTIONS

Once the batteries are installed and the bubble solution is filled, the toy is ready for use:

1. Hold the leaf blower by the handle.
2. Locate the easy-push trigger on the handle.
3. Squeeze and hold the trigger to activate the blower and create a continuous stream of bubbles. The blower will also produce mechanical sounds.

The blower is designed for continuous operation as long as the trigger is held, allowing for extended bubble play. Release the trigger to stop the bubbles and sounds.



Image: A child demonstrating how to hold and activate the toy leaf blower, with bubbles emerging from the nozzle.

Official Product Video



Video: An official product video demonstrating the features and operation of the John Deere Bubble Leaf Blower Toy, including its bubble-blowing action and realistic sounds.

MAINTENANCE

To ensure the longevity and proper function of your John Deere Bubble Leaf Blower Toy:

- **Cleaning:** Wipe the toy with a dry cloth after each use to remove any bubble residue.
- **Storage:** Store the toy in a dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|------------------------------------|--|--|
| No bubbles or weak bubble stream. | Low bubble solution level or depleted batteries. | Refill the bubble solution reservoir. Replace batteries with new AA batteries. |
| Blower does not turn on. | Incorrectly installed or depleted batteries. | Check battery polarity and ensure they are fresh. Replace if necessary. |
| Blower makes noise but no bubbles. | Bubble solution reservoir is empty or bubble mechanism is clogged. | Ensure the reservoir is filled. Gently clean the bubble wand area if visible residue is present. |

SPECIFICATIONS

Brand: John Deere

Model Number: 470146

Material Type: Plastic

Color: Green and Yellow

Item Dimensions (L x W x H): 18"L x 5.5"W x 7.3"H

Power Source: Battery Powered

Batteries Required: 3 AA batteries (not included)

Included Components: John Deere Bubble Leaf Blower, 44oz Bubble Refill Gas Can

Manufacturer Minimum Age: 36 Months

Educational Objective: Encourage imaginative play, role-playing, understanding of chores, and basic bubble science.

SAFETY INFORMATION

WARNING: Choking Hazard - Small parts. Not for children under 3 years. Adult supervision is recommended during use.

Always ensure the bubble solution is handled by an adult or under adult supervision. Avoid contact with eyes. In case of contact, rinse thoroughly with water.