

[Manuals.plus](#) /

› [Household Essentials](#) /

› Household Essentials HE1144 Over-The-Washer Storage Shelf Instruction Manual

Household Essentials HE1144

Household Essentials HE1144 Over-The-Washer Storage Shelf Instruction Manual

Model: HE1144

1. PRODUCT OVERVIEW

The Household Essentials HE1144 Rear Display Over-The-Washer Storage Shelf is designed to provide convenient storage for laundry room supplies. It fits over most front-load washers and dryers that feature average-height rear ledges and control panels. Constructed from durable steel with a protective vinyl coating, this shelf helps prevent scratches on your appliances.

Key features include:

- Designed to fit most front-load washers and dryers with average-height rear ledges and control panels.
- Fixed arm length of 18.75 inches between attachment points, with bendable arms for a custom, secure fit.
- Made from strong steel with a protective vinyl coating to prevent appliance scratches.
- Holds up to 25 lbs of laundry supplies, such as detergent, dryer sheets, and fabric softeners.
- Measures 10 inches in depth and 26.5 inches in width.

2. SAFETY INFORMATION

Please read and follow all safety instructions carefully before assembly and use.

- Always assemble the shelf according to the provided instructions.
- Ensure the shelf fits your appliance correctly, is level, and securely braced.
- Do not use this shelf if your washing machine or dryer does not have a rear control panel or a suitable rear lip for support.
- Do not overload the shelf. The maximum weight capacity is 25 lbs (11.3 kg).
- Requires adequate space behind your appliances for proper installation and stability.

3. PACKAGE CONTENTS

Your Household Essentials HE1144 Over-The-Washer Storage Shelf package includes:

- 1 x Storage Shelf Unit
- Necessary Hardware for Assembly

4. SETUP AND INSTALLATION

Assembly is required. Follow these steps to install your storage shelf:

1. **Measure Your Appliances:** Before installation, measure your washer and dryer to ensure they meet the requirements. The shelf measures 10 inches in depth and 26.5 inches in width. Ensure you have at least 10 inches of space behind your appliance for proper installation.
2. **Position the Shelf:** Place the shelf unit over the rear display panel of your front-load washer or dryer. The hooks on the shelf are designed to rest over the top edge of the appliance's control panel.
3. **Adjust the Support Arms:** The support arms have a fixed length of 18.75 inches between their attachment points on the shelf. These arms can be carefully bent to create a custom fit that tightens securely against the back panel of your appliance. Ensure the shelf is level and stable after adjustment.
4. **Secure the Brackets:** The lower end of the brackets should brace against the back of the appliance. The vinyl coating on the arms helps protect your appliance from scratches.
5. **Verify Stability:** Once installed, gently test the shelf's stability. It should not wobble or shift. If it does, re-adjust the support arms for a tighter fit.

Visual Guide:



Setup requirements and bracket adjustment.




Shelf dimensions for proper fit.

SET UP Requirements*

10 inches behind washer or dryer

26.5 inches accross




Bend bracket to brace lower end on the back of appliance.

Hook over top of appliance display.

*Will NOT fit all washers / dryers. Requires appliances with rear display panels and 10" clearance behind them. Brackets hook onto panel and brace against back of appliance.

Top view of the shelf with support arm attachment points.



Side view showing the support arm design.

5. OPERATING INSTRUCTIONS

Once installed, the Household Essentials Over-The-Washer Storage Shelf provides a convenient surface for your laundry essentials.

- Place laundry supplies such as detergent bottles, dryer sheets, fabric softeners, and other small items on the shelf.
- Distribute weight evenly across the shelf to maintain stability.
- Do not exceed the maximum weight capacity of 25 lbs (11.3 kg).

Product in Use:



Shelf in use on a washing machine.



Shelf holding various laundry supplies.

6. MAINTENANCE

To keep your storage shelf in optimal condition:

- Wipe the shelf with a dry cloth as needed to remove dust or spills.
- Avoid using abrasive cleaners or harsh chemicals, which could damage the vinyl coating.
- Periodically check the stability of the shelf and re-adjust the support arms if necessary to ensure a secure fit.

7. TROUBLESHOOTING

If you encounter issues with your storage shelf, consider the following:

- **Shelf is not stable or wobbles:** Ensure the support arms are bent sufficiently to brace tightly against the back panel of your appliance. Verify that the appliance has a suitable rear ledge or control panel for the hooks to rest on.
- **Shelf does not fit:** This shelf is designed for most front-load washers and dryers with average-height rear ledges.

Low-profile or angled control panels may not provide a secure fit. Confirm your appliance dimensions and rear panel design are compatible.

- **Shelf scratches appliance:** The shelf is designed with a protective vinyl coating. Ensure the rubber inserts on the support arms are in place and that the arms are not scraping against the appliance during installation or use.
- **Items fall off the shelf:** Ensure the shelf is level. Avoid overloading the shelf beyond its 25 lbs capacity. Distribute items evenly.
- **Requires space behind appliances:** Proper installation requires space behind your appliances. If the shelf is unstable, check if there is enough clearance for the support arms to extend and brace correctly.

8. SPECIFICATIONS

Model Number	HE1144
Material	Metal (Steel with Vinyl Coating)
Color	Silver
Product Dimensions (D x W x H)	10"D x 26.5"W x 5"H
Item Weight	1.7 pounds
Weight Capacity Maximum	25 pounds
Mounting Type	Over-The-Appliance
Room Type	Laundry Room
Number of Shelves	1
Special Feature	Space Saving
Installation Type	Over-the-Appliance
Included Components	Hardware

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact Household Essentials customer service directly. Contact details can typically be found on the manufacturer's website or product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CQTQC6JL>

More documents and user manuals: <https://manuals.plus/>