

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VIPERTEK](#) /

> [VIPERTEK VTS-880 Mini Stun Gun User Manual](#)

## VIPERTEK VTS-880

# VIPERTEK VTS-880 Mini Stun Gun User Manual

Model: VTS-880

## INTRODUCTION

---

This manual provides comprehensive instructions for the safe and effective use of your VIPERTEK VTS-880 Mini Stun Gun. Please read all instructions carefully before operating the device. The VIPERTEK VTS-880 is designed as a personal defense tool, featuring a powerful stun function and an integrated LED flashlight, all within a compact and portable design.

## IMPORTANT SAFETY INFORMATION

---

**WARNING:** This device is intended for self-defense purposes only. Misuse may result in serious injury or death. Always check local and state laws regarding the legality of owning and carrying a stun gun in your area. Keep out of reach of children.

- Do not use on individuals with heart conditions, pacemakers, or pregnant women.
- Avoid contact with water or extreme temperatures.
- Do not attempt to open or modify the device. This will void the warranty and could be dangerous.
- Ensure the safety switch is in the "OFF" position when not in use.
- Do not discharge the stun gun for more than 1 second continuously when not in contact with a target, as this may damage the device.
- Use only the provided charging cable.

## PRODUCT OVERVIEW

---

The VIPERTEK VTS-880 is a compact and powerful self-defense tool. Familiarize yourself with its components:

- **Stun Prongs:** Two metal electrodes at the top for delivering the electrical discharge.
- **LED Flashlight:** Integrated light source for illumination.
- **Safety Switch:** A sliding switch to arm/disarm the stun function.
- **Activation Button:** Button to activate the stun function when armed.
- **Flashlight Button:** Button to turn the LED flashlight on/off.
- **Charging Port:** Located at the bottom for recharging the internal battery.

- **Non-Slip Rubber Coating:** Provides a secure grip.



Figure 1: Front view of the VIPERTEK VTS-880 Mini Stun Gun, showing the stun prongs, LED flashlight, and VIPERTEK logo.



Figure 2: Side view illustrating the safety switch, flashlight button, and charging port.



*Figure 3: The compact size of the VIPERTEK VTS-880, shown held comfortably in a hand.*

## **SETUP: INITIAL CHARGING**

---

Before first use, fully charge your VIPERTEK VTS-880. The device features an internal rechargeable battery, eliminating the need for disposable batteries.

1. Ensure the safety switch is in the "OFF" position.

2. Locate the charging port at the bottom of the device.
3. Connect the provided charging cable to the device's charging port.
4. Plug the other end of the charging cable into a standard wall outlet or a compatible USB power adapter.
5. Allow the device to charge for approximately 8 hours for the initial charge. Subsequent charges may take less time.
6. Unplug the device once charging is complete. Do not overcharge.



*Figure 4: The VIPERTEK VTS-880 connected to a wall outlet for charging.*

## OPERATING INSTRUCTIONS

---

### Using the LED Flashlight

1. To turn on the LED flashlight, press the dedicated flashlight button located on the side of the device.
2. Press the button again to turn off the flashlight.

### Using the Stun Function

**CAUTION:** Use the stun function only in self-defense situations and in accordance with all applicable laws.

1. Ensure the device is fully charged.
2. Slide the safety switch from "OFF" to "ON" to arm the stun gun. A red indicator light may illuminate, signifying the device is armed.
3. To activate the stun function, press and hold the activation button. You will hear a loud crackling sound and see an electrical arc between the stun prongs.
4. In a self-defense situation, make direct contact with the assailant's body using the stun prongs. Aim for large muscle

groups.

5. Release the activation button to stop the discharge.
6. After use, immediately slide the safety switch back to the "OFF" position to disarm the device.

## MAINTENANCE

---

- Keep the device clean and dry. Wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the stun gun in a cool, dry place, away from direct sunlight and extreme temperatures.
- Periodically check the charge level and recharge as needed to maintain battery health.
- Do not store the device in a fully discharged state for extended periods.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Stun gun does not activate.	Battery is low or depleted. Safety switch is in "OFF" position.	Recharge the device fully. Slide the safety switch to "ON".
Flashlight does not turn on.	Battery is low or depleted.	Recharge the device fully.
Device not charging.	Charging cable or adapter faulty. Charging port obstructed.	Try a different charging cable or adapter. Ensure charging port is clear of debris.

## SPECIFICATIONS

---

Feature	Detail
Model	VTS-880
Dimensions (L x W x H)	4" x 2" x 0.1" (Device) / 5.12" x 2.64" x 1.85" (Package)
Weight	0.14 Kilograms (Package)
Power Source	Internal Rechargeable Battery
Features	Stun Function, LED Flashlight, Non-Slip Rubber Coating
Included Components	Charging Cable
Material	Rubber



Figure 5: Dimensions of the VIPERTEK VTS-880 Mini Stun Gun.

## WARRANTY AND SUPPORT

---

Your VIPERTEK VTS-880 Mini Stun Gun comes with a **Limited Lifetime Warranty**. For warranty claims, technical support, or any inquiries, please contact VIPERTEK customer service.

You can find more information and contact details on the official VIPERTEK store page:[Visit the VIPERTEK Store on Amazon](#).



© 2024 VIPERTEK. All rights reserved.

*Disclaimer: This manual is for informational purposes only. Always exercise caution and adhere to local laws.*