

[Manuals.plus](#) /

› [Infinix](#) /

› Infinix Note 40 X6853 Smartphone User Manual

Infinix Note 40

Infinix Note 40 X6853 Smartphone User Manual

Model: Note 40 (X6853 / X6837)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Infinix Note 40 X6853 smartphone. Please read this guide thoroughly before operating your device to ensure optimal performance and longevity. Keep this manual for future reference.

2. PACKAGE CONTENTS

Upon unboxing your Infinix Note 40, verify that all items are present:

- Infinix Note 40 Smartphone
- Power Adapter (45W FastCharge2.0 compatible)
- USB Type-C Cable
- SIM Ejector Tool
- Protective Case
- Quick Start Guide
- Warranty Card

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your Infinix Note 40 smartphone.



Image: Front and rear view of the Infinix Note 40 X6853 smartphone, showcasing its display and camera module.



Image: Diagram illustrating the dimensions of the Infinix Note 40 X6853, showing its length (164.1mm), width (74.5mm), and thickness (7.8mm).

3.1. Physical Components

- **Front:** 6.78-inch AMOLED Display, Front Camera, Earpiece.
- **Rear:** 108MP Super-Zoom Camera System, LED Flash, Infinix Branding.
- **Right Side:** Power Button, Volume Up/Down Buttons.
- **Left Side:** SIM Card Tray.
- **Bottom:** USB Type-C Port, Speaker, Microphone.

4. SETUP

4.1. SIM Card Installation

1. Locate the SIM card tray on the left side of the device.
2. Insert the SIM ejector tool into the small hole on the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card (if applicable) into the tray with the gold contacts facing down,

ensuring they are correctly aligned.

4. Carefully reinsert the tray into the phone until it clicks into place.

4.2. Initial Power On and Configuration

1. Press and hold the Power button on the right side of the phone until the Infinix logo appears.
2. Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one to access Google services and the Play Store.
4. Complete the setup process, including setting up a screen lock and fingerprint recognition.

5. OPERATING INSTRUCTIONS

5.1. Display and Navigation

The Infinix Note 40 features a 6.78-inch AMOLED display with a 120Hz refresh rate, providing smooth visuals and responsive touch interaction. Navigate the interface using gestures or the traditional navigation bar.

5.2. Camera System

Your device is equipped with a 108MP Super-Zoom Camera system for high-resolution photography.

108MP

108MP Camera System

Unleash the reconstructive prowess of 108 million pixels, where the lossless 3X Super-Zoom emerges as the perfect focal length. Capture stories uniquely tailored to you, weaving a narrative like never before.



Image: Close-up of the Infinix Note 40's rear camera module, highlighting the 108MP Super-Zoom Camera System and its ability to capture detailed images.

- **Launching the Camera:** Tap the Camera icon on your home screen or lock screen.
- **Taking Photos:** Tap the shutter button to capture an image.
- **Zoom:** Pinch in or out on the screen, or use the zoom slider to adjust the zoom level, including the 3X lossless Super-Zoom.
- **Modes:** Swipe left or right to switch between various camera modes such as Photo, Video, Portrait, Super Night, and Pro mode.

5.3. Performance and Multitasking

The Infinix Note 40 is powered by the Helio G99 Ultimate processor and comes with 8GB of RAM, expandable up to 16GB with extended RAM technology, ensuring efficient multitasking and smooth application performance.



Effortless Multitasking Up to 16GB Extended RAM

Enjoy lightning-fast startups and improved multitasking, even when running numerous apps in the background. Experience seamless performance at its best.

+10%

Apps Launch Speed:
Instant App Launch

Up to
18 Apps Alive

**Reduce Forced
App closes**

Image: A user holding the Infinix Note 40, illustrating the phone's capability for effortless multitasking with up to 16GB extended RAM, leading to faster app launches and more apps staying active in memory.

Unleash the Power of AI

Helio G99 Ultimate

Unleash the power of the top-tier flagship chip, crafted on a cutting-edge 6nm process. Experience a profound boost in system speed and energy efficiency, while broadening support for a range of AI scenarios at the core.



Image: A visual representation of the Helio G99 Ultimate chip, emphasizing its 6nm process and its role in enhancing system speed and energy efficiency for AI scenarios.

- **Switching Apps:** Swipe up from the bottom of the screen and hold (for gesture navigation) or tap the recent apps button to view and switch between open applications.
- **Closing Apps:** Swipe an app card up to close it from the recent apps view.

5.4. Charging

The device supports 45W FastCharge2.0 for rapid wired charging. Use the provided power adapter and USB Type-C cable for optimal charging speeds.

- Connect the USB Type-C cable to the phone's charging port and the power adapter.
- Plug the power adapter into a wall outlet.
- The charging indicator will appear on the screen.

5.5. Security

The Infinix Note 40 includes an in-display fingerprint sensor for secure and convenient unlocking.

- **Setting up Fingerprint:** Go to Settings > Security > Fingerprint and follow the on-screen instructions to register your fingerprints.
- **Unlocking:** Place your registered finger on the designated area of the screen to unlock the device.

5.6. Connectivity

The device supports Dual SIM functionality, 4G cellular networks, Bluetooth, and NFC.

- **Wi-Fi:** Connect to wireless networks via Settings > Wi-Fi.
- **Bluetooth:** Pair with Bluetooth devices via Settings > Connected devices > Bluetooth.
- **NFC:** Enable NFC for contactless payments and data transfer via Settings > Connected devices > Connection preferences > NFC.

6. MAINTENANCE

6.1. Cleaning Your Device

- Use a soft, lint-free cloth to gently wipe the screen and body of the phone.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.
- Keep ports free of dust and debris.

6.2. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > System > System update to check for available updates.

7. TROUBLESHOOTING

If you encounter issues with your Infinix Note 40, refer to the following common solutions:

- **Device Not Turning On:** Ensure the battery is charged. Connect the phone to the charger for at least 15 minutes, then try powering it on again.
- **Apps Crashing/Freezing:** Close and reopen the app. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the issue persists, restart the phone.
- **Poor Network Signal:** Check if your SIM card is properly inserted. Try restarting the phone. If the problem continues, contact your network provider.
- **Battery Draining Quickly:** Reduce screen brightness, disable unused features like Bluetooth or GPS, and close background apps. Check battery usage in Settings > Battery to identify power-hungry apps.
- **Fingerprint Sensor Not Working:** Ensure your finger is clean and dry. Re-register your fingerprint if necessary.

For more complex issues, consider performing a factory reset (backup your data first) or contacting customer support.

8. SPECIFICATIONS

Detailed technical specifications for the Infinix Note 40 X6853.



Image: A summary of key features of the Infinix Note 40, including 108MP Super-Zoom Cam, 45W All-Round FastCharge2.0, 20W Wireless MagCharge, 120Hz AMOLED Display, Helio G99 Ultimate, IP54 Splash Proof, and NFC.

Feature	Specification
Model Name	Note 40 (X6837 / X6853)
Display	6.78-inch AMOLED, 120Hz Refresh Rate, 1080 x 2436 Resolution
Processor	Helio G99 Ultimate
RAM	8 GB (Up to 16 GB Extended RAM)
Internal Storage	256 GB
Rear Camera	108 MP Super-Zoom Camera
Operating System	Android 13.0

Battery Capacity	5000 mAh
Charging	45W FastCharge2.0 (Wired), 20W Wireless MagCharge
Connectivity	Dual SIM, 4G, Bluetooth, NFC
Dimensions	16.41 x 7.45 x 0.78 cm
Weight	190 g
Special Features	In-display Fingerprint, Expandable Memory, IP54 Splash Proof

9. WARRANTY AND SUPPORT

Your Infinix Note 40 smartphone comes with a limited manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage duration and service procedures. For technical support, service, or further inquiries, please visit the official Infinix website or contact their customer service channels as provided in your warranty documentation or on the Infinix support page.

© 2024 Infinix. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

