

KYSONA EM9 (6976499130297)

KYSONA 57° Ergonomic Wireless Tower Mouse User Manual

Model: EM9 (6976499130297)



INTRODUCTION

Thank you for choosing the KYSONA 57° Ergonomic Wireless Tower Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. Designed for comfort and efficiency, this vertical mouse helps reduce wrist strain during extended use. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

- 1 x KYSONA 57° Ergonomic Wireless Tower Mouse
- 1 x 2.4G USB Receiver
- 1 x User Manual

Note: 2 AAA batteries are required and not included in the package.

KEY FEATURES

- **Ergonomic 57° Vertical Design:** Promotes a natural hand and wrist posture to minimize strain.
- **Dual Mode Connectivity:** Seamlessly switch between Bluetooth (BT5.0/BT3.0) and 2.4G wireless connections.
- **Adjustable DPI:** Five sensitivity settings (800/1200/1600/2400/4000 DPI) for precise control.
- **Silent Click Switches:** Reduces clicking noise for a quiet working environment.
- **Smart Auto-Sleep Mode:** Conserves battery life by entering sleep mode during inactivity.
- **Multi-Device Compatibility:** Works with Windows, macOS, iPadOS, laptops, and PCs.

SETUP GUIDE

1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery cover.
3. Insert two (2) AAA batteries, ensuring correct polarity (+/-).
4. Close the battery cover securely.

Hassle-free Design

Wireless mouse has a smart auto-sleep mode to save power and up to 12 months (battery life may vary based on user and computing conditions).



Figure 1: Battery installation in the KYSONA ergonomic mouse.

2. Connecting Your Mouse

The KYSONA mouse supports two connection modes: 2.4G Wireless and Bluetooth. You can connect to up to three devices simultaneously.

2.1. 2.4G Wireless Connection

1. Turn on the mouse using the ON/OFF switch on the bottom.
2. Locate the 2.4G USB receiver stored in the battery compartment.

3. Plug the 2.4G USB receiver into an available USB port on your computer.
4. The mouse should automatically connect. If not, press the "Mode Switch" button on the bottom of the mouse until the indicator light shows 2.4G mode (usually green or blue).



Figure 2: Connecting the mouse via 2.4G wireless and Bluetooth.

2.2. Bluetooth Connection (BT3.0/BT5.0)

1. Turn on the mouse using the ON/OFF switch on the bottom.
2. Press the "Mode Switch" button on the bottom of the mouse to cycle through Bluetooth channels (BT1, BT2). The indicator light will flash blue for Bluetooth pairing mode.
3. On your device (Windows, macOS, iPadOS), go to Bluetooth settings.
4. Search for "KYSONA EM9" or similar and select it to pair.
5. Once paired, the indicator light will stop flashing and remain solid.
6. Repeat for additional Bluetooth devices using BT2.

OPERATING INSTRUCTIONS

1. Ergonomic Grip

Hold the mouse with your hand in a natural handshake position. The 57° vertical tilt is designed to align your wrist and forearm, reducing pronation and muscle strain. Your thumb should rest comfortably on the left side, and your fingers should naturally fall onto the buttons.

Ergonomic Vertical Design

The mouse is designed with a 57° tilt, allowing the wrist and forearm to naturally relax and reducing twisting and tension



Figure 3: Proper ergonomic grip for the KYSONA mouse.




Figure 4: Hand size guide for optimal comfort. This mouse is recommended for small to medium hands.

2. Button Functions

- **Left Click:** Standard selection.
- **Right Click:** Context menu.
- **Scroll Wheel:** Scroll up/down, middle click.
- **Forward/Backward Buttons:** Located near the thumb rest for easy navigation in web browsers or file explorers.
- **DPI Button:** Located behind the scroll wheel, used to adjust mouse sensitivity.

3. DPI Adjustment

Press the DPI button (located behind the scroll wheel) to cycle through the 5 available DPI settings: 800, 1200, 1600, 2400, and 4000. The current DPI setting may be indicated by a light or on an LED screen if available on your model.

5 Adjustable DPI

The mouse offers 4 adjustable DPI settings: 800, 1200, 1600, 2400 and 4000



Figure 5: DPI adjustment settings.

4. Silent Click Feature

The mouse is equipped with silent click switches, significantly reducing the noise produced by clicks. This feature is ideal for quiet environments, ensuring minimal disturbance.

Silent Click

Makes It 95% Quieter Than A Regular Mouse



Figure 6: The silent click feature of the mouse.

5. Smart Auto-Sleep Mode

To conserve battery life, the mouse will automatically enter a sleep mode after a period of inactivity. To wake the mouse, simply move it or click any button.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the mouse performance degrades or the low battery indicator appears. Always use new AAA batteries.
- **Storage:** When not in use for extended periods, turn off the mouse to further conserve battery life. Store in a cool, dry place.

TROUBLESHOOTING

Mouse Not Responding:

- Ensure the mouse is turned ON.
- Check battery levels and replace if necessary.
- For 2.4G connection, ensure the USB receiver is securely plugged into a working USB port.
- For Bluetooth connection, verify that Bluetooth is enabled on your device and the mouse is paired. Try re-pairing if issues persist.
- Ensure the mouse is within the effective operating range (typically 10 meters).

Cursor Movement is Erratic or Slow:

- Adjust the DPI setting using the DPI button to a higher or lower sensitivity.
- Clean the optical sensor on the bottom of the mouse.
- Ensure you are using the mouse on a suitable surface (non-reflective, opaque).

Cannot Connect via Bluetooth:

- Make sure the mouse is in Bluetooth pairing mode (indicator light flashing).
- Forget the device from your computer's Bluetooth settings and try pairing again.
- Ensure your device's Bluetooth version is compatible (BT3.0 or BT5.0).

SPECIFICATIONS

Model Number	EM9 (6976499130297)
Connectivity	2.4G Wireless, Bluetooth (BT3.0, BT5.0)
DPI Settings	800 / 1200 / 1600 / 2400 / 4000
Buttons	5 (Left, Right, Scroll Wheel, Forward, Backward, DPI)
Power Source	2 x AAA Batteries (not included)
Dimensions	4.25 x 2.91 x 0.04 inches (10.7 x 7.4 x 7.1 cm)
Weight	3.52 ounces (100g)
Compatibility	Windows, macOS, iPadOS, Laptops, PCs
Special Features	Ergonomic Design, Silent Switch, Smart Auto-Sleep

PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: A brief overview of the KYSONA ergonomic vertical mouse, showcasing its design and features.

WARRANTY AND SUPPORT

KYSONA products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or visit the official KYSONA website. Keep your purchase receipt for warranty claims.

For additional information and products, visit the [KYSONA Store on Amazon](#).

