

enya NEXG 2N RD

Enya NEXG 2N Acoustic-Electric Carbon Fiber Classical Nylon String Travel Guitar User Manual

Model: NEXG 2N RD

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Enya NEXG 2N Acoustic-Electric Carbon Fiber Classical Nylon String Travel Guitar. Please read this manual thoroughly before using your instrument to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Enya NEXG 2N is an innovative acoustic-electric guitar featuring a durable carbon fiber body, an integrated 50W wireless speaker, and advanced digital signal processing (DSP) for various effects. Its design prioritizes portability and versatility, making it suitable for travel and diverse musical applications.



Figure 1: The Enya NEXG 2N guitar, presented with its included gig bag, charging cable, adjusting wrench, and footswitch pedal. This image provides a complete view of the product and its essential accessories, highlighting its compact and portable nature.

Key Components:

- **Carbon Fiber Body:** Offers exceptional durability, resistance to temperature and humidity changes, and a lightweight design.
- **Integrated 50W Wireless Speaker:** Provides amplified sound for performance and can function as a standalone Bluetooth speaker for audio playback.
- **Color Touch Screen:** An intuitive interface for navigating through effects, looper functions, and the drum machine.

- **Nylon Strings:** Delivers the characteristic smooth midrange, balanced sound, and responsive touch of classical guitars.
- **Footswitch Pedal:** Enables hands-free control over various guitar functions, enhancing live performance and practice.



The Onboard Speaker

The speaker is thoroughly developed to deliver better sonic performance: louder volume, wider dynamic range, and prominent frequency response.



Figure 2: A detailed view of the Enya NEXG 2N's internal speaker system, showcasing the components engineered to deliver its powerful

amplified sound, wider dynamic range, and prominent frequency response.

SETUP AND FIRST USE

Charging the Guitar:

Before initial use, ensure the guitar's internal battery is fully charged. Connect the provided charging cable to the guitar's charging port and a compatible USB power adapter (not included). The color touch screen will display the charging status.

Initial Power On:

Locate the power button on the guitar (refer to the product diagram for exact placement). Press and hold this button until the color touch screen illuminates. The guitar will then initiate its startup sequence and display the main operating interface.

Connecting the Footswitch Pedal:

The footswitch pedal connects wirelessly to the NEXG 2N. Power on the pedal and follow the pairing instructions displayed on the guitar's touch screen. Successful pairing enables hands-free control of various effects and looper functions.

OPERATING THE NEXG 2N

Using the Touch Screen Interface:

The NEXG 2N features a responsive color touch screen designed for intuitive control. Tap on icons to select different modes such as Looper, Drum Machine, and Settings. The main rotary dial can be used for precise adjustments of volume and for navigating through menus.



Color Touch Screen

A color touch screen makes navigating through the presets and functionalities intuitive. All the presets are expandable through ENYA MUSIC App.



Figure 3: The Enya NEXG 2N's color touch screen, clearly displaying options for Looper, Drum Machine, and Settings, along with various effect presets and controls for easy access and customization.

Applying Effects:

The guitar includes 20 onboard presets, offering a range of effects such as compression, chorus, vibrato, octave, delay,

and reverb. Access the effects section on the touch screen to select and modify these effects. Further customization of presets is available through the dedicated ENYA MUSIC App.

Looper and Drum Machine:

Activate the Looper and Drum Machine functions directly from the main screen. The looper allows for recording and layering guitar parts, while the drum machine provides diverse rhythmic patterns for practice or creative composition. Both features can be controlled via the touch screen or the connected footswitch pedal.



**Go
Start
Create**

NEXG 2N features a built-in Looper and a Drum Machine, which allow you to document your musical ideas effortlessly, being able to create and perform all by yourself. We get you the tool, and sky is your limit.



Figure 4: The Enya NEXG 2N's touch screen interface specifically highlighting the Looper and Drum Machine controls, demonstrating the ease with which users can experiment with and document musical ideas.

ENYA MUSIC App Connectivity:

Enhance your experience by downloading the ENYA MUSIC App on your smartphone or tablet. The app provides

advanced functionalities, including in-depth customization of presets and the unique Acoustic Profiling feature. This feature allows you to replicate the tonal characteristics of other acoustic guitars on your NEXG 2N.

Effects

EQ

Compressor

Distortion

Overdrive

Amplifier

Direct

Delay

Reverb

Profile Again

Get any acoustic guitar profile onto NEXG

Effects

Acoustic Vol

75

Acoustic Profiling

Save

NEXG 2N

Your Own Sound

We've developed an App for you to further customize your own sound. The Profiling feature allows you to copy the tone from any other acoustic guitar onto NEXG 2N. The versatility is incredible.

Figure 5: Screenshots of the ENYA MUSIC App interface on a smartphone, illustrating its capabilities for customizing guitar effects and utilizing the Acoustic Profiling feature to achieve diverse tonal qualities.

Voice Assistant for Tuning:

The guitar incorporates a voice assistant feature within its tuning section, providing audible guidance to assist with accurate string tuning.

MAINTENANCE AND CARE

- **Cleaning:** Regularly wipe the carbon fiber body with a soft, dry cloth to remove dust and fingerprints. For more persistent marks, a slightly damp cloth can be used, followed immediately by drying. Avoid using abrasive cleaners or solvents.
- **String Care:** Nylon strings are durable but will eventually wear out and lose their tonal quality. Replace strings as needed, following standard nylon string replacement procedures.
- **Storage:** Always store the guitar in its provided gig bag when not in use to protect it from dust, minor impacts, and environmental fluctuations. While carbon fiber is stable, prolonged exposure to extreme temperatures should still be avoided.
- **Battery Life:** To maintain optimal battery health and longevity, avoid frequently allowing the battery to completely drain. Charge the guitar regularly, especially if it will be stored for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Guitar does not power on.	Low or depleted battery.	Connect the charging cable and allow the guitar to charge for at least 30 minutes before attempting to power on again.
No sound from speaker.	Volume too low; speaker muted; internal issue.	Increase volume using the main dial. Check if the speaker is muted via the touch screen settings. If the problem persists, contact customer support.
Footswitch pedal not connecting.	Pedal not powered on; pairing issue; out of range.	Ensure the pedal is charged and powered on. Re-attempt pairing through the guitar's settings menu. Ensure the pedal is within close proximity to the guitar.
Touch screen unresponsive.	Temporary software glitch.	Perform a soft reset by holding the power button until the guitar powers off completely, then power it back on.
Distorted sound.	Volume too high; effect settings incorrect; input signal too strong.	Reduce the guitar's overall volume. Review and adjust effect parameters on the touch screen or via the ENYA MUSIC App. Ensure any external input signals are not overdriving the system.

SPECIFICATIONS

Feature	Detail
Brand	Enya
Model Number	NEXG 2N RD
Item Weight	6.6 pounds

Feature	Detail
Package Dimensions	43.25 x 13.38 x 6.38 inches
Body Material	Carbon Fiber
Back Material	Carbon Fiber
Top Material	Carbon Fiber
Neck Material Type	Carbon Fiber
Fretboard Material	carbon fiber
String Material	Nylon
Number of Strings	6
Color	Red
Speaker Output	50W (Integrated)
Connectivity	Wireless (for footswitch), Bluetooth (for speaker)
Onboard Effects	Comp, Chorus, Vibrato, Octave, Delay, Reverb (20 presets)
Additional Features	Looper, Drum Machine, Acoustic Profiling, Voice Assistant, OTG Recording

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Enya website or contact your authorized point of purchase. Additional resources and contact details can also be found by visiting the [Enya Store on Amazon](#).
A digital version of this user manual is available for download:[User Manual \(PDF\)](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question