

enya NEXG 2N

Enya NEXG 2N Acoustic-Electric Carbon Fiber Classical Nylon String Travel Guitar User Manual

Model: NEXG 2N

INTRODUCTION

Welcome to the Enya NEXG 2N Acoustic-Electric Carbon Fiber Classical Nylon String Travel Guitar. This instrument integrates advanced technology with traditional craftsmanship, offering a versatile playing experience. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your guitar.



Figure 1: Enya NEXG 2N Acoustic-Electric Guitar in a contemporary environment.

PRODUCT OVERVIEW

The NEXG 2N is designed with a carbon fiber body for durability and stable performance across various conditions. It features an integrated 50W wireless speaker, a color touch screen for navigation, and advanced digital signal processing (DSP) for effects.

Key components include:

- **Carbon Fiber Construction:** Ensures durability and stability.
- **50W Wireless Speaker:** Provides amplified sound and can function as a home stereo.

- **Color Touch Screen:** For intuitive control of settings and effects.
- **DSP Effects:** Built-in compression, chorus, vibrato, octave, delay, and reverb.
- **Onboard Looper and Drum Machine:** Tools for creative composition and practice.
- **Acoustic Profiling:** Replicate tonal characteristics of other guitars.
- **Voice Assistant:** Integrated into the tuning section for convenience.
- **Thinner Neck Profile and Wider Fretboard:** Designed for comfortable playability.



Figure 2: Overview of the Enya NEXG 2N's integrated features, including the speaker and control panel.

SETUP

1. **Unboxing:** Carefully remove the guitar and accessories from the thickened gig bag. Inspect for any visible damage.
2. **Initial Charge:** Before first use, fully charge the guitar using the provided charging cable. The charging port is located on the bottom of the guitar. A full charge ensures optimal performance of the internal electronics and speaker.
3. **Neck Adjustment:** The guitar features an adjustable neck. If the string action feels too high or too low, use the adjusting wrench to fine-tune the truss rod. Refer to standard guitar setup guides for proper truss rod adjustment techniques if unfamiliar.
4. **Strap Attachment:** Attach a guitar strap to the strap buttons for comfortable playing while standing.
5. **Footswitch Pedal:** Connect the footswitch pedal if desired. This accessory allows for hands-free control of certain functions like effects or looper.

Your browser does not support the video tag.

Video 1: A demonstration of the Enya NEXG 2N's sound capabilities and effects with a classical guitar cover, which includes a brief overview of the guitar.

OPERATING INSTRUCTIONS

Power On/Off

To power on the guitar, press and hold the power button located on the control panel. The color touch screen will illuminate. To power off, press and hold the power button again.

Using the Onboard Speaker and Effects

The NEXG 2N features a powerful 50W wireless speaker. Adjust the volume using the dedicated knob on the control panel. The color touch screen allows you to navigate through 20 onboard presets and various effects such as compression, chorus, vibrato, octave, delay, and reverb. These effects can be applied directly to the nylon string sound.



Figure 3: The color touch screen interface for managing presets and effects.

Your browser does not support the video tag.

Video 2: A demonstration showcasing the sound of the Enya NEXG 2N nylon string smart guitar.

Looper and Drum Machine

The NEXG 2N includes an onboard looper and drum machine. Access these features via the touch screen. The looper allows you to record and layer guitar parts, while the drum machine provides various rhythmic patterns for practice or composition. These tools can be used together to create full musical ideas.

Your browser does not support the video tag.

Video 3: A demonstration of the Enya NEXG 2N's looper function for creating layered guitar tracks.

ENYA MUSIC App Integration

Customize and expand the 20 onboard presets using the ENYA MUSIC App. The app also features an Acoustic Profiling function, allowing you to replicate the tonal characteristics of other guitars on your NEXG 2N. Connect your device via Bluetooth for seamless control and expanded capabilities.



Figure 4: The Enya NEXG 2N connected to the ENYA MUSIC App, showcasing customization options.

Tuning and Voice Assistant

The guitar includes a built-in tuner with a voice assistant feature to assist with accurate tuning. Access the tuning section through the color touch screen.

MAINTENANCE

- **Cleaning:** Wipe the carbon fiber body and fretboard with a soft, dry cloth after each use. For deeper cleaning, a slightly damp cloth can be used, followed by a dry one. Avoid harsh chemicals.
- **String Care:** Nylon strings should be replaced periodically to maintain optimal tone and playability. Refer to standard classical guitar string replacement procedures.
- **Storage:** Store the guitar in its thickened gig bag when not in use to protect it from dust and physical damage. While carbon fiber is stable, extreme temperature fluctuations should still be avoided.
- **Battery Care:** To prolong battery life, avoid fully discharging the guitar frequently. Charge it regularly, especially if storing for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speaker	Low battery; Volume too low; Speaker muted.	Charge the guitar; Increase volume; Check mute settings on touch screen.
Guitar not charging	Faulty cable/charger; Loose connection.	Ensure cable is securely connected; Try a different compatible USB-C cable and charger.
Bluetooth connectivity issues	Bluetooth off on device/guitar; Interference.	Ensure Bluetooth is enabled on both devices; Move closer to the guitar; Restart both devices.
Strings buzzing	Incorrect neck relief; High action.	Adjust the truss rod using the provided wrench; Consult a guitar technician if unsure.

SPECIFICATIONS

	• Item Weight: 12.17 pounds • Product Dimensions: 39.09 x 11.92 x 3.46 inches • Item Model Number: NEXG 2N BK • Back Material: Carbon Fiber • Body Material: Carbon Fiber • Color Name: Black • Connector Type: Wireless (Bluetooth) • Fretboard Material: Carbon Fiber • Guitar Pickup Configuration: Combination (Piezo and Microphone) • String Material: Nylon • Top Material: Carbon Fiber • Neck Material Type: Carbon Fiber • Number of Strings: 6 • Guitar Bridge System: Fixed • Musical Style: World-Music • Size: 2N • Hand Orientation: Right
--	--

WHAT'S IN THE BOX

The Enya NEXG 2N package includes the following items:

	• Thickened Gig Bag • Charging Cable • Adjusting Wrench • Footswitch Pedal • Charging Stand (Optional, purchased separately) • Wireless Microphone (Optional, purchased separately) • Monitor Earphone (Optional, purchased separately)
--	---

Effects

Acoustic Vol

Dist

Octa

Modifit

Direct

Delay

Reverb

Profile Again

Get any acoustic guitar profile onto NEXG 2N

Effects

Acoustic Vol

75

Save

NEXG 2N

Your Own Sound

We've developed an App for you to further customize your own sound. The Profiling feature allows you to copy the tone from any other acoustic guitar onto NEXG 2N. The versatility is incredible.

Figure 5: The Enya NEXG 2N guitar shown with its standard accessories.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Enya Musical website or contact your retailer. Keep

your purchase receipt as proof of purchase for any warranty claims.

The product is sold by "Enya Musical" and fulfilled by Amazon. For additional support, visit the [Enya Store on Amazon](#).

© 2024 Enya Musical. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question