

Glitzhome B0CQY4FVPM

Glitzhome Outdoor Water Fountain with LED Light

Model: B0CQY4FVPM

INTRODUCTION

Thank you for choosing the Glitzhome Outdoor Water Fountain. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your new fountain. Please read these instructions thoroughly before assembly and use, and retain them for future reference.

SAFETY INFORMATION

- **Electrical Safety:** Ensure the power outlet is properly grounded and protected by a Ground Fault Circuit Interrupter (GFCI). Do not operate the pump if the power cord is damaged. Always disconnect power before performing any maintenance or cleaning.
- **Water Safety:** Use clean water only. Do not allow children or pets to drink from the fountain. Regularly check water levels to ensure the pump remains fully submerged.
- **Placement:** Place the fountain on a stable, level surface to prevent tipping. Ensure it is away from electrical outlets and other sensitive equipment.
- **Weather Conditions:** During freezing temperatures, drain the fountain, disconnect the pump, and store it indoors to prevent damage.

PACKAGE CONTENTS

Please check to ensure all components are present and undamaged:

- Fountain Body (Spiral Shaped)
- Submersible Pump (UL or ETL Listed)
- Power Adapter (110V~120V 60HZ, US plugs, 6ft power cord)
- LED Light (integrated)
- Instruction Manual

SETUP

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to avoid scratches.
2. **Position the Fountain:** Choose a suitable, level location for your fountain. Ensure it is near a grounded electrical outlet and protected from strong winds.
3. **Connect the Pump:** Connect the pump to the tubing located inside the fountain. Ensure a secure fit.
4. **Fill with Water:** Fill the fountain basin with distilled water until the pump is completely submerged. Do not overfill. The water capacity is approximately 8.5 Liters (2.25 Gallons).
5. **Connect Power:** Plug the power adapter into the electrical outlet. The pump and LED light will activate.



Image: The Glitzhome Outdoor Water Fountain set up in a lush garden environment, showcasing its spiral design and integrated planter.



Image: A visual breakdown of the fountain's features, including the plant platform, splash guard, S-curve spiral design, and LED light.

Video: An official Glitzhome video demonstrating the decorative tiered outdoor water fountain in operation, highlighting its design and water flow.

OPERATING INSTRUCTIONS

- Power On/Off:** The fountain operates by plugging it into a standard electrical outlet. To turn it off, simply unplug the power cord.
- Water Flow Adjustment:** The built-in pump may have an adjustable flow rate. Refer to the pump's specific instructions for details on how to adjust the water flow to your preference and to prevent excessive splashing.
- Water Level:** Regularly check the water level. Due to evaporation, water levels will decrease over time. Refill as needed to ensure the pump remains fully submerged, which is crucial for its longevity and proper operation.
- LED Light:** The integrated LED light automatically illuminates when the fountain is powered on, creating a warm glow for evening ambiance.



Image: A close-up view of the fountain's lower basin, showing the warm LED light illuminating the cascading water, creating a tranquil effect.

MAINTENANCE

- **Regular Cleaning:** To prevent mineral buildup and algae growth, clean the fountain regularly. Drain the water, wipe down surfaces with a soft cloth and mild soap, and rinse thoroughly. A small amount of bleach can be added to the water to inhibit mold and bacterial growth.
- **Pump Care:** Periodically clean the pump to remove any debris that may obstruct water flow. Disconnect the pump, disassemble it according to its instructions, and clean all parts with a brush.
- **Water Changes:** Change the water every few weeks, or more frequently if the water appears cloudy or dirty.

- **Winterization:** Before the first freeze, completely drain all water from the fountain and pump. Disconnect the pump and store it indoors in a dry, frost-free location. Cover the fountain or store it indoors if possible to protect it from harsh winter conditions.



Image: A detailed view of the water gracefully flowing down the spiral structure of the fountain, highlighting the texture of the faux terrazzo finish.


TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not operating	No power; Pump clogged; Low water level	Check power connection and GFCI; Clean pump; Add water to cover pump
Water flow is weak	Pump clogged; Kinked tubing; Low water level	Clean pump; Straighten tubing; Add water
Excessive splashing	Water flow too high; Uneven surface	Adjust pump flow rate; Ensure fountain is on a level surface

Problem	Possible Cause	Solution
LED light not working	Loose connection; Damaged LED	Check connections; Contact customer support for replacement

SPECIFICATIONS

- **Dimensions (L x W x H):** 12.5"L x 12.5"W x 31.25"H
- **Item Weight:** 23.1 Pounds
- **Material:** Polyresin and Stone Powder (Faux Terrazzo Finish)
- **Power Source:** Corded Electric (110V~120V 60HZ, US plugs, 6ft power cord)
- **Water Capacity:** 8.5 Liter (2.25 Gallon)
- **Max. Flow Rate:** 650 Liter/Hour (171.5 GPH)
- **LED:** 0.5~0.8W Warm White
- **Weight Capacity for Top Planter:** 1.5 kgs (3.3 LBS)



31.25"

12.50"

12.50"

Manual Measurement, Allowable Error

Image: A diagram illustrating the precise dimensions of the fountain, measuring 31.25 inches in height and 12.50 inches in width.

WARRANTY

This Glitzhome Outdoor Water Fountain comes with a **one-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims.

SUPPORT

For further assistance, troubleshooting, or warranty inquiries, please contact Glitzhome customer service. Refer to the contact information provided on the product packaging or the official Glitzhome website.

Video: An official Glitzhome video showcasing the modern faux terrazzo spiral polyresin outdoor fountain, highlighting its aesthetic appeal and functionality.