Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gizoon WR211

Gizoon WR211 Rocking Patio Bistro Set User Manual

Model: WR211

1. Introduction

This manual provides comprehensive instructions for the assembly, safe operation, and proper maintenance of your Gizoon 3-Piece Rocking Patio Bistro Set. Please read this manual thoroughly before assembly and use to ensure optimal performance and longevity of your product. Keep this manual for future reference.




Image 1.1: The Gizoon 3-Piece Rocking Patio Bistro Set, featuring two rocking chairs and a glass-top side table.

2. Safety Instructions

Adhere to the following safety guidelines to prevent injury and damage to the product:

- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the weight capacity of the chairs or table.

- Keep children away from the assembly area. Small parts can be a choking hazard.
- Use on a flat, stable surface to prevent tipping.
- Avoid placing hot items directly on the glass table surface without protection.
- Do not stand on the chairs or table.
- In adverse weather conditions (strong winds, heavy rain), store cushions indoors and consider securing or storing the furniture to prevent damage.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

Included Components:

- Rocking Chairs (2)
- Glass-Top Side Table (1)
- Seat Cushions (2)
- Assembly Hardware (screws, bolts, washers, Allen wrench)
- Instruction Manual (1)




Image 3.1: Dimensional diagram of the rocking chair and side table, illustrating their respective measurements.

4. Assembly Instructions

Assembly typically requires 1-2 people and takes approximately 1-2 hours. An adequate workspace is recommended. Wear gloves to prevent injury during assembly.

Tools Required:

- Screwdriver (included)
- Electric screwdriver (optional, not included)

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Verify all parts against the package contents list.
2. **Assemble Rocking Chairs:**
    - Attach the backrest to the seat frame using the provided bolts and Allen wrench. Do not fully tighten yet.
    - Connect the armrests to the backrest and seat frame. Ensure the wooden anti-scald strips are facing upwards. Secure with bolts, but do not fully tighten.
    - Attach the rocking base to the chair frame.
    - Once all parts are loosely assembled, place the chair on a flat surface and gently rock it to ensure alignment. Then, gradually tighten all bolts evenly until secure. Do not overtighten.
3. **Assemble Side Table:**
    - Attach the four legs to the table frame using the provided hardware.
    - Place the glass top onto the table frame. Ensure it sits securely within the frame.
    - Tighten all bolts evenly until secure.
4. **Place Cushions:** Position the high-elastic foam seat cushions onto the rocking chairs.



Image 4.1: Visual guide for assembly, highlighting the recommendation for adequate workspace and wearing gloves.

5. Operating Instructions

Your Gizoon Rocking Patio Bistro Set is designed for comfortable outdoor relaxation.

Using the Rocking Chairs:

- Sit gently into the chair, ensuring your weight is evenly distributed.
- The integrated rocking design allows for a slight, comfortable motion.
- The wooden strips on the armrests are designed to remain cool, providing an anti-scald feature during warm weather.
- The high-elastic foam cushions offer supportive comfort for extended periods.

Using the Side Table:

- The glass-top table provides a stable surface for beverages, books, or small decorative items.
- Avoid placing excessively heavy objects on the table.



Image 5.1: Illustration of the rocking design, demonstrating the gentle motion of the chair.



Image 5.2: Detailed view of chair features, including the anti-scald wooden armrest, waterproof hand-woven rattan, and the removable cushion cover.

6. Maintenance

Regular maintenance will help preserve the appearance and extend the lifespan of your patio set.

Cleaning:

- **Frame and Rattan:** Wipe with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Dry completely to prevent water spots.
- **Glass Tabletop:** Clean with a glass cleaner and a soft cloth.
- **Cushions:** The cushion covers are removable for cleaning. Follow the care instructions on the cushion label. Spot clean minor spills with a mild detergent and water. Allow to air dry completely.

General Care:

- Periodically inspect all bolts and connections and tighten as needed.
- Store cushions indoors during prolonged periods of non-use or inclement weather to protect them from fading and moisture.
- Consider using a furniture cover to protect the entire set when not in use, especially during off-season.



Image 6.1: Detailed view of table features, highlighting its easy-to-clean surface, arc corners for safety, and stable structure.

7. Troubleshooting

Refer to the following common issues and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chair feels wobbly	Loose bolts or uneven surface.	Check and tighten all assembly bolts. Ensure the chair is on a flat, level surface.
Tabletop is not stable	Loose leg connections or uneven surface.	Tighten all leg connection bolts. Place the table on a flat, level surface.
Cushions appear flattened	Prolonged use or storage.	Fluff cushions regularly. Store in a dry, well-ventilated area when not in use.

8. Specifications

Feature	Detail
Model Number	WR211
Material	Alloy Steel, Wicker, Glass
Color	Grey
Assembled Chair Dimensions (L x W x H)	23.2" x 28.7" x 36.1"
Assembled Table Dimensions (L x W x H)	17" x 17" x 19" (estimated from image)
Item Weight	19.4 pounds (per chair, total set weight will be higher)
Product Care Instructions	Wipe with Damp Cloth

9. Warranty and Support

Gizoon is committed to providing quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.
If you have any questions regarding assembly, missing parts, or product performance, please contact Gizoon customer support:

- **Customer Service:** Refer to the contact information provided at the point of purchase or on the official Gizoon website.
- **Response Time:** Gizoon aims for quick responses to inquiries.

© 2025 Gizoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQYBQFZ2

More documents and user manuals: **https://manuals.plus/**