Snailax SL-681-2

Snailax SL-681-2 Cordless Neck and Shoulder Massager Instruction Manual

Model: SL-681-2

Introduction

Thank you for choosing the Snailax SL-681-2 Cordless Neck and Shoulder Massager. This device is designed to provide deep tissue kneading massage with optional heat, targeting the neck, shoulders, and back for muscle relaxation and comfort. Please read this manual thoroughly before use to ensure safe and effective operation.

Safety Information

- Always unplug the massager from the power source before use.
- Do not use the massager while sleeping or taking a bath.
- Keep the massager away from heat sources and direct sunlight.
- Do not use the massager if you have any medical conditions, are pregnant, or have any injuries or implants in the area to be massaged. Consult a physician before use if you have any concerns.
- Always follow the instructions provided with the massager for safe and proper use.
- Always supervise use and keep away from children.

Package Contents

- 1x Cordless Neck and Shoulder Massager
- 1x Type-C USB Cable
- 1x User Manual




Image: Snailax SL-681-2 package contents including the massager, USB cable, and user manual. Please measure your neck size before purchasing to ensure suitability. Product dimensions are provided in the images for reference.

Product Features

- **4D Shiatsu Kneading Massage:** Designed to replicate the skilled touch of a professional masseur, providing deep tissue relief.
- **Soothing Heat Function:** Features 2 temperature levels (default high) to promote muscle relaxation and enhance the

massage experience.

- **Cordless Freedom:** Offers up to 10 sessions on a single charge, providing portability for use at home, office, or while traveling. Charges via a convenient Type-C port.
- **Wearable and Portable Design:** Weighs only 2.6 pounds and includes a strap for hands-free use, allowing you to perform other activities during massage.
- **Premium Material:** Constructed with Optics PU Leather for durability and comfort.
- **Removable Sleeve:** The massage pad cover is removable for easy cleaning.
- **Low Noise Operation:** Operates at less than 45dB.
- **Auto Shut-off:** Features a default 10-minute timer for safety and convenience.




Image: Illustration of the 4D kneading massage technology with ergonomically designed massage heads. Note: This neck massager has 2 levels of strength to choose from; the default is low. If you feel the strength is too weak, please adjust to high.



Image: Depiction of the soothing heat function with 2 temperature levels (110°F-130°F). Heating relieves muscle stiffness. Note: This neck massager has 2 temperature levels to choose from; the default is high. If you feel the intensity is too strong, please adjust to low.

Setup

Charging the Device

1. The massager may have low power during transportation. Fully charge the product before first use.

2. Connect the provided Type-C USB cable to the massager's charging port.
3. Ensure the Type-C cable is plugged in properly and the charging indicator light is on. If the light is not on, the charging effect may be affected.

Wearing the Massager

The Snailax SL-681-2 offers two primary ways to wear it for optimal massage:

- **Hands-On Mode:** Place the massager around your neck and shoulders. Use the hand straps to pull down and adjust the intensity of the massage.
- **Hands-Free Mode:** Secure the massager around your shoulders using the adjustable back buckle strap. This allows for hands-free operation while maintaining consistent pressure.



Image: Illustration of two ways to wear the Snailax SL-681-2: using the back buckle for hands-free operation or holding the hand straps for adjustable pressure.

Operating Instructions

The control panel is conveniently located on the massager for easy access.



Image: Close-up of the Snailax SL-681-2 control panel with buttons for Power On/Off, Mode, Heat, and Speed.

1. **Power On/Off:** Long-press the power button for 2 seconds to turn the device on or off. The massager has an auto-shutoff function after 10 minutes of continuous use.
2. **Mode Selection:** Press the 'M' button to cycle through different massage modes.
3. **Speed Adjustment:** Use the speed button (represented by vertical lines) to select between low, medium, and high massage speeds.
4. **Heat Function:** Press the heat button (represented by wavy lines) to activate or deactivate the soothing heat function. There are 2 temperature levels available. The default is high; adjust to low if intensity is too strong.

Usage Areas

The versatile design allows for use on various body parts:

- Neck
- Shoulders
- Upper Back
- Lower Back
- Waist
- Legs



Image: Demonstrates the multipurpose use of the Snailax SL-681-2 massager on the neck, back, waist, and leg.

Your browser does not support the video tag.

Video: Official Snailax guide on how to use the Cordless Neck Massager with Heat, demonstrating various applications and features.

Maintenance

Cleaning

- The massage pad cover is removable. Unzip the cover and remove it for cleaning.
- Hand wash the removable cover with mild detergent and air dry. Do not machine wash or tumble dry.
- Wipe the main unit with a soft, damp cloth. Do not immerse the unit in water.

Storage

- Store the massager in a cool, dry place when not in use.
- Avoid placing heavy objects on the massager.

Troubleshooting

Problem	Solution
Battery problem or unable to charge	Note: 1) The power will be lost during transportation. Please fully charge the product before use. 2) Make sure the TYPE-C is plugged in properly and the charging indicator light is on when charging, otherwise it may affect the charging effect. 3) The default timer of this neck massager is 10 minutes. If it stops working after a period of use, it may be due to the end of the timer.
Massage heads rotating at reduced speed	Device may have been in use for 10 minutes. Auto-shutoff function activated. Continue using by pressing the 'On' button after resting the unit for 15 minutes. Over-heat protection function activated. Device is switched off for your safety. Please rest device for 15-30 minutes before restarting.
Device fails to start	Check if device has been used for more than 10 minutes. If so, let device rest for 15 minutes before continuing. Device may require longer time to cool in warmer environments. The battery is low, please charge in time.



Image: A visual representation of common problems and their solutions for the Snailax SL-681-2 massager.

Specifications

- **Product Dimensions:** 1.97 x 3.54 x 2.36 inches
- **Item Weight:** 2 Pounds
- **Item Model Number:** SL-681-2
- **Batteries:** 2 x 9V batteries required (included)
- **Power Source:** Battery Powered
- **Material:** Optics PU Leather
- **Manufacturer:** SNAILAX
- **Date First Available:** February 24, 2024

Warranty and Support

Snailax products typically come with a warranty. Please refer to the product packaging or contact Snailax customer service for specific warranty details and support inquiries. Some reviews mention a 2-year warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question