

onerbl 1d1d35ba-0b90-4033-a565-60feb0cdab77

onerbl 5V AC/DC Adapter Instruction Manual

Model: 1d1d35ba-0b90-4033-a565-60feb0cdab77

Introduction	Safety Information	Setup	Operating Instructions Specifications	Maintenance	Troubleshooting
------------------------------	------------------------------------	-----------------------	---	-----------------------------	---------------------------------

1. INTRODUCTION

This manual provides instructions for the safe and efficient use of your onerbl 5V AC/DC Adapter. This adapter is designed as a replacement power supply for devices requiring 5V DC input, such as the Technical Pro XP152PKG 3000W 15" Rechargeable Bluetooth LED Speaker.

Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

To ensure safe operation, please observe the following precautions:

- Use the adapter only with devices that match its voltage and current specifications (5V DC).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is plugged into a properly grounded wall outlet.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Keep out of reach of children.

EXTENDED CORD DESIGN



Figure 2.1: The adapter features built-in protections against short-circuit, over-voltage, and over-current to ensure electrical safety.

3. SETUP

Follow these steps to set up your onerbl 5V AC/DC Adapter:

1. **Verify Compatibility:** Ensure your device requires a 5V DC power input and has a compatible power port. This adapter is specifically designed for devices like the Technical Pro XP152PKG speaker.
2. **Inspect the Adapter:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Device:** Insert the DC output plug of the adapter firmly into the power input port of your device.
4. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard AC 100-240V 50/60Hz wall outlet.
5. **Power On Device:** Once connected, you can power on your device.



Figure 3.1: The adapter connected to a power strip, demonstrating a typical setup for powering a device.

4. OPERATING INSTRUCTIONS

The onerbl 5V AC/DC Adapter operates automatically once connected. It converts the AC wall current to the required 5V DC for your compatible device.

- The adapter is designed for continuous operation within its specified voltage and current limits.
- If your device has an internal battery, the adapter will charge the battery while simultaneously powering the device.
- Monitor your device for proper charging or operation after connecting the adapter.

5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, cuts, or bends. Replace the adapter if any damage is observed.



Figure 5.1: Front and side views of the adapter, highlighting its design for easy handling and storage.

6. TROUBLESHOOTING

If you encounter issues with your adapter, refer to the following table:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not powering on/charging.	◦ Adapter not properly plugged in. ◦ Wall outlet not functioning. ◦ Device power port issue. ◦ Adapter is damaged. ◦ Device is incompatible.	◦ Ensure both ends of the adapter are securely connected. ◦ Test the wall outlet with another device. ◦ Check the device's power port for debris or damage. ◦ Inspect the adapter for physical damage. If damaged, replace it. ◦ Verify device voltage and connector type.
Adapter feels excessively hot.	◦ Overload or short circuit. ◦ Poor ventilation.	◦ Immediately unplug the adapter. Check the connected device for issues. ◦ Ensure the adapter is in a well-ventilated area.

7. SPECIFICATIONS

Feature	Detail
Brand	onerbl
Model Number	1d1d35ba-0b90-4033-a565-60feb0cdab77
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 5V
Plug Format	Type A (US Standard)
Total Power Outlets	1
Cable Length	Approximately 76 inches (6.3 feet)
Protection Features	Over Voltage Protection, Over Heat Protection, Short Circuit Protection, Over Current Protection




Figure 7.1: Dimensions of the adapter and its cable length.

8. WARRANTY AND SUPPORT

This product is covered by a standard warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer.

For technical support or inquiries, please contact onerbl customer service through your purchase platform or the contact information provided with the product packaging.

© 2024 onerbl. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question