Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TECLAST P30T

TECLAST P30T Android 14 Tablet User Manual

Model: P30T

Introduction

Thank you for choosing the TECLAST P30T Android 14 Tablet. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly to ensure optimal performance and longevity of your tablet.



Image: Front and back view of the TECLAST P30T tablet.

What's in the Box

The TECLAST P30T tablet comes with a comprehensive accessory kit to enhance your user experience. Please check that all items are present:

- TECLAST P30T Tablet
- Keyboard
- Mouse
- Protective Case
- Stylus
- Screen Protector (pre-applied or included)
- USB-C Charging Cable
- Power Adapter

- OTG Adapter
- Headphones
- Tablet Stand
- Camera Privacy Cover



Image: The TECLAST P30T tablet shown with its full accessory kit, including keyboard, mouse, stylus, and stand.

Product Overview

The TECLAST P30T features a sleek design with a durable metal body, measuring just 7.8mm thin and weighing approximately 440g. It is designed for comfortable handling and portability.



Image: The TECLAST P30T tablet showcasing its thin profile and metal construction.

Key Components:

- **Display:** 10.1-inch IPS screen with 1280x800 resolution, TDDI, In-cell touch technology, 300 nits brightness, and up to 120Hz touch sampling rate.
- **Processor:** Unisoc T606 Octa-Core CPU (2x A75, 6x A55) with Mali-G57 GPU.
- **Memory & Storage:** 4GB RAM + 8GB virtual expansion (total 12GB), 128GB internal storage, expandable up to 1TB via microSD card.

- **Cameras:** 5MP AI Dual Rear Camera with autofocus and flashlight, 2MP Front Camera for video calls and face recognition.
- **Battery:** 6000mAh with USB-C charging.
- **Connectivity:** Dual-band Wi-Fi 6 (802.11ax), Bluetooth 5.0.
- **Audio:** Dual speakers with PureSound audio, digital amplifier chip, 3.5mm headphone jack.
- **Navigation:** Supports Beidou, GPS, GLONASS, GALILEO, A-GPS.

Setup

1. Initial Power On and Language Settings

1. Press and hold the power button until the TECLAST logo appears.
2. Follow the on-screen prompts to select your preferred language and region.
3. Complete the initial Android setup, including connecting to Wi-Fi and signing in to your Google account.

2. Wi-Fi Connection

1. Go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if prompted.

Image: The TECLAST P30T tablet demonstrating Wi-Fi 6 connectivity.

3. Bluetooth Device Pairing (Keyboard/Mouse)

To pair the included Bluetooth keyboard:

1. Turn on the Bluetooth keyboard using its power switch.
2. On your tablet, go to **Settings** > **Connected devices** > **Pair new device**.
3. Select "TECLAST K10" (or similar name) from the list of available devices.
4. Confirm the pairing code if prompted.




Image: Step-by-step guide for connecting the TECLAST Bluetooth keyboard.

To pair the included Bluetooth mouse:

1. Turn on the Bluetooth mouse using its power switch.

2. On your tablet, go to **Settings** > **Connected devices** > **Pair new device**.
3. Select "BT5.2 Mouse" (or similar name) from the list of available devices.
4. Confirm the pairing.




Image: Step-by-step guide for connecting the TECLAST Bluetooth mouse.

4. MicroSD Card Installation

1. Locate the microSD card slot on the side of your tablet.
2. Gently insert the microSD card into the slot until it clicks into place.
3. The tablet will detect the card, and you can then format it or use it for additional storage.



Image: The TECLAST P30T tablet illustrating the microSD card slot and its storage capabilities.

Operating Instructions

Android 14 Features

The TECLAST P30T runs on Android 14, offering enhanced personalization, security, and productivity features.



Image: Overview of Android 14 features on the TECLAST P30T tablet.

Parallel View

Maximize tablet landscape usability. Parallel View allows you to split the screen horizontally, displaying an app's main menu and content page simultaneously, providing access to more information at once.



Image: The TECLAST P30T tablet displaying an application in Parallel View mode.

Productivity Features

- **Multitasking:** Easily perform multiple tasks with optimized landscape experience and customizable taskbar.
- **UI Customization:** Personalize your interface with various colors, themes, and language options.
- **Accessibility:** Enhanced accessibility features including pinch-to-zoom, larger fonts, and non-flash notifications.
- **Security:** Strengthen device security with 6-digit lock screen passwords and improved data privacy settings.



Image: The TECLAST P30T tablet showcasing multitasking, UI customization, accessibility, and security features.

Gestures and Widgets

- **3-Finger Screenshot:** Enable in **Settings** > **Gestures** to quickly capture screenshots.
- **Dock Bar:** For quick application launch and window switching.
- **Widget Function:** Set up desktop widgets for easy access to necessary information.
- **Split Screen:** Use split-screen mode to perform two tasks simultaneously.



Image: The TECLAST P30T tablet demonstrating 3-finger screenshot, Dock bar, widget function, and split screen.

Parental Control

Utilize the built-in "Family Link" parental control feature to manage screen time, monitor app usage, remotely lock the device, and check your child's tablet location information.




Image: A child using the TECLAST P30T tablet with parental control features enabled.

GPS Functionality

The TECLAST P30T supports Beidou, GPS, GLONASS, GALILEO, and A-GPS for precise and accurate global navigation and direction.



Image: The TECLAST P30T tablet mounted in a car, displaying GPS navigation.

Camera Usage

The P30T features a 5MP AI dual camera system on the rear and a 2MP front camera. The AI focus function helps capture accurate photos, and the "FaceGlam" feature enhances facial contours in real-time for attractive portraits.



Image: The TECLAST P30T tablet showcasing its camera features, including AI dual camera and flashlight.

Face Recognition

The front camera supports face recognition for convenient and secure unlocking. Register your face information to easily access your tablet system without needing to enter a password.



Image: A user unlocking the TECLAST P30T tablet using face recognition.

Audio Features

Experience immersive audio with the P30T's dual speakers and PureSound audio technology. The tablet also features a 3.5mm headphone jack for private listening.



Image: The TECLAST P30T tablet highlighting its stereo sound and digital amplifier chip.

Active Noise Cancelling

The system features dual microphones and adaptive noise suppression (ANS) to effectively reduce environmental noise. This ensures your voice is prioritized during calls, conferences, and video recordings.



Image: The TECLAST P30T tablet demonstrating active noise cancelling for individual and team meetings.

Widevine L1 Support

The TECLAST P30T supports Widevine L1, allowing you to stream high-definition content from platforms like Amazon Prime, Disney+, and Hulu.



Image: The TECLAST P30T tablet displaying high-definition content, indicating Widevine L1 support.

GMS Certification

The TECLAST P30T is GMS (Google Mobile Services) certified, ensuring full access to the Google Play Store and its millions of applications, as well as other Google services.



Image: The TECLAST P30T tablet displaying various app icons, indicating GMS certification.

Maintenance

Cleaning Your Tablet

- Always power off the tablet before cleaning.
- Use a soft, lint-free cloth, slightly dampened with water or a screen cleaner, to wipe the screen and body.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays, as these can damage the screen and finish.
- Do not allow moisture to enter any openings.

Battery Care

- Charge the tablet using the provided USB-C cable and power adapter.
- Avoid extreme temperatures, as they can affect battery life.
- For optimal battery health, avoid fully discharging the battery frequently.



Image: The TECLAST P30T tablet highlighting its 6000mAh battery and USB-C charging port.

Troubleshooting

Common Issues and Solutions:

- **Tablet won't turn on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If it still doesn't turn on, try holding the power button for 10-15 seconds.
- **Screen is unresponsive:** Restart the tablet. If the issue persists, perform a factory reset (note: this will erase all data).
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Ensure you are within range of the Wi-Fi signal.
- **Bluetooth device won't pair:** Ensure the Bluetooth device is in pairing mode and within range. Restart Bluetooth on both the tablet and the accessory.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache and data in**Settings** > **Apps**. Ensure your apps are updated to the latest version.
- **Slow performance:** Close unnecessary background apps. Clear cache regularly. Consider uninstalling unused apps.

If you encounter persistent issues not covered here, please refer to the support section for contact information.

Specifications

Feature	Detail
Brand	TECLAST
Model Series	P30T
Operating System	Android 14
Processor	Unisoc T606 8-Core CPU (1.6 GHz)
RAM	12 GB (4GB installed + 8GB virtual expansion)

Feature	Detail
Storage Capacity	128 GB
Expandable Storage	Up to 1TB via microSD
Screen Size	10.1 inches
Native Resolution	1280x800 pixels
Aspect Ratio	16:10
Wireless Type	Bluetooth, Wi-Fi (802.11ax / Wi-Fi 6)
Mobile Phone Technology	5G (Note: This refers to Wi-Fi 5GHz band, not cellular 5G)
Hardware Interface	MicroSD, Bluetooth, Headphone
Battery Type	Lithium Polymer
Battery Capacity	6000mAh
Item Weight	450 grams
Included Components	Keyboard, Mouse, Protective Case, Stylus, Film

Warranty and Support

TECLAST products are designed for reliability and performance. In the event of any issues, please refer to the following support information:

- **Warranty:** Please refer to the warranty card included with your product for specific warranty terms and conditions. Typically, TECLAST offers a limited warranty against manufacturing defects.
- **Customer Service:** For technical support, troubleshooting assistance, or warranty claims, please contact TECLAST customer service. Contact details can usually be found on the official TECLAST website or on the packaging.
- **Online Resources:** Visit the official TECLAST website for FAQs, updated drivers, and additional support resources.

When contacting support, please have your product model (P30T) and purchase information readily available.

© 2024 TECLAST. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQYLBWB8

More documents and user manuals: **https://manuals.plus/**