

[Manuals.plus](#) /

› [bamboosang](#) /

› bamboosang Professional Vertical Garment Steamer GT1 User Manual

bamboosang GT1

bamboosang Professional Vertical Garment Steamer GT1 User Manual

Model: GT1

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, setup, and maintenance of your bamboosang Professional Vertical Garment Steamer GT1. Please read this manual thoroughly before first use and retain it for future reference.



Image: The bamboosang GT1 Professional Vertical Garment Steamer in use, demonstrating its powerful features.

The bamboosang GT1 Garment Steamer is designed for efficient wrinkle removal and fabric refreshing. It features 1400W power, 95g/min continuous steam, and 12 steam adjustment levels, suitable for various fabric types.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the steamer away from children and pets.
- Use only distilled or de-mineralized water to prevent mineral buildup and prolong appliance life.
- **Double Overheating Protection:** The appliance features automatic power-off if the iron soleplate temperature exceeds 150°C, and automatic heating stop if steam temperature reaches 170°C.
- **High-Temperature Sterilization:** The steam output provides high-temperature sterilization, contributing to garment hygiene.
- **Water Shortage Prompt:** The water tank includes a sensor that prompts when water levels are low, preventing dry heating.
- Always unplug the steamer from the electrical outlet when filling or emptying the water tank, and when not in use.
- Do not operate the steamer with a damaged cord or plug.

Functionality and Security



01

- Double Overheating Protection
- Enhances equipment safety



02

- High Temperature Sterilisation Function
- Cares for garment health



03

- Tank Water Shortage Prompt
- Prevents performance decline



04

- Self Cleaning Function
- Extends machine lifespan

Image: Overview of the steamer's key safety and functionality features.

3. PRODUCT COMPONENTS

The following components are included with your bamboosang GT1 Garment Steamer:

Product Accessories

High quality professional clothing care



Main Unit



Water Tank



Ironing Board



Ironing Board
Cover



Triangle
Support Pole



Garment
Hanger



Telescopic
Aluminium Poles



Ironing Board
Support Tube




Connecting
Shaft



Steamer
Head Holder



Rag



Heat-resistant
Gloves

Image: All components and accessories included with the steamer.

- Main Unit (with base and steam generator)
- 1.6L Removable Translucent Water Tank
- Foldable Ironing Board
- Ironing Board Cloth Cover
- Triangle Support Pole
- Garment Hanger
- Telescopic Aluminium Poles (2 sections)
- Ironing Board Support Tube
- Connecting Shaft
- Steamer Head Holder
- Rag
- Heat Protecting Glove

4. SETUP

Follow these steps to assemble your garment steamer:

Installation Method

Ironing board & Connecting shaft

Ironing board installation



1. Unfold the ironing board



2. Insert the ironing board support tubes into the back holes



3. Complete

Connecting shaft installation



1. Unscrew the nut of the connecting shaft



2. Insert the hole of the telescopic poles



3. Screw on the nuts, complete

Image: Detailed installation steps for the ironing board and connecting shaft.

4.1 Ironing Board Installation

1. Unfold the ironing board.
2. Insert the ironing board support tubes into the designated holes on the back of the board.
3. Ensure the board is securely attached and stable.

4.2 Connecting Shaft Installation

1. Unscrew the nut from the connecting shaft.
2. Insert the connecting shaft into the hole of the telescopic poles.
3. Screw on the nuts to secure the shaft.

4.3 Assembling the Poles and Hanger

1. Attach the telescopic aluminum poles to the main unit base.
2. Secure the garment hanger and steamer head holder to the top of the telescopic poles.
3. Adjust the height of the poles as needed. The height can be adjusted between 1.3m and 1.67m.



Image: Retractable support poles and their adjustable height.

4.4 Filling the Water Tank

1. Remove the 1.6L translucent water tank from the main unit.
2. Open the tank cap and fill with distilled or de-mineralized water. Do not overfill.
3. Close the cap securely and place the water tank back into the main unit. Ensure it is properly seated.




Image: Removing and filling the 1.6L removable water tank.

5. OPERATING INSTRUCTIONS

Before operating, ensure the water tank is filled and the steamer is properly assembled.

5.1 Powering On and Heating

1. Plug the power cord into a suitable electrical outlet (220V AC).
2. Turn on the power switch. The steamer will begin to heat up.
3. The steamer has a fast heat-up time, producing continuous steam in approximately 50 seconds.



Powerful Ironing Performance

12 Steam Adjustments

Steam pressure
6Bar

Steam output time
50s

Steam volume
95g/min

Image: Steamer head applying steam to a garment, highlighting performance metrics.

5.2 Adjusting Steam Levels

The steamer offers 12 levels of steam adjustment to suit different fabric types. Rotate the steam control dial on the main unit to select the desired steam intensity.

- **Levels 1-3:** Delicate fabrics like Silk, Nylon.
- **Levels 4-6:** Synthetic Fiber, Cotton, Linen.
- **Levels 7-9:** Mixed Fabric, Woolen, Plush.
- **Levels 10-12:** Down, Thick Plush, and other heavy fabrics.



12 Steam Adjustment



Removable water tank



Bottom with wheel

 Level 1: Silk	 Level 2: Nylon	 Level 3: Wool	 Level 4: Synthetic Fiber	 Level 5: Cotton	 Level 6: Linen
 Level 7: Mixed Fabric	 Level 8: Woolen	 Level 9: Plush	 Level 10: Thick Plush	 Level 11: Down	 Level 12: Thickened Plush

Image: Steamer in use, illustrating the 12 steam adjustment levels for various fabrics.

5.3 Ironing Methods

The bamboosang GT1 supports both vertical and horizontal ironing.

Foldable Ironing Board

Triangular support pole, load capacity 75kg



Horizontal Ironing Method



Vertical Ironing Method

Image: Demonstrating both horizontal and vertical ironing methods.

Vertical Ironing

- Hang the garment on the provided hanger.
- Hold the steamer head close to the fabric, moving it in a downward motion.
- Use the heat protecting glove to hold the bottom of the garment taut.

Horizontal Ironing

- Unfold the ironing board and secure it in the horizontal position.
- Place the garment flat on the ironing board.
- The steamer head can be rotated 90° for flexible angles and easy access to tough areas.
- Utilize the pulse steam function for powerful bursts to remove stubborn creases. The ceramic coated soleplate ensures even heat distribution and smooth ironing results.



90°Rotatable Tironing Head

Provides flexible angles for easy access to tough areas

- Pulse steam function
- Powerful steam burst for quick wrinkle removal
- Temperature control technology
- Adjustment for different fabrics, preventing damage
- Ceramic coating technology
- Smooth ironing results

Image: The 90° rotatable ironing head in action, detailing its features.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your steamer.

6.1 Self-Cleaning Function

The steamer is equipped with a self-cleaning function to prevent dust and limescale buildup. Refer to the product's control panel for the self-cleaning button and follow the instructions:

1. Ensure the water tank is filled.
2. Press and hold the self-cleaning button (usually indicated by a 'Clean' or 'Self-Clean' icon).
3. Allow the cycle to complete. This process helps maintain steam quality and prevents clothing contamination.

6.2 Draining and Storage

- After each use, unplug the steamer and allow it to cool completely.

- Remove the water tank and empty any remaining water.
- Wipe down the exterior of the steamer with a soft, damp cloth.
- Store the steamer in a dry, cool place. The foldable ironing board and retractable poles allow for compact storage.

7. TROUBLESHOOTING

If you encounter issues with your steamer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; steamer not heated; mineral buildup.	Refill water tank; allow 50 seconds for heating; perform self-cleaning cycle.
Water leaking from steamer head	Condensation; steamer not hot enough; mineral buildup.	Allow steamer to fully heat before use; perform self-cleaning; ensure proper water level.
Steamer not turning on	Not plugged in; power switch off; overheating protection activated.	Check power connection; ensure switch is on; unplug and allow to cool for 30 minutes before restarting.
Wrinkles not removing effectively	Incorrect steam level; moving too quickly; fabric type.	Select higher steam level; move steamer head slower; use pulse steam for stubborn wrinkles; ensure garment is taut.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	bamboosang
Model Number	GT1
Wattage	1400 watts
Voltage	220 Volts (AC)
Heat Time	50 Seconds
Steam Flow	95g/min
Steam Pressure	6 Bar
Max Steam Temperature	170°C / 338°F
Water Tank Capacity	1.6 litres
Product Dimensions (L x W x H)	86.5L x 48.5W x 167H centimetres (max height)
Colour	Grey
Benefits	Remove Wrinkle, Fabric Refreshening, Sterilize

9. WARRANTY AND SUPPORT

Your bamboosang Professional Vertical Garment Steamer GT1 is covered by a manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact bamboosang customer support. For technical assistance, troubleshooting not covered in this manual, or to inquire about replacement parts, please contact bamboosang customer service through the retailer's platform or the official bamboosang website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question