

Enya NEXG SE PURPLE

ENYA NEXG SE Smart Acoustic Electric Carbon Fiber Travel Guitar User Manual

Model: NEXG SE PURPLE | Brand: Enya

1. PRODUCT OVERVIEW

The ENYA NEXG SE is an innovative acoustic-electric travel guitar designed for versatility and portability. It features an integrated 30W wireless speaker, a DSP chip for customizable effects via the ENYA MUSIC App, and a wireless headset microphone for singing and playing. Constructed from carbon fiber, it offers a durable and lightweight design suitable for various musical scenarios.



Figure 1: Enya NEXG SE Smart Guitar and included accessories.



Figure 2: Internal components of the NEXG SE, highlighting the integrated speaker system.

2. SETUP

2.1 Unboxing and Initial Inspection

Upon receiving your ENYA NEXG SE, carefully remove all components from the thickened gig bag. Verify that all listed accessories are present: the guitar, wireless headset microphone, charging cable, and adjusting wrench.

2.2 Charging the Guitar

Connect the provided charging cable to the guitar's charging port. The guitar features an internal battery that powers its smart functions and speaker. Ensure the guitar is fully charged before first use for optimal performance.

2.3 Bluetooth Connectivity

The NEXG SE can connect to your smart device via Bluetooth for app control and audio streaming. To connect:

1. Power on the guitar.
2. Open the ENYA MUSIC App on your smart device.
3. Follow the in-app instructions to pair your device with the guitar.

Your browser does not support the video tag.

Video 1: Demonstrates how to connect the NEXG SE guitar to Bluetooth for app control and audio playback.

2.4 Wireless Headset Microphone Setup

The included wireless headset microphone allows for integrated singing and playing. Pair the microphone with the guitar according to the instructions provided with the microphone. Adjust EQ and reverb settings for the microphone via the ENYA MUSIC App.



NEXG SE

Sing & Play Anywhere

NEXG SE comes with a wireless headset mic. Combined with the onboard speaker, you've basically got a Karaoke machine. The Vocal Removal is built in for sing-alongs. Sing it out. Play it out, any-time, anywhere.



Figure 3: The wireless headset microphone included with the NEXG SE.

3. OPERATING INSTRUCTIONS

3.1 Onboard Speaker and Sound

The NEXG SE features a powerful 30W onboard speaker, eliminating the need for external amplification in many settings. The speaker provides rich bass, clear mids, and sparkling treble. Adjust the volume using the dedicated knob on the guitar's control panel.



The Onboard Speaker

The speaker is thoroughly developed to deliver better sonic performance: louder volume, wider dynamic range, and prominent frequency response.



Figure 4: Detail of the 30W onboard speaker, providing powerful sound directly from the guitar.


Your browser does not support the video tag.

Video 2: A sound check demonstrating the audio capabilities of the Enya NEXG SE Smart Guitar.

3.2 DSP Chip and ENYA MUSIC App

The integrated DSP chip allows for extensive sound customization. Use the ENYA MUSIC App to:

- Store and recall 4 onboard presets.
- Adjust effects such as overdrive, wah, delay, reverb, chorus, vibrato, octave, compression, and EQ.
- Utilize the vocal removal feature to play along with backing tracks.
- Profile the tone of other acoustic guitars onto your NEXG SE.



NEX SE

Color Display Screen

A color display screen makes navigating through the presets and functionalities intuitive. All the presets are expandable through ENYA MUSIC App.



Figure 5: The intuitive color display screen for navigating presets and functionalities.

Effects

EQ

Acoustic Vol

75

AC profiling

Comp

Dist

Octa

NonlinFit

Direct

Delay

Reverb

User Guide

Save

Profile Again

Acoustic Profiling

Get any acoustic guitar onto NEXG

Effects

EQ

Acoustic Vol

75

AC profiling

Comp

Dist

Octa

NonlinFit

Direct

Delay

Reverb

User Guide

Save

NEXG SE

Your Own Sound

We've developed an App for you to further customize your own sound. The Profiling feature allows you to copy the tone from any other acoustic guitar onto NEXG SE. The versatility is incredible.

Figure 6: The ENYA MUSIC App interface, allowing for deep customization of effects and sound profiles.

Your browser does not support the video tag.

Video 3: Demonstration of the vocal removal feature on the Enya NEXG SE, allowing users to play along with instrumental tracks.

3.3 Playing and Practice Modes

- **Live Play:** Utilize the onboard speaker for performances or practice sessions without external gear.
- **Silent Practice:** Connect headphones to the guitar for private practice sessions. All effects and backing tracks will be routed through your headphones.
- **External Connection:** The guitar can be connected to a Digital Audio Workstation (DAW) or traditional amplifier for recording or larger performances.

Your browser does not support the video tag.

Video 4: A tutorial on how to play "House of the Rising Sun" on the NEXG SE, showcasing its playability.

4. MAINTENANCE

4.1 Cleaning and Care

The carbon fiber body of the NEXG SE is durable and easy to clean. Use a soft, damp cloth to wipe down the guitar after each use. Avoid abrasive cleaners or solvents that could damage the finish. Store the guitar in its thickened gig bag when not in use to protect it from dust and impacts.

4.2 String Replacement

The guitar comes equipped with Phosphor Bronze strings. For optimal tone and playability, replace strings regularly based on your usage. Refer to standard guitar string replacement guides for proper technique. The guitar uses D'Addario XS strings for best performance.

4.3 Truss Rod Adjustment

An adjusting wrench is included for truss rod adjustments, which may be necessary to maintain optimal neck relief due to environmental changes or string gauge preferences. If you are unfamiliar with truss rod adjustments, it is recommended to seek assistance from a qualified guitar technician.

5. TROUBLESHOOTING

5.1 No Sound from Speaker/Effects

- Ensure the guitar is powered on and fully charged.
- Check the volume level on the guitar and within the ENYA MUSIC App.
- Verify that no headphones are plugged in if you intend to use the onboard speaker.
- If using effects, ensure they are enabled and configured correctly in the app.

5.2 Bluetooth Connectivity Issues

- Make sure Bluetooth is enabled on your smart device and the guitar.
- Restart both the guitar and your smart device.
- Forget the device in your smart device's Bluetooth settings and attempt to re-pair.
- Ensure the ENYA MUSIC App is up to date.

5.3 Wireless Microphone Not Connecting

- Ensure the microphone is charged and powered on.
- Refer to the microphone's specific pairing instructions.

- Check microphone settings within the ENYA MUSIC App.

6. SPECIFICATIONS

Feature	Specification
Item Weight	10.18 pounds
Package Dimensions	41.5 x 12.5 x 4.9 inches
Country of Origin	China
Item Model Number	NEXG SE PURPLE
Back Material	Carbon Fiber
Body Material	Carbon Fiber
Color Name	Purple
Fretboard Material	carbon fiber
Guitar Pickup Configuration	combination
Scale Length	23.7 Inches
String Material	Phosphor Bronze
Top Material	Carbon Fiber
Neck Material Type	Carbon Fiber
Number of Strings	6
Guitar Bridge System	Fixed
Musical Style	world-music
Size	SE
Hand Orientation	Right

7. WARRANTY AND SUPPORT

Enya Musical is committed to providing quality products and customer satisfaction. For any inquiries, technical support, or warranty claims, please contact Enya Musical directly. They offer 24-hour global service to assist with your needs. Additional protection plans may be available for purchase through authorized retailers.

For further assistance, you may also refer to the official User Manual (PDF) available online:[User Manual \(PDF\)](#)

8. IMPORTANT SAFETY INFORMATION

- Do not expose the guitar to extreme temperatures or humidity.
- Avoid dropping or subjecting the guitar to severe impacts.
- Keep the guitar away from water or other liquids.
- Use only the provided charging cable and adapter to prevent damage.
- Do not attempt to disassemble or repair the guitar yourself, as this may void the warranty and cause damage.

© 2024 Enya Musical. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question