

FINETONES US-47LUC-KIE68-ES2

FINETONES 71-inch Pantry Cabinet User Manual

Model: US-47LUC-KIE68-ES2

1. INTRODUCTION

Thank you for choosing the FINETONES 71-inch Pantry Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

- **Anti-Tip Kit:** It is mandatory to fix the product to the wall using the provided anti-tip kit to prevent the cabinet from tipping over. Failure to do so can result in serious injury or death.
- **Assembly:** Due to the large size and weight of the cabinet, assembly by two people is recommended.
- **Electrical Safety:** Ensure all electrical connections for the power outlets and LED lights are properly installed and conform to local electrical codes. Do not overload the outlets.
- **Material Care:** The cabinet is constructed from engineered wood. Handle components with care during assembly to prevent damage.

3. PACKAGE CONTENTS

Verify that all parts and hardware are present before beginning assembly. A detailed list of numbered parts and screws is included in the separate assembly instructions provided with your product. If any parts are missing or damaged, please contact customer support.

4. SETUP AND ASSEMBLY

Follow the detailed, step-by-step assembly instructions provided in the separate manual. All parts are numbered for easy identification. A rubber mallet may be useful for certain steps, but avoid excessive force to prevent damage to the engineered wood components.

4.1. General Assembly Overview



Figure 1: Fully assembled FINETONES 71-inch Pantry Cabinet in white.



Figure 2: Diagram showing the dimensions and internal storage layout, including adjustable shelves and drawers.

4.2. Door Alignment

If the cabinet doors are not aligned or flush after assembly, adjustments can be made using the hinges. Refer to the video below for detailed instructions on how to adjust the hinges to correct common door alignment issues.

Video 1: Instructions on how to adjust cabinet hinges for proper door alignment.

5. OPERATING INSTRUCTIONS

5.1. Power Outlets and USB Ports

The cabinet features a built-in charging station with 2 standard AC outlets and 2 USB ports, located on the countertop level. Use these to power kitchen appliances such as microwaves, coffee makers, or to charge mobile devices.



Figure 3: The integrated charging station with two AC outlets and two USB ports.

5.2. LED Lights

The cabinet includes LED strip lights to illuminate the open countertop area. These lights enhance visibility and can be turned on/off via a switch located near the power outlets. Ensure the velcro is used to keep wires neatly organized.



Figure 4: The pantry cabinet demonstrating LED lighting in both daytime and nighttime settings.

5.3. Adjustable Shelves

The cabinet features adjustable shelves within the upper and lower compartments, allowing you to customize storage space according to your needs. To adjust a shelf, remove any items, lift the shelf, and reposition the shelf pins to the desired height.

3 Drawer & 6 Door Large Capacity

This pantry cabinet is ideal thanks to its plentiful storage and spacious display space. It's a versatile addition to extend the storage space in any room, including the kitchen, dining room, living room, etc. Smooth white finishes and sleek lines create an elegant modern kitchen cabinet.



Figure 5: Illustration of the adjustable shelves within the cabinet compartments.

5.4. Drawers and Cabinets

The cabinet includes three smooth-gliding drawers and multiple cabinet doors for organized storage. The handleless design provides a sleek, modern aesthetic.



Figure 6: The three large capacity drawers with smooth sliding rails, providing ample storage.

Video 2: Overview of the FINETONES 71-inch Tall Kitchen Pantry Storage Cabinet, highlighting its features.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.

7. TROUBLESHOOTING

- **Doors Not Aligning:** Refer to the "Steps to Get Doors Aligned and Flat by Adjusting the Hinges" video in Section 4.2 for detailed adjustment instructions.
- **LED Lights Not Working:** Check the power connection to the charging station and ensure the switch is in the 'on' position. Verify that the LED strip is properly connected.
- **Power Outlets/USB Ports Not Working:** Ensure the main power switch for the charging station is on. Check if the cabinet's power cord is securely plugged into a functional wall outlet.
- **Drawers Sticking:** Ensure the drawer slides are clean and free of debris. Lubricate with a silicone-based spray if necessary.

8. SPECIFICATIONS

Feature	Detail
Brand	FINETONES
Model Name	Kitchen Pantry Storage Cabinet
Model Number	US-47LUC-KIE68-ES2
Color	White
Product Dimensions	15.2"D x 39.4"W x 70.9"H
Material	Engineered Wood
Item Weight	124 Pounds
Special Features	Adjustable Shelf, Built-In Charging Station (2 AC Outlets, 2 USB Ports), Handleless Design, LED Lights, Wall-mounted Device (Anti-tip kit)
Number of Shelves	4

Number of Drawers	3
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact FINETONES customer service directly. Ensure you have your model number (US-47LUC-KIE68-ES2) available when contacting support.