

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Bewinner](#) /

› [Bewinner 1L Electric Ceramic Stew Pot User Manual \(Model: Bewinnerv74a1gnu2x-12\)](#)

Bewinner Bewinnerv74a1gnu2x-12

Bewinner 1L Electric Ceramic Stew Pot User Manual

Model: Bewinnerv74a1gnu2x-12

Brand: Bewinner

1. IMPORTANT SAFETY PRECAUTIONS

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the main unit in water or any other liquid.
- Keep out of reach of children.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged.
- The appliance features an **anti-dry burn function** to prevent damage if water levels are too low. However, always ensure sufficient water is present for operation.
- Use only the provided inner pot and accessories.
- Avoid touching hot surfaces. Use handles or oven mitts.

2. PRODUCT OVERVIEW

The Bewinner 1L Electric Ceramic Stew Pot is a versatile and compact appliance designed for preparing a variety of dishes, including soups, stews, porridge, and desserts. Its intelligent features and ceramic construction ensure efficient and safe cooking.

Key features include a 1-liter capacity, 200W power for efficient cooking, and a 24-hour intelligent reservation function for customized cooking times. The ceramic inner pot is non-stick and durable, making it easy to use and clean. The compact design is suitable for small kitchens or individual use.

24 hours reservation
Fully automatic cooking



Figure 2.1: The Bewinner Electric Ceramic Stew Pot, highlighting its 24-hour reservation and automatic cooking capabilities.



Non stick, easy to clean
Thickening and durability



Figure 2.2: The ceramic inner pot, emphasizing its non-stick, easy-to-clean, and durable properties.



Figure 2.3: Illustration of the 200W low-power heating system, designed for energy efficiency.

3. PRODUCT COMPONENTS

The Bewinner Electric Ceramic Stew Pot includes the following main components:

- **Main Unit:** The outer housing containing the heating element and control panel.
- **Ceramic Inner Pot:** The primary cooking vessel.
- **Lid:** Covers the inner pot during cooking.
- **Steaming Rack:** (If included, for steaming functions)
- **Instruction Manual:** This document.

One piece raised pot mat



Cooling base for efficient heat dissipation



One touch simmering



Figure 3.1: Internal view of the main unit with its raised pot mat and the cooling base for efficient heat dissipation.

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the ceramic inner pot and lid with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are dry before assembly.
3. **Placement:** Place the main unit on a flat, stable, and heat-resistant surface. Ensure adequate

ventilation around the appliance.

4. **Add Water to Main Unit:** Pour the appropriate amount of water into the main unit's outer chamber, around the area where the inner pot will sit. This water is used for steaming and indirect heating.
5. **Place Inner Pot:** Carefully place the ceramic inner pot into the main unit.
6. **Add Ingredients:** Add your desired ingredients and liquids into the ceramic inner pot.
7. **Cover:** Place the lid securely on the inner pot.
8. **Connect Power:** Plug the power cord into a 110V US standard electrical outlet.



Figure 4.1: Correct placement of the ceramic inner pot into the main unit.

5. OPERATING INSTRUCTIONS

The control panel features touch buttons for various functions and settings.

One piece raised pot mat



Cooling base for efficient heat dissipation



One touch simmering



Figure 5.1: The touch control panel for operating the stew pot.

5.1 Function Selection

Press the 'Function' button to cycle through the available cooking modes. The selected mode will be indicated by a light next to its name on the control panel. Available functions typically include:

- **Dessert:** For sweet dishes and custards.
- **Steam:** For steaming foods like buns or vegetables (requires a steaming rack, if included).

- **Porridge:** For cooking various types of porridge.
- **Bird's Nest:** A specialized function for delicate ingredients.
- **Keep Warm:** Maintains food at a warm temperature after cooking.
- **Soup:** For preparing soups and broths.

5.2 Time Adjustment

After selecting a function, use the '+' and '-' buttons to adjust the cooking time. The digital display will show the set time.

5.3 Delay Start (Reservation Function)

To use the 24-hour intelligent reservation function:

1. Press the 'Delay Start' button.
2. Use the '+' and '-' buttons to set the desired delay time (up to 24 hours). This is the time until cooking begins.
3. Select your desired cooking function and adjust its cooking time.
4. The appliance will start cooking automatically after the delay time has elapsed.

5.4 Starting and Canceling

- Once the function and time are set, the appliance will typically start automatically after a few seconds, or you may need to press the 'Function' button again to confirm and start.
- To cancel an ongoing program or reset settings, press the 'Cancel' button.

Your browser does not support the video tag.

Video 5.1: Demonstration of the Bewinner Electric Ceramic Stew Pot's various cooking functions and ease of use, including preparing different meals and setting timers.

6. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your stew pot.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Inner Pot and Lid:** The ceramic inner pot and lid should be **hand washed** with warm soapy water. Do not use abrasive cleaners or scouring pads that could damage the ceramic surface. Rinse thoroughly and dry completely.
- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water. Ensure no water enters the electrical components.
- **Storage:** Store the clean and dry appliance in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your Bewinner Electric Ceramic Stew Pot, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power outage.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.

Problem	Possible Cause	Solution
Food is not cooking or heating properly.	Incorrect function selected; insufficient water in the outer chamber; lid not properly sealed.	Verify the correct cooking function is selected. Ensure adequate water is in the main unit's outer chamber. Check that the lid is securely placed.
Anti-dry burn protection activated.	Water level in the outer chamber is too low.	Unplug the appliance, allow it to cool, and add more water to the outer chamber before restarting.
Control panel buttons are unresponsive.	Temporary electronic glitch; moisture on the panel.	Unplug the unit for a few minutes, then plug it back in. Ensure the control panel is dry and clean.

If the problem persists after trying these solutions, please contact customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Bewinner
Model Number	Bewinnerv74a1gnu2x-12
Color	Pink
Material	Ceramic
Capacity	1 Liter
Wattage	200 watts
Voltage	110 Volts (US Plug)
Control Method	Touch
Number of Settings	2 (Implied by control panel options)
Item Weight	3.49 pounds
Package Dimensions	9.5 x 9.2 x 8.9 inches
Dishwasher Safe	No (Hand Wash Only)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Bewinner aims to provide quality products and support.

You may also visit the [Bewinner Store on Amazon](#) for additional product information and contact options.