

## Dynalink DL-GT36

# Dynalink Google TV Box DL-GT36 User Manual

4K UHD Smart Streaming Media Player

## 1. INTRODUCTION

This manual provides essential information for setting up and operating your Dynalink Google TV Box DL-GT36. This device transforms your television into a smart entertainment hub, offering access to a wide range of streaming services, apps, and features through the Google TV operating system. Please read these instructions carefully before use.

## 2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1x Dynalink Google TV Streaming Player
- 1x Voice Remote Control
- 1x HDMI 2.0 Cable
- 1x Power Adapter
- 1x Micro USB Cable
- 2x AAA Batteries
- 1x Quick Start Guide

# Package Contents



1x Streaming player



1 x Quick Guide



2x AAA Batteries



1 x Remote



1x HDMI 2.0 Cable



1x Power Adaptor

1x Micro USB Cable

Image: Contents of the Dynalink Google TV Box package.

## 3. SETUP INSTRUCTIONS

Follow these steps to set up your Dynalink Google TV Box:

1. **Connect the Power Adapter:** Plug the Micro USB cable into the Dynalink Google TV Box and connect the power adaptor to an electrical outlet.
2. **Connect the HDMI Cable:** Connect one end of the HDMI cable to the HDMI port on the Dynalink Google TV Box and the other end to an available HDMI input on your television. Note the HDMI input number (e.g., HDMI 1, HDMI 2).
3. **Insert Batteries into Remote:** Open the battery compartment on the back of the voice remote control and insert the two AAA batteries, ensuring correct polarity.
4. **Power On and Select Input:** Turn on your television and use your TV remote to select the corresponding HDMI input where the Dynalink Google TV Box is connected.
5. **Initial Google TV Setup:** Follow the on-screen instructions to complete the initial setup, which includes connecting

to your Wi-Fi network, logging into your Google account, and installing desired streaming applications.

# Google Assistant Voice Control

Built-In Google Assistant, use voice searches & actions




Image: Seamless setup of the Dynalink Google TV Box.

## 4. OPERATING INSTRUCTIONS

Once set up, you can begin using your Dynalink Google TV Box:

### 4.1. Using the Voice Remote Control

The included voice remote control allows for intuitive navigation and voice commands:

- **Navigation Pad:** Use the circular pad to move through menus and select items.
- **Google Assistant Button:** Press and hold this button to activate Google Assistant. Speak your commands or questions into the remote's microphone. For example, say "Hey Google, open Netflix" or "Hey Google, show me dramas."
- **Volume Control:** Adjust the volume of your television using the dedicated volume buttons.
- **App Shortcut Buttons:** Quickly access popular streaming services like YouTube and Netflix with dedicated buttons.

# Dolby Audio

Ensures flawless reproduction of cinematic sound for movies



Image: Using the Google Assistant voice control on the Dynalink remote.

## 4.2. Navigating Google TV

The Google TV interface organizes your content for easy discovery:

- **Home Screen:** Displays personalized recommendations, recently watched content, and your installed apps.
- **For You Tab:** Provides tailored content suggestions based on your viewing habits and subscriptions.
- **Live Tab:** Access live TV channels from supported services.
- **Apps Tab:** Browse and launch all your installed applications.
- **Library Tab:** Find your purchased movies and TV shows.





# Easy-to-Use Google TV Interface

All of your subscriptions in one place





Image: Easy-to-use Google TV interface.

## 4.3. Chromecast Built-in

The Dynalink Google TV Box features Chromecast built-in, allowing you to cast content from compatible mobile devices or computers directly to your TV screen:

- Ensure your mobile device or computer is connected to the same Wi-Fi network as your Google TV Box.
- Open a Chromecast-enabled app (e.g., YouTube, Netflix, Google Photos) on your device.
- Tap the Cast icon () within the app and select your Dynalink Google TV Box from the list of available devices.

# Chromecast built-in

Built-In unlocks endless streaming on your big screen




Image: Seamless casting with Chromecast built-in.

## 5. KEY FEATURES

The Dynalink Google TV Box DL-GT36 offers several advanced features for an enhanced entertainment experience:

- **4K UHD Visual Clarity:** Experience content in stunning Ultra HD 4K resolution with HDR10+ support, providing vivid visuals and lifelike colors.





## Brilliant 4K UHD

Experience vivid 4K Ultra HD and dynamic HDR for exceptional viewing

Image: Brilliant 4K UHD display.

- **Dolby Audio Support:** Enjoy immersive sound quality with Dolby Audio, delivering a cinematic audio experience for movies and shows.

# Dolby Audio

Ensures flawless reproduction of cinematic sound for movies



Image: Dolby Audio ensures flawless reproduction of cinematic sound.

- **Google TV 12.0 OS:** Runs on the latest certified Google TV 12.0 operating system, offering a user-friendly interface that consolidates all your favorite content in one place.
- **High Performance & Storage:** Equipped with 2GB DDR4 RAM for smooth operation and 16GB eMMC internal storage for installing numerous apps and games.





Image: Powerful ARM Quad 64-bit Cortex-A35 CPU with 2GB DDR4 and 16GB eMMC.

- **Dual-Band Wi-Fi & Bluetooth 5.0:** Supports 2.4G/5G dual-band Wi-Fi for fast and stable internet connectivity, and Bluetooth 5.0 for connecting game controllers, headphones, and other accessories.

6. SPECIFICATIONS

Feature	Specification
Brand	Dynalink
Model Name	DL-GT36
Operating System	Google TV 12.0
Resolution	4K UHD
RAM	2GB DDR4
Storage	16GB eMMC

Connectivity Technology	Wireless (2.4G/5G Dual WiFi, Bluetooth 5.0)
Connector Type	HDMI
Special Features	Chromecast, Voice Control (Google Assistant)
Product Dimensions	3.11 x 3.11 x 0.87 inches
Item Weight	12 ounces

## 7. TROUBLESHOOTING

If you encounter issues with your Dynalink Google TV Box, refer to the following common solutions:

- **No Power:**

- Ensure the power adapter is securely connected to the device and a working power outlet.
- Check if the power outlet is functional by plugging in another device.

- **No Signal on TV:**

- Verify that the HDMI cable is firmly connected to both the Google TV Box and your television.
- Confirm that your TV is set to the correct HDMI input source.
- Try a different HDMI port on your TV or a different HDMI cable.

- **Remote Control Not Responding:**

- Replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote and the Google TV Box.
- If the remote is paired via Bluetooth, try re-pairing it according to the on-screen instructions during initial setup or in the device settings.

- **Wi-Fi Connection Issues:**

- Restart your Wi-Fi router and the Google TV Box.
- Ensure the Google TV Box is within range of your Wi-Fi router.
- Check your Wi-Fi password for accuracy.

- **App Freezing or Crashing:**

- Close and restart the problematic application.
- Clear the app's cache and data through the Google TV settings (Settings > Apps > [App Name] > Clear cache/Clear data).
- Ensure the Google TV Box software and all apps are updated to their latest versions.

## 8. OFFICIAL PRODUCT VIDEO

Watch the official product video for an overview of the Dynalink Google TV Box features and capabilities.

Your browser does not support the video tag.

Video: Dynalink Google TV Box, 4K UHD Smart Streaming Media Player with Voice Remote Control. This video highlights the device's features, including its easy-to-use interface, 4K UHD and HDR support, Dolby Audio, Google Assistant, and simple plug-and-play setup.

## 9. WARRANTY AND SUPPORT

---

For warranty information, please refer to the documentation included with your product or visit the official Dynalink website. If you require further assistance or technical support, please contact Dynalink customer service through their official channels.