Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DICKIE TOYS 204114015

Dickie Toys ABC Cozy Carlo Instruction Manual

Model: 204114015

1. Product Overview

The Dickie Toys ABC Cozy Carlo is a durable toy bus designed for young children. It features a freewheel mechanism for easy movement and an interactive sunroof that can be opened and closed, encouraging fine motor skills and imaginative play. This toy is part of the ABC series, focusing on early childhood development through engaging play.



Figure 1: Front-side view of the Dickie Toys ABC Cozy Carlo toy bus.

2. Safety Information

Important: Please read all safety information before allowing a child to play with this toy.

- **Recommended Age:** This toy is suitable for children aged 12 months and up.
- **Supervision:** Adult supervision is recommended during play, especially for younger children.
- **Choking Hazard:** Ensure all parts are securely attached before play. Regularly inspect the toy for any loose or broken parts that could pose a choking hazard.
- **Material Safety:** The toy is made from child-safe, non-toxic materials.
- **Damage:** Do not use the toy if it is damaged. Dispose of damaged toys properly.



Figure 2: Side view indicating the 12 months and up age recommendation.

3. Setup and First Use

The Dickie Toys ABC Cozy Carlo comes fully assembled and ready for play. No batteries or complex setup are required.

1. **Unboxing:** Carefully remove the toy from its packaging. Dispose of all packaging materials responsibly and keep them away from children.
2. **Inspection:** Before first use, inspect the toy for any signs of damage or loose parts.
3. **Cleaning:** Wipe the toy with a damp cloth before initial use (refer to Section 5 for detailed cleaning instructions).



Figure 3: The product as it appears in its retail packaging.

4. Operating Instructions

The ABC Cozy Carlo is designed for simple, intuitive play.

- **Freewheel Movement:** Push the bus forward or backward on a flat surface. The freewheel mechanism allows for smooth and easy rolling.
- **Opening Sunroof:** The sunroof on top of the bus can be manually opened and closed. Gently lift the front edge of the sunroof to open it, and push it down to close. This feature allows for interactive play, such as placing small items inside the bus.



Figure 4: The Cozy Carlo with its sunroof in the open position, highlighting its interactive feature.

5. Maintenance and Care

Proper care will ensure the longevity of your toy.

- **Cleaning:** Wipe the toy clean with a soft, damp cloth. Do not immerse the toy in water. Avoid using harsh chemicals or abrasive cleaners, as these may damage the toy's finish or materials.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check the wheels and sunroof mechanism for any debris or obstructions that might hinder their function.

6. Troubleshooting

If you encounter any issues with your ABC Cozy Carlo, refer to the following common solutions:

Problem	Possible Cause / Solution
Toy does not roll smoothly.	Check the wheels for any hair, lint, or debris that may be obstructing movement. Clean as necessary. Ensure the toy is on a flat, smooth surface.
Sunroof is difficult to open or close.	Inspect the sunroof hinges and edges for any foreign objects or damage. Ensure no pressure is being applied to the sunroof while attempting to open or close it.
Visible damage to the toy.	Discontinue use immediately to prevent potential hazards. Contact customer support if the toy was recently purchased and appears to be defective.

7. Specifications

Feature	Detail
Model Number	204114015
Product Dimensions (L x W x H)	11.02 x 7.09 x 7.09 inches (28 x 18 x 18 cm)
Item Weight	1.34 pounds (0.61 kg)
Recommended Age	12 months and up
Features	Freewheel, Opening Sunroof
Material	Child-safe plastic



Figure 5: Top-down view of the Cozy Carlo, showing its compact design.

8. Warranty and Support

DICKIE TOYS products are manufactured to high-quality standards. For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official DICKIE TOYS website.

DICKIE TOYS Official Website: Visit DICKIE TOYS Store on Amazon

© 2026 DICKIE TOYS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CR1JMMD9

More documents and user manuals: **https://manuals.plus/**