

[Manuals.plus](#) /

› [ECONTROLLY](#) /

› ECONTROLLY KKG9A-C1 KKG9B-C2 Replacement Remote Control User Manual

ECONTROLLY KKG9A-C1

ECONTROLLY KKG9A-C1 KKG9B-C2 Replacement Remote Control User Manual

INTRODUCTION

This manual provides instructions for the ECONTROLLY KKG9A-C1 and KKG9B-C2 replacement remote control, designed for use with various Changhong, Mirage, and Agratto A/C air conditioner models. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

SETUP

1. Battery Installation

The remote control requires two (2) AAA batteries (not included).

1. Open the battery compartment cover located on the back of the remote control.
2. Insert the batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.

Note: For optimal performance and to avoid issues, use new alkaline batteries. Rechargeable batteries may not provide sufficient power.



This image displays the back of the remote control with the battery compartment cover removed, showing the slots for two AAA batteries. The battery polarity markings are visible, indicating correct insertion.

2. Initial Use

No programming or setup is required. Once batteries are installed, the remote control is ready for use with compatible air conditioner models.

OPERATING INSTRUCTIONS

Basic Functions

The remote control features several buttons for managing your air conditioner's functions:

- **Power Button:** Turns the air conditioner ON or OFF.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temp ▲/▼ Buttons:** Adjusts the temperature setting.
- **Fan Button:** Adjusts fan speed.

- **Swing Button:** Controls the louver swing function.
- **Sleep Button:** Activates or deactivates sleep mode.
- **Display Button:** Toggles the display on the air conditioner unit.
- **Turbo Button:** Activates rapid cooling or heating.
- **Timer Button:** Sets the ON/OFF timer.
- **Lock Button:** Locks the remote control settings to prevent accidental changes.
- **Quiet Button:** Activates quiet operation mode.
- **Hour/Settime/Minu Buttons:** Used for setting the timer or clock functions.
- **Reset Button:** Resets the remote control to default settings. Use a pointed object to press.



This image shows the front of the ECONTROLLY replacement remote control, highlighting its ergonomic design and button layout. Key buttons visible include Power, Mode, Temp, Fan, Swing, Sleep, Display, Turbo, Timer, Lock, Quiet, Hour, Settime, Minu, and Reset.

Important Note on Temperature Display

This remote control is designed to display temperature in Celsius. It cannot be converted to Fahrenheit. If your air

conditioner unit displays Fahrenheit, using this remote may cause the unit to switch to Celsius display. This is an inherent characteristic of the remote control.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's performance degrades, the display becomes dim, or it stops responding. Follow the battery installation steps outlined in the Setup section.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period (e.g., several months), remove the batteries to prevent potential leakage and damage to the remote control.

TROUBLESHOOTING

Remote Control Not Responding

- Ensure new alkaline batteries are correctly installed. Replace old or rechargeable batteries with fresh alkaline ones.
- Check for any physical obstructions between the remote control and the air conditioner's infrared receiver.
- Ensure you are within the effective operating range of the air conditioner (typically within 20 feet and direct line of sight).

Air Conditioner Display Changes to Celsius

This remote control operates exclusively in Celsius. If your air conditioner unit was previously set to Fahrenheit, using this remote will likely cause the unit's display to switch to Celsius. This is expected behavior and cannot be altered by the remote control.

Compatibility Issues

This remote is compatible with specific Changhong, Mirage, and Agratto A/C models, including KKG9A-C1 and KKG9B-C2. If you are unsure about compatibility with your specific air conditioner model, please contact customer support for assistance.

SPECIFICATIONS

Model Numbers: KKG9A-C1, KKG9B-C2

Material: ABS (Acrylonitrile Butadiene Styrene)

Power Supply: 2 x AAA batteries (not included)

Dimensions: Approximately 6 x 3 x 0.5 inches (15.24 x 7.62 x 1.27 cm)

Weight: Approximately 2 ounces (56.7 grams)

Compatible Brands: Changhong, Mirage, Agratto

Special Feature: Ergonomic design

SUPPORT

For any questions regarding compatibility, operation, or troubleshooting not covered in this manual, please contact ECONTROLLY customer support. When contacting support, please provide your air conditioner model number for faster and more accurate assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I switch the ECONTROLLY KKG9A-C1 remote control from Fan mode to Cooling mode?

To change the operation of your air conditioner from "Fan" mode to "Cool" mode using the ECONTROLLY KKG9A-C1 remote control, follow these steps: Locate the Mode Button on the front of the remote control....

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0CR3RC65C>

More documents and user manuals: <https://manuals.plus/>