

Manuals.plus /

› Skraut Home /

› Skraut Home TV Unit Set with Electric Fireplace 100\_2\_02 Instruction Manual

## Skraut Home 100\_2\_02

# Skraut Home TV Unit Set with Electric Fireplace

Model: 100\_2\_02

## 1. IMPORTANT SAFETY INFORMATION

---

Please read and understand all safety warnings and instructions before assembly and use of this product. Failure to follow these instructions may result in injury or damage.

- **Tipping Hazard:** This furniture unit carries a risk of tipping if not properly secured. Always ensure stable fixation of the furniture to prevent accidents.
- **Assembly Instructions:** Carefully follow all assembly instructions provided. Do not deviate from the steps outlined.
- **Electric Fireplace Usage:** Use the electric fireplace strictly in accordance with its specific instructions. Ensure proper storage and handling after use.
- **Sharp Edges and Children:** Be aware of potential sharp edges during assembly and use. Supervise children closely when they are near the furniture.

## 2. SETUP AND ASSEMBLY

---

Assembly of this TV unit set is required. Detailed assembly instructions are included with the product packaging. Please ensure all components are present before beginning assembly.

### 2.1 Required Tools (Not Included)

- Screwdriver (Phillips head recommended)
- Hammer
- Measuring tape
- Level

### 2.2 Assembly Steps

1. Unpack all components and verify against the parts list in the included manual.
2. Follow the step-by-step diagrams and instructions for assembling each module (TV module, central buffet module, shelf unit).
3. Ensure all screws and fasteners are tightened securely. Do not overtighten.
4. Position the assembled units in your desired location, ensuring the floor is level.
5. Secure the furniture to the wall using appropriate anti-tip hardware (if provided and recommended in the main manual) to prevent tipping.




Figure 1: Technical drawing showing the dimensions of the TV unit set, including the TV module, central buffet, and shelf unit. Dimensions are in millimeters.



Figure 2: An overall view of the assembled Skraut Home TV unit set, featuring the electric fireplace, TV module, central buffet, and a four-shelf unit.

### 3. OPERATING THE ELECTRIC FIREPLACE

---

The integrated electric fireplace provides a realistic 3D flame effect without heat, ensuring safety from burns. It operates via an electrical connection.

#### 3.1 Powering On/Off

- Connect the fireplace power cord to a standard electrical outlet.
- Use the included remote control to turn the fireplace effect on or off.

#### 3.2 Adjusting Flame Intensity

- The remote control allows you to select from 3 levels of flame intensity. Refer to the remote control's specific instructions for button functions.

#### 3.3 Remote Control Batteries

- The remote control requires batteries, which are not included with the product. Insert the correct battery

type as indicated in the remote control's compartment.



Figure 3: A close-up view of the electric fireplace, showcasing its realistic 3D flame effect.



# SKRAUT HOME



Figure 4: A detailed perspective of the electric fireplace unit, highlighting its design and integration into the furniture.

## 4. MAINTENANCE

---

Regular maintenance will help preserve the appearance and functionality of your Skraut Home TV unit set.

### 4.1 Cleaning the Furniture

- Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the melamine finish.
- For stubborn marks, use a mild soap solution and immediately dry with a clean cloth.
- Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent discoloration or warping.

### 4.2 Electric Fireplace Care

- Ensure the fireplace is unplugged before cleaning.
- Gently wipe the exterior surfaces with a soft, dry cloth. Do not spray liquids directly onto the unit.
- Periodically check the power cord for any signs of damage.



Figure 5: A close-up image illustrating the high-quality oak wood grain texture of the furniture's surface.

## 5. TROUBLESHOOTING

---

If you encounter issues with your TV unit set or electric fireplace, refer to the following common solutions.

### 5.1 Furniture Stability Issues

- **Wobbling:** Check all assembly screws and ensure they are securely tightened. Verify that the furniture is placed on a level surface.
- **Tipping:** Re-check the wall fixation. Ensure appropriate anti-tip hardware is correctly installed and secured to a sturdy wall stud or anchor.

### 5.2 Electric Fireplace Not Functioning

- **No Power:** Ensure the power cord is fully plugged into a working electrical outlet. Check the circuit breaker if necessary.
- **Remote Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace sensor.

- **No Flame Effect:** If the unit has power but no flame effect, refer to the specific fireplace manual for advanced troubleshooting or contact customer support.

## 6. SPECIFICATIONS

Feature	Detail
Model Number	100_2_02
Overall Dimensions (L x W x H)	310 x 35 x 186 cm
Weight	88 Kilograms
Material	Melamine
Color	Oak and Black
Number of Shelves	4
Electric Fireplace Power	34 W
Fireplace Features	LED flame effect, 3 intensity levels, remote control
Assembly Required	Yes



Figure 6: The TV unit with its doors open, revealing the spacious storage compartments within the TV module and central buffet.

## 7. WARRANTY AND SUPPORT

---

For warranty information, please refer to the documentation included with your purchase or contact the retailer directly. Specific details regarding spare parts availability are not provided at this time.

### 7.1 Customer Support

If you require further assistance, have questions about assembly, or need to report a damaged part, please contact Skraut Home customer service or your point of purchase. Have your model number (100\_2\_02) and purchase details ready for faster service.