

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Gaiatop](#) /

> Gaiatop Portable Mini Fan User Manual

Gaiatop HF-01

Gaiatop Portable Mini Fan User Manual

Model: HF-01

Brand: Gaiatop

INTRODUCTION

Thank you for choosing the Gaiatop Portable Mini Fan. This compact and versatile fan is designed to provide personal cooling with its 3-speed settings, integrated power display, and convenient flashlight. Its lightweight and rechargeable design makes it ideal for both indoor and outdoor use.





Figure 1: Gaiatop Portable Mini Fan (Black)

WHAT'S INCLUDED

Please check the package contents upon unboxing:

- 1 x Gaiatop HF-01 Handheld Fan
- 1 x User Manual
- 1 x Type-C Charging Cable



Figure 2: Key features of the Gaiatop Portable Mini Fan

SETUP

Charging the Fan

The Gaiatop Portable Mini Fan is equipped with an 1800mAh rechargeable battery. For optimal performance, fully charge the fan before first use.

1. Locate the Type-C charging port on the fan.
2. Connect the provided Type-C charging cable to the fan and a compatible USB power source (e.g., computer, wall adapter).
3. The LED display will show the charging status and battery percentage. A full charge takes approximately 2.5 hours.

Long Battery Life Type-C Fast Charging Inlet

 **6.5h**
1st Speed

 **3.5h**
2nd Speed

 **2h**
3rd Speed



Figure 3: Charging the fan via Type-C port. A full charge provides 2-7 hours of operation depending on speed setting.

OPERATING INSTRUCTIONS

Power On/Off and Speed Control

The fan features a single power button for easy operation.

- To turn on the fan and set to Speed 1: Press the power button once.
- To set to Speed 2: Press the power button a second time.
- To set to Speed 3: Press the power button a third time.
- To turn off the fan: Press the power button a fourth time.

LED Display

The integrated LED display provides real-time information:

- **Charging State:** Indicates if the fan is currently charging.
- **Percentage of Power:** Shows the remaining battery capacity.
- **Gear Display:** Displays the current wind speed setting (1, 2, or 3).

Flashlight Function

The fan includes a built-in LED flashlight at the bottom.

- To turn the flashlight on/off: Double-click the power button quickly.




Figure 4: LED display details and flashlight operation.



Figure 5: Simple operation guide for the fan's functions.

FEATURES AND DESIGN

The Gaiatop Portable Mini Fan is designed for convenience and efficiency.

- **Powerful Brushless Motor:** Provides strong and stable airflow across all three speeds.
- **Long Battery Life:** 1800mAh battery offers 2-7 hours of continuous use on a single charge.
- **Portable Design:** Compact size (2"D x 2"W x 6"H) and lightweight (0.25 lbs) for easy carrying in a pocket or bag.
- **Handheld or Desktop Use:** Equipped with a metal buckle for hanging and an anti-slip pad at the bottom for stable desktop placement.
- **Integrated Flashlight:** LED light at the bottom provides an additional utility feature.

Lightweight Design

0.25lb



Figure 6: Demonstrating the fan's lightweight and portable design.



Figure 7: Illustration of the fan's powerful brushless motor.

MAINTENANCE

To ensure the longevity and optimal performance of your Gaiatop Portable Mini Fan, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fan. Do not use harsh chemicals or abrasive materials. Ensure the fan is turned off before cleaning.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Recharge the fan regularly, even if not in constant use.
- **Avoid Obstructions:** Ensure the fan blades and air inlets/outlets are free from dust, lint, or other obstructions to maintain proper airflow.

TROUBLESHOOTING

If you encounter issues with your Gaiatop Portable Mini Fan, please refer to the following common solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Low battery or no charge.	Charge the fan using the provided Type-C cable. Check the LED display for charging status.
Weak airflow.	Fan blades or air inlets are obstructed.	Ensure there are no obstructions around the fan blades or air vents. Clean if necessary.
Flashlight does not turn on.	Incorrect operation or low battery.	Double-click the power button quickly to activate the flashlight. Ensure the fan has sufficient battery charge.
Fan makes unusual noise.	Foreign object in fan or damaged blades.	Turn off the fan immediately. Inspect for any foreign objects. If damaged, discontinue use and contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Gaiatop
Model Name	HF-01
Color	Black
Product Dimensions	2"D x 2"W x 6"H
Item Weight	0.25 Pounds (4 ounces)
Power Source	Battery Powered
Battery Capacity	1800mAh Lithium Ion (included)
Charging Time	Approx. 2.5 hours (with 2A fast charging)
Working Time	2-7 hours (depending on speed)
Number of Speeds	3
Control Method	Touch (button)
Special Features	Portable, LED Light, LED Display, Lightweight
Included Components	Handheld Fan, User Manual, Type-C Cable
Indoor/Outdoor Usage	Outdoor, Indoor
Country of Origin	China

WARRANTY AND SUPPORT

Specific warranty information for the Gaiatop Portable Mini Fan is not provided in this manual. For details regarding warranty coverage, technical support, or replacement parts, please contact Gaiatop customer service directly or visit their official website.

You can often find support information on the product packaging or through the retailer where the product was purchased.