

- Manuals.plus /
- › ODK /
 - › ODK Chest of Drawers with 6 Fabric Drawers, 2 AC Outlets, and 2 USB Charging Ports (Model SNG-6D)

ODK SNG-6D

ODK Chest of Drawers with 6 Fabric Drawers, 2 AC Outlets, and 2 USB Charging Ports

Model: SNG-6D

1. INTRODUCTION

Thank you for choosing the ODK Chest of Drawers, Model SNG-6D. This versatile storage unit is designed to enhance your living space with its functional design, featuring six spacious fabric drawers, a sturdy metal frame, and an integrated power strip with two AC outlets and two USB charging ports. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new furniture.



Image 1.1: The ODK Chest of Drawers, Model SNG-6D, showcasing its six fabric drawers and the integrated power strip on the top surface.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the drawers or the top surface. Refer to the Specifications section for weight limits.
- Use the included anti-tip kit to secure the unit to a wall. This is crucial to prevent tipping, especially in households with children or pets.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Do not expose the unit to excessive moisture or direct sunlight.

- When using the integrated power strip, ensure that the total power consumption of connected devices does not exceed the specified limits.
- Do not attempt to modify the electrical components.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Top Panel
- Wooden Middle Shelf
- 6 Fabric Drawers with Handles
- Integrated Power Strip (2 AC Outlets, 2 USB Ports) with Power Cord
- Assembly Hardware (Screws, Allen Wrench, Screwdriver)
- Adjustable Feet
- Anti-Tip Kit
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. It is recommended to have two people for certain steps. Follow the detailed instructions provided in the included manual for best results.

1. **Unpack and Organize:** Carefully unpack all components and lay them out on a soft, clean surface. Group similar parts and hardware.
2. **Assemble the Metal Frame:** Connect the vertical and horizontal metal frame components using the provided screws and Allen wrench. Ensure all connections are secure.
3. **Install Wooden Panels:** Attach the wooden top panel and the wooden middle shelf to the assembled metal frame. Use the designated screws and screwdriver.
4. **Insert Power Strip:** Carefully place the integrated power strip into its designated cutout on the top wooden panel. Secure it if necessary according to the specific instructions.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the rigid bottom panel to give it shape. Attach the handles to the front of each drawer.
6. **Insert Drawers:** Slide the assembled fabric drawers into their respective compartments within the frame.
7. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the metal frame. Adjust them to ensure the unit is level and stable on uneven floors.
8. **Install Anti-Tip Kit:** Secure the anti-tip kit to the back of the chest of drawers and to a wall stud using the provided hardware. This step is critical for safety.



Image 4.1: Dimensional overview of the ODK Chest of Drawers, including overall unit measurements and individual drawer sizes.



Image 4.2: Detail showing the adjustable feet and the 11.7 cm clearance beneath the unit, allowing for robot vacuum operation.

5. OPERATING INSTRUCTIONS

5.1 Using the Fabric Drawers

The six fabric drawers provide ample storage. To open, gently pull the handle. To close, push the drawer fully into its compartment. Avoid forcing drawers if they feel stuck; ensure they are properly aligned.

5.2 Using the Integrated Power Strip

The chest of drawers features a built-in power strip with two standard AC outlets and two USB charging ports for convenient device charging.

- **Connecting to Power:** Plug the power cord from the integrated strip into a wall outlet.
- **AC Outlets:** Insert your device's power adapter into one of the two AC outlets.
- **USB Charging Ports:** Connect your USB charging cable directly to one of the two USB ports to charge compatible devices.

Caution: Do not exceed the maximum power rating of the integrated power strip. Refer to the Specifications section for details.

Posto Alto sul Terreno

| Consente al Robot Spazzante di Lavorare Senza Problemi



Image 5.1: The integrated power strip, showing two AC outlets and two USB ports for convenient charging.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your ODK Chest of Drawers.

- **Cleaning the Frame and Wooden Panels:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning Fabric Drawers:** For light cleaning, use a lint roller or a soft brush to remove dust and debris. For stains, spot clean with a mild detergent and a damp cloth, then air dry completely. Do not machine wash the fabric drawers.
- **Electrical Components:** Ensure the power strip and cord are free from dust and debris. Do not immerse in water.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your chest of drawers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit is wobbly or unstable.	Loose fasteners; uneven floor.	Tighten all assembly screws. Adjust the leveling feet at the bottom of the frame. Ensure the anti-tip kit is properly installed.

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Drawer not fully unfolded; bottom panel not inserted correctly; drawer overloaded.	Ensure the fabric drawer is fully expanded and the bottom panel is flat. Reduce the weight in the drawer.
Power outlets/USB ports not working.	Power cord not plugged in; wall outlet not active; device malfunction; overloaded circuit.	Check if the power cord is securely plugged into a working wall outlet. Test the wall outlet with another device. Ensure the total load does not exceed the power strip's rating. Try a different device or cable.
Missing parts during assembly.	Packaging error.	Contact ODK customer support with your purchase details and a list of missing parts.

If you experience issues not covered here, or if the problem persists, please contact ODK customer support.

8. SPECIFICATIONS

- **Brand:** ODK
- **Model:** SNG-6D
- **Color:** White
- **Product Dimensions (Overall):** 100 cm (Width) x 30 cm (Depth) x 83.7 cm (Height)
- **Drawer Dimensions (Internal):** Approximately 29.5 cm (Width) x 30 cm (Depth) x 22.5 cm (Height)
- **Item Weight:** 14.13 kg
- **Material:** Metal frame, Wooden top/shelf, Fabric drawers
- **Power Strip:**
 - 2 AC Outlets (120-240V/12A)
 - 2 USB Charging Ports (5V/2A)
 - Power Cord Length: 178 cm
- **Clearance from Ground:** 11.7 cm (suitable for robot vacuum cleaners)
- **Maximum TV Size (Recommended):** Up to 50 inches (when used as a TV stand)

9. WARRANTY AND SUPPORT

ODK is committed to providing quality products and customer satisfaction.

- **Return/Exchange Policy:** ODK offers a free return or exchange service within 30 days of purchase.
- **Customer Support:** For any questions, concerns, or assistance with your product, please contact our professional 24-hour online customer service team. They will endeavor to resolve your issue as quickly as possible.
- **Contact Information:** Please refer to your purchase documentation or the ODK official website for the most current customer support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find the PDF installation manual for the ODK SNG-6D Chest of Drawers since it was missing from the package?

You can find the assembly and setup instructions for the ODK SNG-6D Chest of Drawers directly on the product page. While a direct PDF download link is not currently provided, the following steps summarize...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0CR47RH4Z>

More documents and user manuals: <https://manuals.plus/>