

[Manuals.plus](#) /

› [ARCADE1UP](#) /

› ARCADE1UP NBA Jam 30th Anniversary Deluxe Arcade Machine User Manual

ARCADE1UP B0CR5FVL62

ARCADE1UP NBA Jam 30th Anniversary Deluxe Arcade Machine User Manual

Model: B0CR5FVL62

INTRODUCTION

Welcome to the world of classic arcade gaming with your new ARCADE1UP NBA Jam 30th Anniversary Deluxe Arcade Machine. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your arcade unit. Relive the glory days of arcade basketball with NBA JAM, NBA JAM TOURNAMENT EDITION, and NBA HANGTIME, featuring built-in Wi-Fi for online multiplayer and global leaderboards.

SAFETY INFORMATION

Recommended Minimum Age: 14 years and up. This product is designed for users aged 14 and older. Adult supervision is recommended for younger users. Ensure the arcade machine is placed on a stable, level surface to prevent tipping. Keep all electrical components away from liquids. Do not attempt to modify or repair the unit yourself. Refer all servicing to qualified personnel.

WHAT'S IN THE BOX

Your ARCADE1UP NBA Jam Deluxe Arcade Machine package includes:

- ARCADE CABINET
- Pre-installed games: NBA Jam, NBA Jam Tournament Edition, and NBA Hang Time
- Assembly hardware and tools
- Power adapter
- Instruction Manual

Please verify all components are present before beginning assembly.



Image: The ARCADE1UP NBA Jam Deluxe Arcade Machine in its retail packaging, showing the cabinet and game titles.

SETUP

Assembly

The ARCADE1UP NBA Jam Deluxe Arcade Machine requires assembly. Follow the detailed instructions provided in the included assembly guide. It is recommended to have at least two people for assembly due to the size and weight of the components. Ensure all screws and fasteners are securely tightened for stability.

ARCADE1UP
DELUXE

3 GAMES INCLUDED



Image: The fully assembled ARCADE1UP NBA Jam Deluxe Arcade Machine, highlighting its design and the inclusion of three games.

Placement

Choose a suitable location for your arcade machine. The unit measures approximately 32 x 25 x 61 inches and weighs 89.4 pounds. Ensure there is enough space around the machine for comfortable gameplay, especially for multiple players. Avoid placing the unit in direct sunlight or near heat sources. A stable, flat surface is crucial for safe operation.



Image: The ARCADE1UP NBA Jam Deluxe Arcade Machine with its height and width dimensions clearly marked, indicating its substantial

size.

OPERATING INSTRUCTIONS

Power On/Off

To power on the arcade machine, locate the ON/OFF button on the control panel. Press it to turn the unit on. The screen will display a loading sequence. To power off, press the ON/OFF button again.

Video: A user demonstrates the power on/off and volume controls on the ARCADE1UP NBA Jam machine's control panel.

Game Selection

Once powered on, the main menu will appear, allowing you to select from the three classic NBA Jam titles: NBA Jam, NBA Jam Tournament Edition, and NBA Hang Time. Use the joysticks and buttons to navigate and select your desired game.

Video: A detailed look at the game selection screen and the process of choosing a game on the NBA Jam arcade machine.

Gameplay

The arcade machine supports 2 to 4 players simultaneously. Each player has a dedicated joystick and set of buttons for shooting, blocking, passing, and stealing. The upgraded joysticks and light-up buttons enhance the arcade experience. The 17-inch BOE color monitor provides vibrant graphics for an immersive gameplay experience.



Image: A close-up view of the control panel, showing the joysticks, light-up buttons, and player indicators for up to four players. Utilize the built-in Wi-Fi for online multiplayer matches with up to 3 other players. You can also access global leaderboards to compete for high scores. The dual speakers provide dynamic sound effects that enhance the gameplay.

Video: Demonstrates gameplay on the NBA Jam arcade machine, highlighting the action and player interaction.

Volume Control

Adjust the game volume using the dedicated volume controls located on the control panel. This allows you to set the audio level to your preference for an optimal gaming environment.

MAINTENANCE

To ensure the longevity and optimal performance of your arcade machine, regular maintenance is recommended:

- **Cleaning:** Use a soft, dry cloth to wipe down the cabinet and control panel. For the screen, use a screen-safe cleaner and a microfiber cloth. Avoid abrasive cleaners or solvents that could damage the polyglass surface or

graphics.

- **Dusting:** Regularly dust the vents and openings to prevent dust buildup, which can affect internal components.
- **Cable Management:** Ensure all cables are neatly organized and not pinched or strained.
- **Storage:** If storing the unit for an extended period, ensure it is in a dry, temperature-controlled environment.

TROUBLESHOOTING

If you encounter any issues with your ARCADE1UP NBA Jam Deluxe Arcade Machine, refer to the following common troubleshooting tips:

- **No Power:** Ensure the power adapter is securely plugged into both the machine and a working electrical outlet. Check if the ON/OFF button is pressed.
- **No Display:** If the unit powers on but there is no image, ensure all internal connections are secure (refer to assembly guide). Try restarting the machine.
- **Connectivity Issues (Wi-Fi):** If you experience problems with online multiplayer or leaderboards, check your home Wi-Fi network connection. Ensure the arcade machine is within range of your router. You may need to reconfigure network settings via the machine's menu.
- **Controls Unresponsive:** If joysticks or buttons are not responding, power cycle the machine. Check for any physical obstructions or damage to the controls.
- **Game Freezing/Crashing:** Restart the machine. Ensure the software is up to date if updates are available via Wi-Fi.

For persistent issues not resolved by these steps, please contact ARCADE1UP customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	32 x 25 x 61 inches
Item Weight	89.4 pounds
Monitor Size	17-inch BOE Color Monitor
Number of Players	2-4 players (Wi-Fi Online Multiplayer)
Included Games	NBA Jam, NBA Jam Tournament Edition, NBA Hang Time
Special Features	Light Up Buttons, Global Leaderboards, Light Up Marquee, 3D Molded Light Up Coin Doors, Dual Speakers, Metal Certificate of Authenticity Plaque
Manufacturer Recommended Age	14 years and up
Country of Origin	China

WARRANTY AND SUPPORT

This product typically comes with a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the documentation included with your purchase or visit the official ARCADE1UP website. In case of product defects or issues, ARCADE1UP offers customer support to assist you. Additionally, purchases often include a 30-day easy return policy. For returns or further assistance, please contact the

retailer or ARCADE1UP customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question