

[Manuals.plus](#) /

› [Vileda](#) /

› Vileda Classic Ironing Board with Reversible Iron Rest | User Manual

## Vileda 174223

# Vileda Classic Ironing Board User Manual

Model: 174223

## 1. INTRODUCTION

Thank you for choosing the Vileda Classic Ironing Board. This manual provides essential information for the safe and efficient use, setup, and maintenance of your ironing board. Please read these instructions carefully before first use and retain them for future reference.



Image 1.1: Vileda Classic Ironing Board, showcasing its design and features.

The Vileda Classic ironing board is designed to make ironing comfortable and efficient. Its stable and compact design ensures ease of use and storage.

## 2. SAFETY INFORMATION

- Always ensure the ironing board is placed on a stable, flat, and non-slip surface before use.
- Do not overload the ironing board or the iron rest.
- Keep children and pets away from the ironing board during use and when it is hot.
- Always unplug the iron and allow it to cool completely before storing the ironing board.
- Regularly check the ironing board for any signs of damage. Do not use if damaged.
- The ironing board features a **Kid Safe** locking mechanism to prevent accidental folding. Always engage this lock when the board is in use.



Image 2.1: Illustration of the 'Kid Safe' mechanism, requiring a pull and lift action to adjust or fold the board, enhancing safety.

## 3. SETUP

1. **Unpacking:** Carefully remove the ironing board from its packaging. Retain packaging for potential future transport or returns.
2. **Unfolding:** Place the ironing board on the floor. Release the transport lock (if present) and gently unfold the legs until they are fully extended and locked into position. Ensure the **Kid Safe** mechanism is engaged.
3. **Adjusting Height:** The Vileda Classic ironing board features adjustable height from 71 cm to 90 cm. To adjust, locate the height adjustment lever/mechanism (usually under the board or on one of the legs), activate it, and raise or lower the board to your desired comfortable ironing height. Ensure it locks securely into place before use.
4. **Iron Rest:** The ironing board includes a reversible iron rest. Position it according to your preference for left or right-handed use.



Image 3.1: The Vileda Classic Ironing Board fully set up, showing the iron rest in position.



Image 3.2: Detail of the reversible iron rest, designed to hold the iron securely and featuring a hook for hangers.

## 4. OPERATING INSTRUCTIONS

1. **Preparation:** Ensure the ironing board is stable and at a comfortable height. Place your iron on the designated iron rest.
2. **Ironing Surface:** The ironing surface measures 114 x 33 cm, providing ample space for various garments. The 100% cotton cover with sponge padding ensures good steam permeability for effective ironing.
3. **Non-Slip Feet:** The board is equipped with non-slip feet to enhance stability and prevent movement during ironing.
4. **After Use:** Once ironing is complete, unplug your iron and allow it to cool down.
5. **Folding for Storage:** To fold the board, disengage the height adjustment and **Kid Safe** lock, then carefully fold the legs. Secure with the transport lock if available. The compact design allows for easy storage.




Image 4.1: Diagram showing the non-slip feet of the ironing board, designed to provide enhanced stability during use.

## 5. MAINTENANCE

- **Cleaning the Cover:** The 100% cotton ironing board cover can be removed and cleaned according to its care label. Allow it to dry completely before reattaching.
- **Frame Cleaning:** Wipe the metal frame with a damp cloth and mild detergent if necessary. Dry thoroughly.
- **Storage:** Store the ironing board in a dry place, away from direct sunlight and extreme temperatures. Its space-saving design makes it easy to store in small areas.
- **Inspection:** Periodically inspect all parts for wear and tear, especially the leg joints and the cover. Replace the cover if it becomes worn or damaged to maintain optimal ironing performance.

## 6. TROUBLESHOOTING

- **Board is unstable:** Ensure all legs are fully extended and locked into their positions. Check that the height adjustment mechanism is securely engaged. Make sure the board is on a flat, even surface.
- **Difficulty adjusting height:** Ensure the adjustment lever/mechanism is fully disengaged before attempting to change height. Do not force the mechanism.
- **Iron rest feels loose:** Verify that the iron rest is correctly attached and secured to the board.

## 7. SPECIFICATIONS

| Feature                    | Detail                                                                  |
|----------------------------|-------------------------------------------------------------------------|
| Model Number               | 174223                                                                  |
| Ironing Surface Dimensions | 114 x 33 cm                                                             |
| Adjustable Height          | 71 cm to 90 cm                                                          |
| Item Weight                | 4.6 Kilograms                                                           |
| Cover Material             | 100% Cotton with sponge padding                                         |
| Frame Material             | Metal                                                                   |
| Color                      | Light Blue                                                              |
| Special Features           | Reversible iron rest, Kid Safe lock, Non-slip feet, Space-saving design |



Image 7.1: Visual representation of the ironing board's dimensions and adjustable height range.



Image 7.2: Indication that the product is Made in Italy.

## 8. WARRANTY AND SUPPORT

For warranty information, please refer to the specific terms and conditions provided at the point of purchase or on the

Vileda official website. Warranty periods may vary by region.  
For product support, spare parts, or any inquiries, please contact the manufacturer directly:

**FHP di R. Freudenberg s.a.s.**  
Via dei Valtorta 48

20127 Milano

Italy

Please have your model number (174223) and purchase details ready when contacting support.

© 2026 Vileda. All rights reserved.

**ASK A QUESTION ABOUT THIS MANUAL**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question