

[Manuals.plus](#) /

› [DWaybox](#) /

› DWaybox Protective Case for TCL Tab 10 Gen 2 10.36 inch User Manual

DWaybox TCL Tab 10 Gen 2 10.36 inch

DWaybox Protective Case for TCL Tab 10 Gen 2 10.36 inch User Manual

Model: TCL Tab 10 Gen 2 10.36 inch (8496G)

1. INTRODUCTION

Thank you for choosing the DWaybox Protective Case for your TCL Tab 10 Gen 2 10.36 inch tablet. This manual provides essential information for the proper installation, operation, and maintenance of your new protective case. Please read it thoroughly before use.

1.1 Product Overview

This protective case is designed specifically for the TCL Tab 10 Gen 2 10.36 inch tablet (Model: 8496G) released in 2023. It is crafted from high-quality, environmentally friendly soft silicone material, offering excellent protection against accidental drops, scratches, shocks, and dust. The case features thickened corners for enhanced drop protection and a unique internal honeycomb design for improved heat dissipation. It also includes a built-in multi-angle kickstand for versatile viewing and typing positions.



Figure 1.1: Front and back view of the DWaybox Protective Case with a TCL Tab 10 Gen 2 tablet. The case is blue, showing the tablet screen on the front and the kickstand mechanism on the back.

1.2 Package Contents

- 1 x DWaybox Protective Case (Blue)
- 1 x DWAY Brand Stylus Pen

Free

2-in-1 Design

Stylus + Ballpoint Pen

Stylus Tip

Pen Tip



Figure 1.2: The DWAY brand stylus pen included with the protective case. This pen features both a stylus tip and a ballpoint pen tip.

2. SETUP AND INSTALLATION

Installing the DWaybox protective case is a simple process. Ensure your tablet is clean and free of dust before installation.

2.1 Compatibility Check

This case is **only compatible** with the TCL Tab 10 Gen 2 10.36 inch (Model: 8496G) released in 2023. It is not compatible with any other tablet models. Please verify your tablet's model number before proceeding.

2.2 Case Installation

1. Gently align your TCL Tab 10 Gen 2 tablet with the case, ensuring the camera and port cutouts match.
2. Carefully push the tablet into the soft silicone case, starting from one corner and working your way around. The flexible nature of the silicone allows for easy insertion.
3. Ensure all edges of the tablet are securely seated within the case's frame.
4. Verify that all buttons (volume, power) and ports (charger, headphone jack) are accessible and align correctly with

the case's precise cutouts.



Figure 2.1: The DWaybox case perfectly fitted onto the TCL Tab 10 Gen 2 tablet, highlighting the precise cutouts and secure fit.

3. OPERATING THE MULTI-ANGLE KICKSTAND

The integrated kickstand provides multiple viewing angles for enhanced usability, whether for media consumption, web browsing, or typing.

3.1 Extending the Kickstand

1. Locate the kickstand on the back of the case.
2. Gently pull the kickstand outwards from the designated slot until it clicks into an open position.
3. Adjust the kickstand to achieve your desired viewing or typing angle. The design allows for three stable positions.



Figure 3.1: Rear view of the case, illustrating the integrated kickstand in its retracted position.



Figure 3.2: Side profile of the case with the kickstand deployed, demonstrating a stable viewing angle.

3.2 Retracting the Kickstand

When not in use, the kickstand can be easily retracted to lay completely flat, adding no extra bulk to the case.

1. Gently push the kickstand back into its slot on the case.
2. Ensure it clicks securely into place, flush with the back surface of the case.

4. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your DWaybox protective case.

4.1 Cleaning Instructions

- To clean the silicone case, wipe it gently with a soft, damp cloth.
- For stubborn dirt, a mild soap solution can be used. Avoid harsh chemicals or abrasive cleaners, as these may damage the silicone material.
- Ensure the case is completely dry before re-installing your tablet.

4.2 Storage

Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

5. TROUBLESHOOTING

This section addresses common questions and minor issues you might encounter.

5.1 Case Does Not Fit My Tablet

- **Solution:** Verify your tablet's model number. This case is exclusively designed for the TCL Tab 10 Gen 2 10.36 inch (Model: 8496G) released in 2023. If your tablet is a different model, the case will not fit correctly.

5.2 Buttons or Ports Are Obstructed

- **Solution:** Ensure the tablet is properly seated within the case. Gently adjust the tablet until all cutouts align perfectly with the device's buttons, camera, and ports. The case is designed with precise cutouts for full accessibility.

5.3 Kickstand Feels Loose or Does Not Stay Open

- **Solution:** Ensure the kickstand is fully extended and clicked into one of its designated positions. If it still feels loose, inspect for any debris or damage in the hinge mechanism. Avoid excessive force when extending or retracting the kickstand.

6. PRODUCT SPECIFICATIONS

Attribute	Detail
Brand	DWaybox
Compatible Devices	TCL Tab 10 Gen 2 10.36 inch (Model: 8496G)
Material	Soft Silicone
Color	Blue
Special Features	Multi-Angle Kickstand, Shockproof, Kids Friendly, Precise Cutouts, Heat Dissipation Design
Product Dimensions	9.88 x 6.34 x 0.63 inches
Item Weight	14.1 ounces
Model Number	TCL Tab 10 Gen 2 10.36 inch
ASIN	B0CR8VPPDK

7. CUSTOMER SUPPORT

DWaybox is committed to ensuring your complete satisfaction. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact our professional service team.

We aim to resolve your inquiries and provide support within 24 hours.

Contact Information: Please refer to your purchase platform or packaging for direct contact methods, or send a message through the seller contact option on the platform where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question