Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

erjigo EDX Pro X

KZ EDX PRO X HiFi In-Ear Monitor Earbuds User Manual

Model: EDX Pro X

Introduction

Thank you for choosing the KZ EDX PRO X HiFi In-Ear Monitor Earbuds. This manual provides essential information for the proper setup, operation, and maintenance of your new audio device. Please read this manual thoroughly before use to ensure optimal performance and longevity of your earbuds.

What's in the Box

- KZ EDX PRO X In-Ear Monitor Earbuds (Left and Right)
- Detachable 0.75mm Pin Cable

Product Overview

The KZ EDX PRO X earbuds are designed for audiophiles, featuring a super-linear dynamic driver and professional acoustic tuning for rich, delicate sound and powerful bass. Their ergonomic design ensures comfortable wear, while the detachable cable offers versatility and extends product lifespan.



Image: The KZ EDX PRO X HiFi In-Ear Monitor Earbuds, showcasing their transparent design and detachable cable.

Key Features

- **Super-Linear Dynamic Driver:** Optimized internal structure for reduced sound distortion and broadened dynamic range, providing a richer, more delicate sound.



Image: An exploded view diagram illustrating the components of the Super-Linear Dynamic Driver, highlighting its optimized internal structure.

- **Excellent Resolution and Powerful Bass:** Advanced audio processing and precise acoustic design ensure accurate capture and presentation of each note, delivering deep and powerful bass.



Image: A close-up of the KZ EDX PRO X earbud, emphasizing its design for excellent sound detail resolution.

- **Professional Acoustic Tuning:** High-quality dynamic driver and precise acoustic chamber design provide superior audio performance across low, mid, and high frequencies.




Image: A frequency response graph demonstrating the professional acoustic tuning of the KZ EDX PRO X earbuds across the audible spectrum.

- **Classic Appearance Design:** Combines transparent resin and metal decoration for a lightweight, sturdy, and comfortable fit.



Image: A detailed view of the KZ EDX PRO X earbud, showcasing its classic transparent resin and metal design elements.

- **Sturdy, Ergonomic, and Interchangeable Cable:** The 0.75mm pin cable is detachable, allowing for easy replacement and enhanced sound quality, extending the earphone's lifespan.



Image: The KZ EDX PRO X earbud with its stable and sturdy 2-pin interchangeable cable, demonstrating the connection point.

Setup

1. **Connect the Cable to Earbuds:** Identify the left (L) and right (R) earbuds and the corresponding connectors on the cable. Gently align the 0.75mm pins on the cable with the sockets on the earbuds. Push firmly until they click into place. Ensure a secure connection to prevent signal loss.
2. **Connect to Audio Source:** Insert the 3.5mm jack of the cable into the audio output port of your device (e.g., smartphone, tablet, computer, audio player).

Operating Instructions

Wearing the Earbuds

1. Identify the left (L) and right (R) earbuds.
2. Gently insert each earbud into the corresponding ear canal. The cable is designed to loop over the top of your ear for a secure and comfortable fit. Adjust the earbud until it sits snugly and comfortably in your ear, creating a good

seal for optimal sound quality and passive noise isolation.

Media Control (if applicable)

If your cable includes an in-line remote, you can control media playback and calls:

- **Play/Pause:** Press the button once.
- **Next Track:** Press the button twice quickly.
- **Previous Track:** Press the button three times quickly.
- **Answer/End Call:** Press the button once during an incoming call or active call.
- **Reject Call:** Press and hold the button during an incoming call.

Maintenance

- **Cleaning:** Regularly clean the earbuds and ear tips with a soft, dry, lint-free cloth. For ear tips, you may use a slightly damp cloth with mild soap, then dry thoroughly before reattaching. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store your earbuds in a clean, dry place, preferably in a protective case, to prevent tangling and damage to the cable and earbuds.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable, especially near the connectors, to prevent internal wire damage.
- **Moisture:** Keep the earbuds away from excessive moisture and liquids. They are not water resistant.

Troubleshooting

Problem	Possible Cause	Solution
No sound or sound from one side	Loose cable connection, incorrect audio source, damaged cable/earbud.	Ensure cable is securely connected to both earbuds and the audio source. Test with another audio source or device. Check for visible damage to the cable or earbuds.
Poor sound quality (e.g., distorted, weak bass)	Improper fit, dirty ear tips, low quality audio file/source.	Adjust earbud fit to ensure a proper seal. Clean ear tips. Try a different audio file or source.
Cable detaches easily	Improper connection, worn connectors.	Ensure the cable is pushed firmly until it clicks. If issues persist, the cable or earbud connector may be worn and require replacement.

Specifications

Feature	Detail
Model Name	EDXPROX
Impedance	23 3
Sensitivity	108 3dB

Feature	Detail
Frequency Response Range	20-40000Hz
Plug Type	3.5mm
Pin Type	0.75mm
Wire Type	Flat transparent black cable
Wire Length	1205cm
Wearing Style	In-ear
Connectivity Technology	Wired
Material	Metal (housing)
Item Weight	70 Grams (approx. 2.47 ounces)
Water Resistance Level	Not Water Resistant
Control Type	Media Control (Remote)

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the manufacturer directly through their official website or customer service channels. Keep your proof of purchase for any warranty claims.

© 2025 erjigo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRB68886

More documents and user manuals: **https://manuals.plus/**