

[Manuals.plus](#) /

› [COLSUR](#) /

› COLSUR S29 Multi-Functional Device User Manual

COLSUR S29

COLSUR S29 Multi-Functional Device User Manual

Bluetooth Speaker, Wireless Charger, FM Radio, Dimmable LED Night Light, Digital Alarm Clock

INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your COLSUR S29 multi-functional device. This device integrates a Bluetooth speaker, FM radio, digital alarm clock, 15W wireless charger, and a dimmable LED night light. Please read this manual thoroughly before use to ensure proper functionality and to maximize your user experience.



Image: The COLSUR S29 device, showcasing its integrated features including the wireless charging pad, LED light bar, and digital display.

PACKAGE CONTENTS

Verify that all items are present in the package:

- COLSUR S29 Multi-Functional Device
- Power Adapter (Qualcomm Quick Charge 3.0 compatible)
- Type-C Data Cable
- User Manual (this document)

Multi-Functional Speakers



Image: The COLSUR S29 device, power adapter, and Type-C data cable, illustrating the items included in the package.

SETUP

Initial Charging and Power Connection

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Power:** Connect the provided Type-C data cable to the device's power input port and the other end to the

power adapter. Plug the adapter into a wall outlet.

3. **Initial Charge:** For first-time use, charge the device for at least 5 minutes to activate the internal battery. The device has a 2500mAh rechargeable battery.
4. **Placement:** Place the device on a stable, flat surface. Ensure the radio antenna (located at the bottom) is not obstructed for optimal FM reception.

Component Identification

Multi-Functional Speakers



Image: An exploded view of the COLSUR S29 device, highlighting the mobile phone wireless charging area, LED light bar, phone stand, Bluetooth speaker, FM radio, alarm clock display, power adapter, and Type-C data cable.

- **Mobile Phone Wireless Charging Area:** Top surface for wireless charging.
- **LED Light Bar:** Integrated light source with adjustable brightness.
- **Phone Stand:** Groove on top for holding a smartphone.
- **Bluetooth Speaker:** Fabric-wrapped speaker grille.
- **FM Radio:** Integrated function with external antenna.
- **Alarm Clock Display:** Front-facing LED digital time display.
- **Control Buttons:** Located on the top panel (e.g., D/SNOOZE, MODE, SWITCH, BT, FM, Volume +/-).
- **Silicone Pads:** On the bottom for stability.
- **Diffusion Holes:** On the bottom for sound and heat dissipation.
- **Radio Antenna:** Integrated into the bottom for FM reception.

OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the **POWER** button (if available, otherwise refer to the 'SWITCH' button for mode changes) to turn the device on or off. The digital display will illuminate upon power-on.

2. Setting the Time and Alarm

1. **Time Setting:** Press the **MODE** button until the time display flashes. Use the **Volume +/-** buttons to adjust hours and minutes. Press **MODE** again to confirm.
2. **Alarm Setting:** Press the **ALARM** button (or long-press **MODE** if no dedicated alarm button) until the alarm time flashes. Use **Volume +/-** to set the desired alarm time. Press **ALARM** (or **MODE**) again to confirm.
3. **Alarm Activation:** Ensure the alarm icon is displayed on the screen to confirm it is active.
4. **Snooze Function:** When the alarm sounds, short press the **D/SNOOZE** button to activate snooze for an additional 5 minutes.
5. **Alarm Deactivation:** To turn off the alarm, press any button other than **D/SNOOZE**, or let it ring for its full duration.

Surprisingly Loud Alarm Clock

16 precision volume levels, ideal for heavy sleepers



Volume 0-16 Levels

Big Snooze Function extra 5 mins



Image: The COLSUR S29 device on a bedside table, displaying the time and illustrating the snooze function for the alarm clock.

3. Bluetooth Speaker Mode

1. **Activate Bluetooth:** Press the **BT** button or cycle through modes using the **MODE** button until "BT" appears on the display. The device will enter pairing mode, indicated by a flashing Bluetooth icon.
2. **Pairing:** On your smartphone or other Bluetooth-enabled device, search for "COLSUR S29" (or similar name) in the Bluetooth settings and select it to pair. A confirmation sound will indicate successful pairing.

3. **Playback:** Once paired, you can play audio from your device through the COLSUR S29 speaker. Use the **Volume +/-** buttons on the COLSUR S29 or your connected device to adjust the volume (0-16 levels).
4. **Range:** The Bluetooth 5.0 connection offers a wireless range of up to 33 feet (10 meters).

Premium Material




Image: A person enjoying music from the COLSUR S29 Bluetooth speaker, illustrating its high-fidelity sound capabilities.

4. FM Radio Mode

1. **Activate FM Radio:** Press the **FM** button or cycle through modes using the **MODE** button until "FM" appears on the display.
2. **Auto Scan:** Long press the **FM** button to automatically scan and save available radio stations.
3. **Manual Tuning:** Short press the **Volume +/-** buttons to switch between saved stations.
4. **Volume Adjustment:** Use the **Volume +/-** buttons to adjust the radio volume (0-16 levels).
5. **Antenna:** Ensure the device is placed in an open area for optimal signal reception. The integrated antenna is located at the bottom.

FM Radio

Enjoy your Favorite Channel



Image: A person relaxing while listening to the COLSUR S29 FM radio, demonstrating the device's radio functionality and volume control.

5. Wireless Charging

1. **Power Requirement:** The wireless charging function requires the device to be connected to a power source via the provided adapter.
2. **Placement:** Place your Qi-compatible smartphone or AirPods on the designated wireless charging area on top of the device.

3. **Charging Indicator:** A charging indicator (e.g., a lightning bolt icon on your phone screen) will appear to confirm charging has begun.
4. **Compatibility:** Supports 15W fast wireless charging for compatible iOS and Android devices.
5. **Important Note:** For optimal charging, ensure your phone case is less than 5mm thick and does not contain metal, magnetic attachments, or credit cards.

High-Fidelity Sound Bluetooth Speaker

The greater wireless range of **33ft** provides a hearing feast exclusively for you.



 **2500mAh**
battery for long-lasting use

Image: A smartphone wirelessly charging on the COLSUR S29 device, demonstrating the charging function and its compatibility with various devices.

180° Adjustable Phone Holder



Image: A diagram illustrating the universal compatibility of the COLSUR S29 wireless charging feature with various iPhone, Samsung, and Google Pixel models, as well as AirPods. It also shows examples of phone cases that may interfere with charging (magnetic, phone holder, metal, credit card).

6. Dimmable LED Night Light

1. **Turn On/Off:** Press the **LIGHT** button (or a dedicated button for the LED light) to turn the night light on or off.
2. **Adjust Brightness:** Short press the **LIGHT** button repeatedly to cycle through 4 levels of brightness: Off, Dim, Medium, and High.



Image: A visual representation of the COLSUR S29's 4-level adjustable LED night light, showing the light bar in Off, Dim, Medium, and High brightness settings, with the digital clock display also adjusting brightness.

7. Phone Holder Function

The integrated groove on the top surface of the device serves as a phone stand, allowing you to prop up your smartphone for hands-free viewing while charging or listening to music. The phone holder is designed to be 180° adjustable for various viewing angles.



Image: A person exercising while using the COLSUR S29 as a phone holder, demonstrating the 180° adjustable phone stand feature.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Liquid Exposure:** Avoid exposing the device to water or excessive moisture. If liquid spills on the device, immediately disconnect power and allow it to dry completely before reuse.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, especially if not used for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery or no power connection.	Connect the device to power using the provided adapter and cable. Ensure the power outlet is functional. Charge for at least 5 minutes.
Wireless charging not working.	Device not connected to power; phone case too thick or contains metal; phone not Qi-compatible; phone misaligned.	Ensure the device is plugged in. Remove phone case or any metallic objects. Reposition the phone on the charging pad. Verify phone supports Qi wireless charging.
Bluetooth speaker not pairing.	Device not in pairing mode; Bluetooth disabled on source device; too far from source device; interference.	Ensure the COLSUR S29 is in Bluetooth pairing mode ("BT" flashing). Enable Bluetooth on your source device. Move closer to the speaker (within 33ft). Disconnect other Bluetooth devices.
Poor FM radio reception.	Obstruction of antenna; weak signal in location.	Relocate the device to an open area, away from large metal objects or other electronics that may cause interference.
Alarm not sounding.	Alarm not set or activated; volume too low.	Verify the alarm time is set correctly and the alarm icon is displayed. Increase the device volume.

SPECIFICATIONS

Brand	COLSUR
Model Number	S29

Display Type	Digital LED
Connectivity Technology	Bluetooth 5.0, Wireless
Wireless Charging Output	15W (Max)
Battery Capacity	2500mAh
LED Light Brightness Levels	4 (Off, Dim, Medium, High)
Speaker Features	Dual Speakers, Rich Bass, 33ft Wireless Range
Alarm Clock Features	Adjustable Volume (0-16 levels), Dual Snooze Mode
Power Source	Battery Powered, Electrical (via Type-C)
Product Dimensions	7.8"W x 2"H (approximate)
Item Weight	2.31 pounds
Material	Acrylonitrile Butadiene Styrene (ABS)

WARRANTY AND SUPPORT

COLSUR products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included with your purchase or visit the official COLSUR website. If you encounter any issues or require technical assistance, please contact COLSUR customer support through the contact information provided on the product packaging or the official website.

Note: Please charge the product for 5 minutes when you first receive it.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CRB7ZYSB>

More documents and user manuals: <https://manuals.plus/>