

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Dwi Dowellin](#) /

> [Dwi Dowellin 28" Ejection & Shooting Transport Truck Toy User Manual](#)

Dwi Dowellin E7020

Dwi Dowellin 28" Ejection & Shooting Transport Truck Toy User Manual

Model: E7020

1. INTRODUCTION

Thank you for choosing the Dwi Dowellin 28" Ejection & Shooting Transport Truck Toy. This versatile toy offers multiple play modes, including a large transport truck, racing car launcher, and foam ball shooter, complete with lights and sounds. This manual provides essential information for safe assembly, operation, and maintenance to ensure an enjoyable experience.

2. WHAT'S IN THE BOX

Please check the contents of your package against the list below:

- 1 x Large Ejection Transport Truck
- 4 x Ejection Alloy Racing Cars
- 6 x EVA Soft & Safe Foam Balls
- 1 x 360-degree Launcher Mechanism
- 1 x Sheet of Truck Stickers
- 1 x Product Manual



Image: All components included in the Dwi Dowellin Truck Toy set.

3. SAFETY INFORMATION

- **CHOKING HAZARD:** Small parts. Not suitable for children under 3 years. Adult supervision is recommended during play.
- The toy is made from ABS high-grade plastic material, is BPA Free, Phthalate Free, and Lead Free.
- Features water-based paint and polished smooth edges and corners for secure use.
- Ensure all parts are securely assembled before play.



Image: Child playing with the truck, highlighting the toy's safety features.

4. SETUP

4.1 Assembly

1. Unpack all components from the box.
2. Attach the launcher mechanism to the rear section of the transport truck. Ensure it clicks securely into place.
3. Extend the racing track from the truck's body by pulling it outwards until it locks.
4. Apply the included stickers to the truck and cars as desired for customization.

Put the Ball/Car into the launcher



Adjusting the angle



Pull the handle back and launch



Image: Visual guide for loading and launching, illustrating parts of the assembly.

4.2 Battery Installation

Locate the battery compartment on the underside of the truck's cab. Use a screwdriver to open the compartment, insert the required batteries (not included), and close the compartment securely. This powers the lights and sounds.

5. OPERATING INSTRUCTIONS

5.1 Sound and Light Functions

Press the buttons located on the top of the truck's cab to activate various sounds and turn on the headlights. These features enhance imaginative play and provide auditory and visual stimulation.

Multiple Mode



Opening/Closing Doors



Musical Sounds



LED Lights

Image: Truck cab with buttons for sounds and lights.

5.2 Ejection/Shooting Mode (Foam Balls)

1. Load the EVA foam balls into the transparent tube of the launcher.
2. Adjust the angle of the launcher to aim.
3. Pull the red handle back firmly to eject the foam balls.

5.3 Ejection/Shooting Mode (Racing Cars)

1. Place one of the alloy racing cars into the designated slot on the launcher.
2. Adjust the angle of the launcher.
3. Pull the red handle back firmly to eject the racing car.



Image: The truck in action, shooting balls and launching cars.

5.4 Racing Mode

1. Extend the racing track from the truck.
2. Place racing cars at the starting line of the track.
3. Use the integrated launch mechanism to send the cars racing down the track.



Image: The truck configured for racing mode with cars on the track.

5.5 Official Product Video

Your browser does not support the video tag.

Video: An official demonstration of the Dwi Dowellin Truck Toy's features, including car and ball launching, and truck deformation.

6. MAINTENANCE

- **Cleaning:** Wipe the toy with a soft, damp cloth. Do not immerse in water.
- **Storage:** Store the toy and its accessories in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

- **No Sound or Lights:** Ensure batteries are correctly installed and are not depleted. Replace with fresh batteries if necessary.
- **Balls/Cars Not Launching Effectively:**
 - a. Verify that the launcher handle is pulled back completely before release.
 - b. Check for any obstructions in the launching mechanism or tube.
 - c. Ensure balls and cars are loaded correctly into their respective slots.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	28 x 4 x 7.7 inches
Item Weight	2.29 pounds
Item Model Number	E7020
Manufacturer Recommended Age	36 months - 17 years
Manufacturer	SHANTOU CITY CHENGHAI DISTRICT WEIFENGDA TOYS FACTORY

9. WARRANTY AND SUPPORT

Your Dwi Dowellin Truck Toy comes with a worry-free 12-month warranty. If you encounter any issues or have questions regarding your product, please contact the seller or manufacturer for assistance. Please refer to your purchase documentation for specific contact details.