



Manuals.plus /

› SOWO /

› SOWO Portable Bluetooth Speaker Instruction Manual

**SOWO 203e685f-c2ea-4e9c-8ff1-124252362457**

# SOWO Portable Bluetooth Speaker Instruction Manual

Model: 203e685f-c2ea-4e9c-8ff1-124252362457

## INTRODUCTION

---

Thank you for choosing the SOWO Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Designed for powerful sound and durability, this speaker is perfect for outdoor adventures, parties, and everyday use.

## WHAT'S IN THE BOX

---

- SOWO Portable Bluetooth Speaker
- Charging Cable (USB-C)
- Buckle/Carabiner
- User Guide
- Storage Bag



The SOWO Portable Bluetooth Speaker and its included accessories.

# PLAY, TRAVEL WITH THE **CONCERT HALL**



Detailed view of the speaker's packaging and all items included in the box, including the storage bag and charging cable.

## SETUP

### Charging the Speaker

Before first use, fully charge the speaker. The speaker features a port coverless waterproof design, meaning the charging port is waterproof even when exposed. This allows for easier use while charging without worrying about water damage.

- Connect the provided USB-C charging cable to the speaker's charging port.
- Connect the other end of the cable to a compatible USB power adapter (not included).
- A full charge takes approximately 2.5 hours and provides up to 16 hours of playtime.

# SIZE REFERENCE



The speaker's USB-C charging port, designed to be waterproof even when exposed.

# PARTYBOOM TO MAKE SURROUND SOUND

*Supports connecting two or more speakers*



The speaker offers an impressive 16 hours of playtime on a single charge, ideal for extended use.

Official SOWO video demonstrating how to use the Soundwave Pro speaker, including charging and basic operation.

## Powering On/Off

- To power on: Press and hold the power button (usually marked with a circle or universal power symbol) for 3 seconds until you hear an audible prompt.
- To power off: Press and hold the power button for 3 seconds until you hear an audible prompt.

## Bluetooth Pairing

The SOWO speaker uses Bluetooth 5.3 for stable and reliable connectivity.

- Ensure the speaker is powered on and in pairing mode (indicated by a flashing blue LED).
- On your mobile device, enable Bluetooth and search for available devices.
- Select "Soundwave Pro" from the list of devices to connect.
- Once connected, you will hear a confirmation sound, and the LED indicator will turn solid blue.

## OPERATING INSTRUCTIONS

---

### Basic Controls

The speaker features intuitive button controls located on its top surface.

Button	Function
Power Button	Press and hold to Power On/Off. Short press to check battery status.
Volume +	Increase volume.
Volume -	Decrease volume.
Play/Pause	Play or pause audio.
Partyboom Button	Activate True Wireless Stereo (TWS) pairing.
Microphone	Built-in for hands-free calls.

# 16 HOURS OF PLAYTIME



Top view of the speaker showing the control buttons for power, volume, playback, and Partyboom functionality.

## Partyboom Technology (True Wireless Stereo)

Enhance your audio experience by pairing two or more SOWO speakers together for true stereo sound or a more dynamic music party.

- Ensure both (or multiple) speakers are powered on and not connected to any other Bluetooth devices.
- On the primary speaker, long press the Partyboom button for 3 seconds.
- On the secondary speaker(s), briefly press the Partyboom button.
- Wait for approximately 6 seconds for the speakers to connect. The interconnect light will turn orange and remain on once connected.
- Pair your phone's Bluetooth with the primary speaker.

# Contrast with hand-held speakers

## Soundwave Pro



✓ Volume	Loud
✓ Size	Small
✓ Weight	Light
✓ Battery life	16H+
✓ Hooking	Portable

## Other portable speakers



! Volume	Loud
! Size	Big
! Weight	Sink
! Battery life	12H+
! Carry	Inconvenient

Two SOWO speakers paired together using Partyboom Technology for an immersive surround sound experience.

Official SOWO video demonstrating how to use the Soundwave Pro speaker, including TWS pairing for multiple speakers.

## Sound Adjustment & Placement

The speaker's design allows for flexible sound projection:

- When placed upright, the sound is more focused, ideal for personal listening.
- When laid flat on its back, the sound is balanced in 360 degrees, perfect for filling a room or outdoor space.

# COVERLESS AND IP67 FULLY WATERPROOF DESIGN



**No PLUG, WATERPROOF AND MORE CONVENIENT**

Diagram illustrating the speaker's internal tweeter and woofer components, which contribute to its powerful bass and clear sound.

## Portability

The SOWO speaker is designed for easy transport and use anywhere.

- It features a portable rope and clip, allowing you to attach it to backpacks, tents, or bikes.
- Its compact size and lightweight design make it ideal for travel, camping, and outdoor activities.

# CLEAREST AND AMAZING BASS



## High Frequency Clarity

## Low Frequency Enhancement

The speaker features a convenient carabiner clip, allowing it to be easily attached to bags or other gear for portability.

## MAINTENANCE

---

### Cleaning

To clean your speaker, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface.

### Waterproofing

While the speaker is IP67 waterproof, ensure the charging port is free of debris before charging. Do not submerge the speaker for extended periods or expose it to high-pressure water jets.

## TROUBLESHOOTING

---

### No Power

- Ensure the speaker is fully charged.
- Press and hold the power button for 3 seconds to turn on.

## No Bluetooth Connection

- Ensure the speaker is in pairing mode (flashing blue LED).
- Turn off and on your device's Bluetooth.
- Make sure the speaker is not connected to another device.
- Move your device closer to the speaker.

## Poor Sound Quality

- Ensure your audio source is playing high-quality audio.
- Adjust the speaker's placement for optimal sound projection (upright for focused, flat for 360-degree).
- Check for any physical obstructions blocking the speaker's output.

## SPECIFICATIONS

Feature	Detail
Brand	SOWO
Model Name	portable speaker
Speaker Type	Outdoor
Special Feature	Bass Boost
Connectivity Technology	Bluetooth 5.3
Wireless Communication Technology	Bluetooth
Water Resistance Level	IP67 Waterproof
Battery Life	16 Hours
Charging Time	2.5 Hours
Speaker Maximum Output Power	50 Watts
Frequency Response	20 KHz
Signal-to-Noise Ratio	80 dB
Item Weight	1.1 Pounds
Product Dimensions	7.8"D x 3.5"W x 2.1"H
Included Components	charging cable, buckle, User Guide, storage bag

## WARRANTY & SUPPORT

This SOWO Portable Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information, troubleshooting beyond this manual, or technical support, please refer to the official User Guide PDF available at <https://m.media-amazon.com/images/I/B19e-17kJZL.pdf> or contact SOWO customer service.

