

- Manuals.plus /
- › SUDOTACK /
- › SUDOTACK Ultrafit Wireless Open Ear Headphones Instruction Manual

SUDOTACK Ultrafit

SUDOTACK Ultrafit Wireless Open Ear Headphones Instruction Manual

Model: Ultrafit | Brand: SUDOTACK

INTRODUCTION

The SUDOTACK Ultrafit Wireless Open Ear Headphones are designed for comfort and awareness, allowing you to enjoy audio while remaining connected to your surroundings. Featuring a non-intrusive design and soft ear hooks, these headphones provide a secure and stable fit for various activities, including workouts and running. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your headphones.



Figure 1: SUDOTACK Ultrafit Wireless Open Ear Headphones and Charging Case

WHAT'S IN THE BOX

- SUDOTACK Ultrafit Wireless Open Ear Headphones (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual

PRODUCT FEATURES

Ultra-Comfortable and Secure Fit

The Ultrafit headphones feature a non-intrusive design with soft, skin-friendly ear hooks that fit gently and securely around your ears without entering the ear canal. This design reduces stress and the risk of hearing loss from extended wear, ensuring comfort and stability even during exercise.

TRUE OPEN WIRELESS EARBUDS

Non-Intrusive design with Air conduction technology



Figure 2: Earbud design for ultimate comfort and skin-friendly silicone.

NONSTOP AWARENESS

Connect all your sound worlds and keep aware of your surrounding



Work with Most Eyeglasses




Figure 3: Secure fit for active use.

Enhanced Awareness

Open-ear headphones keep your ears open to ambient sounds, such as traffic, voices, and other essential noises. This feature is crucial for outdoor activities like running or cycling, allowing you to stay aware of your surroundings for safety.

COMFORT TO WEAR ALL DAY

Conforms seamlessly to your ear structure



Ultimate
Comfort



Secure
Fit

Figure 4: Nonstop awareness for outdoor activities.

NONSTOP AWARENESS

Connect all your sound worlds and keep
aware of your surrounding



Light
Weight



Secure
Fit



Figure 5: Lightweight and secure fit for runners.

Extended Playtime & Digital Display

The charging case has a built-in 700mAh battery, providing up to 30 hours of continuous play with multiple charges. A single earphone offers over 7 hours of playtime. The digital display on the charging case indicates the remaining battery percentage.

DIRECTIONAL SOUND TRANSMISSION TECHNOLOGY

Close to the ear canal, forming an angle of less than 20°, maintaining high quality sound.



Figure 6: Battery life and charging case capacity.

UP TO **30** HOURS OF HEALTHY COMPANIONSHIP

Meet various sports companionship needs

30_H

with Charge Case

7_H

Single Earphone

700_{MAH}

Battery

Figure 7: Digital display on the charging case.

Immersive Sound & Clear Communication

Equipped with 16.2mm large carbon fiber dynamic drivers, these headphones deliver powerful bass, clear mids, and bright highs for a high-fidelity audio experience. The open-ear design allows for natural-sounding calls, as your ears remain open to your own voice and external sounds.

SECURE AND COMFORTABLE FIT

IPX5 waterproof, sports anytime, anywhere



Ultimate
Comfort



IPX 5

Figure 8: Superior audio sound quality with carbon fiber diaphragm.

IPX5 Water Resistance

The headphones are IPX5 water-resistant, making them suitable for sports and outdoor activities where they might be exposed to sweat or light rain.

		Earbuds	Bone conduction headphones
Wearing comfort			
Healthy			
Single battery life	7 HRS		
With charging case	30 HRS		
Barrier-free communication			

Figure 9: IPX5 waterproof rating for sports anytime, anywhere.

SETUP

Wearing Instructions

1. Hang the end of the headphone on your ear helix.
2. Turn the headphone and slide it behind the ear.
3. Adjust the ear hook for a secure and comfortable fit.

SKIN-FRIENDLY SILICONE MATERIAL

Ergonomic design



METAL CHARGING CASE

Adjust the ear hook for a secure and comfortable fit.



Figure 10: Proper wearing technique for optimal comfort and sound.

Bluetooth Pairing

To pair your headphones with a device:

1. Open the charging case. The headphones will automatically enter pairing mode.
2. On your device (e.g., smartphone, tablet), go to Bluetooth settings.
3. Select "SUDOTACK Ultrafit" from the list of available devices.
4. Once connected, the headphones are ready for use.

OPERATING INSTRUCTIONS

The SUDOTACK Ultrafit headphones feature intuitive touch controls on each earbud. Please note that you need to release your finger for every single tap.




Figure 11: Headphone controlling gestures.

Music Mode Controls

- **Play/Pause:** Tap 2 times (R headphone)
- **Previous Track:** Tap 3 times (L headphone)
- **Next Track:** Tap 3 times (R headphone)
- **Volume Down:** Tap and hold for 3 seconds (L headphone)
- **Volume Up:** Tap and hold for 3 seconds (R headphone)

Phone Mode Controls

- **Answer/Hang up calls:** Tap 2 times (L/R headphone)
- **Reject incoming call:** Tap and hold for 2 seconds

Other Modes

- **Activate Voice Assistant:** Tap 2 times (under non-call status)
- **Power On/Off:** Tap and hold for 6 seconds (without case)

MAINTENANCE

Cleaning

Regularly clean your headphones and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive materials or harsh chemicals.

Storage

When not in use, store the headphones in their charging case to protect them from dust, moisture, and physical damage. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your SUDOTACK Ultrafit headphones, please refer to the common problems and solutions below:

- **No Sound/Low Volume:**
 - Ensure the headphones are properly paired with your device.
 - Check the volume levels on both your headphones and your connected device.
 - Ensure the headphones are charged.
 - Some audio recordings may have lower volume or harsh high frequencies; this is due to the recording quality, not the headphones.
- **Pairing Issues:**
 - Make sure Bluetooth is enabled on your device.
 - Place the headphones back in the charging case, close the lid, and then open it again to re-enter pairing mode.
 - Forget the device from your phone's Bluetooth settings and try pairing again.
 - Ensure the headphones are fully charged.
- **Microphone Quality:**
 - The built-in microphone provides clear voice quality for calls and voice commands. Ensure the microphone is not obstructed.
- **Comfort:**
 - The open-ear design is intended for extended comfortable wear without ear fatigue. If discomfort occurs, re-adjust the ear hooks as per wearing instructions.

Official Product Video

Video 1: An overview and review of the SUDOTACK Ultrafit Air Conduction Open Ear Headphones, demonstrating features and discussing performance.

SPECIFICATIONS

Feature	Detail
Model Name	Ultrafit
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	Open Ear
Audio Driver Size	16.2 Millimeters
Battery Life (with case)	Up to 30 Hours
Battery Life (single earphone)	Over 7 Hours
Charging Case Battery	700mAh
Water Resistance Level	IPX5 (Water Resistant)
Bluetooth Range	10 Meters
Control Type	Touch Control, Volume Control, Remote
Material	Silicone
Item Weight	7 ounces
Manufacturer	SUDOTACK

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official SUDOTACK website. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CRDYKJWD>

More documents and user manuals: <https://manuals.plus/>