sweeek NILS

Sweeek NILS Scandinavian Chair Set - User Manual

Introduction

Welcome to your new Sweeek NILS Scandinavian Chair Set. This manual provides essential information for the assembly, proper use, and maintenance of your chairs to ensure their longevity and your enjoyment. Please read these instructions carefully before assembly and use.



Image: The Sweeek NILS Scandinavian Chair Set in a dining room environment.

Safety Warnings

WARNING: Do not use with a weight exceeding 110 kg (242 lbs) per chair. Exceeding this limit may cause damage to the chair or personal injury. Assemble all components carefully and securely following the instructions provided to ensure stability and safety.

This product is intended for domestic use only.

Package Contents

Please verify that all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 4 x NILS Chair Seats (Green Celadon Bouclette Upholstery)
- 4 x Sets of Beech Wood Legs
- Required Assembly Hardware (screws, washers, Allen key)
- Instruction Manual



Image: A complete set of four Sweeek NILS chairs.

Setup and Assembly

The Sweeek NILS chairs are designed for straightforward assembly. Follow these steps carefully to ensure correct and safe construction.

Tools Required

- Included Allen key
- (Optional) Phillips head screwdriver

Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface (e.g., a blanket or carpet) to prevent scratches or damage during assembly.
2. **Attach Legs to Seat Base:** Identify the beech wood leg base for one chair. Align the leg assembly with the pre-drilled holes on the underside of the chair seat. Ensure the orientation is correct, with the wider part of the seat facing forward.



Image: Underside of the chair showing the leg attachment points.

3. **Secure Legs:** Using the provided screws and Allen key, firmly attach each leg to the chair seat. Insert all screws loosely first, then gradually tighten them in a cross pattern to ensure even pressure. Do not overtighten initially.



Image: Detailed view of the leg attachment hardware.

4. **Final Tightening:** Once all legs are in place and partially tightened, go back and fully tighten all screws until secure. Ensure the chair is stable and does not wobble.
5. **Stability Check:** Gently rock the assembled chair to ensure stability. If it wobbles, slightly loosen all leg screws, apply even pressure to the seat, and then retighten the screws. Repeat for all four chairs.

Operating Instructions

The Sweeek NILS chair is designed for comfortable seating for one person in a domestic environment. Follow these guidelines for proper use.

Proper Use

- Always ensure the chair is placed on a flat, stable surface before use to prevent tipping.
- Sit centrally on the seat to distribute your weight evenly across the chair's structure.
- Avoid standing on the chair or using it as a step stool, as this can lead to instability and potential injury.
- Do not exceed the maximum weight capacity of 110 kg (242 lbs).

Maintenance

Regular and proper maintenance will help preserve the appearance and extend the life of your Sweeek NILS chairs.

Cleaning the Upholstery

The bouclette upholstery is designed for easy maintenance.

- **Regular Cleaning:** Vacuum the fabric regularly using an upholstery attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, gently blot the affected area immediately with a clean, dry cloth. Do not rub vigorously, as this can spread the stain or damage the fabric fibers. For stubborn stains, use a mild fabric cleaner diluted according to its instructions. Always test the cleaner on an inconspicuous area first to ensure it does not cause discoloration.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or strong solvents, as these can damage the fabric and its color.

Wood Frame Care

The beech wood legs require minimal care.

- Wipe wood surfaces with a soft, slightly damp cloth. Dry immediately with a clean, dry cloth to prevent water marks.
- Avoid prolonged exposure to direct sunlight or extreme humidity, which can cause wood to warp, crack, or fade.

Troubleshooting

Wobbly Chair

If your chair feels unstable or wobbly after assembly or prolonged use:

1. Check that all screws connecting the legs to the seat are fully tightened. Over time, screws may loosen and require re-tightening.
2. Place the chair on a flat, level surface. If it still wobbles, slightly loosen all leg screws, apply even downward pressure to the seat, and then retighten the screws in a cross pattern. This helps to settle the legs evenly.

Stains on Upholstery

For persistent stains on the bouclette upholstery:

1. Refer to the "Cleaning the Upholstery" section for detailed spot cleaning instructions.
2. If the stain persists after following the recommended cleaning methods, consider consulting a professional upholstery cleaner.

Specifications

Detailed technical specifications for the Sweeek NILS Scandinavian Chair.

Brand	sweeek

Model	NILS Scandinavian Chair
Color	Green Celadon
Material (Seat Shell)	Polypropylene
Material (Upholstery)	100% Polyester Bouclette (300 g/m²)
Material (Cushion Filling)	Foam (1.8 cm thick)
Material (Legs)	Beech Wood
Overall Dimensions (per chair)	47 cm (W) x 55 cm (D) x 81 cm (H)
Seat Dimensions	47 cm (W) x 43 cm (D)
Seat Height	42 cm
Backrest Dimensions	27 cm (W) x 39 cm (H)
Distance Between Legs	33.5 cm x 33 cm
Net Weight (per chair)	4.5 kg
Maximum Supported Weight	110 kg (242 lbs)
Usage	Domestic use only



Image: Dimensional drawing of the NILS chair.

Warranty and Support

Warranty Information

This Sweeek NILS Scandinavian Chair Set comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal domestic use. Please retain your proof of purchase for any warranty claims.

Customer Support

For any questions, missing parts, or assistance with assembly, maintenance, or warranty claims, please contact Sweeek customer support through your retailer or the official Sweeek website. Provide your product model (NILS) and proof of purchase when contacting support.