

Drsaec J53

Drsaec J53 Wireless Earbuds User Manual

Model: J53 | Brand: Drsaec

INTRODUCTION


Thank you for choosing the Drsaec J53 Wireless Earbuds. These earbuds feature advanced Bluetooth 5.3 technology and dual-channel transmission, providing a stable and fast audio experience. Designed for convenience, they offer automatic pairing and intuitive touch controls. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds to ensure optimal performance.

PACKAGE CONTENTS

Please check the box for the following items:

- Drsaec J53 Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- User Manual

PRODUCT OVERVIEW



The image displays the Drsaec J53 Wireless Earbuds in their open charging case. The earbuds are white with a sleek design, featuring blue light indicators and a fingerprint icon suggesting touch control. The charging case is also white and has a circular LED display on the front, showing '100' indicating full charge. The design emphasizes portability and ease of use.

The Drsaec J53 earbuds are designed for comfort and performance. They feature an in-ear form factor with a rounded tip for a secure fit. The compact charging case includes a digital LED display to show the battery level, ensuring you are always aware of your charge status. The earbuds are equipped with touch controls for easy management of audio playback and calls.

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the USB-C charging cable to the charging port on the case and a power source. The LED display on the case will indicate the charging progress. Ensure both earbuds are properly seated in the case during charging.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "J53" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds support automatic re-connection to the last paired device once taken out of the case.

OPERATING INSTRUCTIONS

Touch Controls

The Drsaec J53 earbuds feature intuitive touch controls on each earbud. Specific gestures may vary slightly, but common functions include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Control:** (If supported) Long press on left/right earbud to decrease/increase volume. Refer to specific product documentation for exact volume control gestures.

Power On/Off

The earbuds automatically power on when removed from the charging case and power off when placed back into the case and the lid is closed.

MAINTENANCE

To ensure the longevity and optimal performance of your Drsaec J53 Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals. Gently clean the charging contacts on both the earbuds and the case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. While suitable for sports and light rain, avoid prolonged submersion or exposure to saltwater or other liquids. Ensure earbuds are dry before placing them back in the charging case.
- **Charging:** Use the provided USB-C cable for charging. Avoid using damaged cables or chargers. Do not overcharge the device.

TROUBLESHOOTING

If you encounter issues with your Drsaec J53 Wireless Earbuds, try the following troubleshooting steps:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place earbuds back in the case, close the lid, then open again. Turn off and on Bluetooth on your device. Forget "J53" from your device's Bluetooth list and re-pair.
No sound or low volume	Check the volume level on both your device and the earbuds. Ensure earbuds are properly connected to your device. Clean any debris from the earbud speakers.
Earbuds not charging	Ensure the charging cable is securely connected. Check if the charging case has power. Clean the charging contacts on both earbuds and case.
Connection unstable/dropping	Ensure your device is within the 10-meter Bluetooth range. Avoid obstacles between the earbuds and your device. Minimize interference from other wireless devices.

SPECIFICATIONS

Feature	Detail
Model Name	J53
Connectivity Technology	Wireless
Wireless Communication	Bluetooth 5.3
Bluetooth Range	10 Meters
Water Resistance Level	IP7 Waterproof

Feature	Detail
Control Method	Touch
Frequency Range	20 Hz - 20,000 Hz
Item Weight	3.2 ounces
Package Dimensions	4.37 x 3.19 x 1.54 inches
Batteries	2 Lithium Polymer batteries (included)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included in your product packaging or contact Drsaec customer service through the official brand website or your point of purchase. Please have your model number (J53) and purchase details ready when contacting support.

© 2024 Drsaec. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

