CIVYPRO BK-506

CIVYPRO BK-506 Electric Callus Remover Refill Rollers Instruction Manual

Introduction

This manual provides essential instructions for the proper installation, use, and maintenance of your CIVYPRO BK-506 Electric Callus Remover Refill Rollers. These rollers are designed as direct replacements for the original grinding heads of the CIVYPRO BK-506 Electric Callus Remover device.

The package includes three different coarse levels to address various foot care needs:

- **Extra Coarse:** For effectively removing tough, hard, and cracked skin.
- **Regular Coarse:** Ideal for softening and smoothing regular hard skin.
- **Gentle Coarse:** Suitable for daily maintenance and achieving a perfect finishing touch.



Image: Three CIVYPRO refill rollers, each with a textured surface, ready for installation.



Image: The CIVYPRO BK-506 Electric Callus Remover device displayed alongside three compatible refill rollers, highlighting their perfect fit.

Setup: Roller Installation

Follow these steps to replace the refill rollers on your CIVYPRO BK-506 Electric Callus Remover:

1. **Ensure the device is off:** Before attempting to remove or install a roller, confirm that the callus remover is turned off to prevent accidental activation.
2. **Remove the old roller:** With one hand, hold down the release button located on the right side of the device. With your other hand, gently lift the right side of the roller to detach and remove it.
3. **Install the new roller:** Select the desired refill roller. Place one side of the new roller into its corresponding groove on the device. Ensure it is properly seated. Then, press the other side of the roller firmly into place until you hear a distinct clicking sound, indicating it is securely locked.

Important Notice: Always check that the roller head is securely attached to the device before use to ensure safe and

effective operation.



Image: A visual guide demonstrating the three steps for replacing the refill roller: turning off the device, removing the old roller, and installing the new one.

Operating: Roller Types and Usage

The CIVYPRO BK-506 refill rollers offer varying levels of coarseness to cater to different skin conditions. Choose the appropriate roller for your specific needs:

- **Extra Coarse Roller:** Best for significant callus removal and very hard, cracked skin.
- **Regular Coarse Roller:** Suitable for general dead skin removal and smoothing moderately hard skin.
- **Gentle Coarse Roller:** Ideal for light exfoliation, daily maintenance, and finishing touches to achieve smooth skin.

When using the device with the chosen roller, apply gentle pressure and move it over the desired area. Avoid excessive pressure or prolonged use in one spot to prevent skin irritation. The rollers are designed to safely and effectively remove rough skin, leaving your feet smooth and clean.



Image: Detailed views of the three distinct quartz sand roller heads, illustrating their varying textures for different coarseness levels.



Image: Visual comparison of skin conditions before and after using the Gentle Coarse, Regular Coarse, and Extra Coarse rollers, showing their respective results.

Maintenance: Cleaning and Replacement

Proper maintenance of your refill rollers ensures optimal performance and hygiene:

- **Cleaning:** The rollers are washable and reusable. After each use, remove the roller from the device and rinse it under running water. You may use a small brush (not included) to gently scrub away any accumulated skin particles. Allow the roller to air dry completely before reattaching it to the device or storing it.
- **Replacement:** We recommend changing the roller of your callus remover as needed for best results. The lifespan of a roller head depends on the frequency of use and the amount of skin removed. Replace rollers when they show signs of wear, such as reduced effectiveness or visible damage to the abrasive surface.



Image: Visual instructions for cleaning the refill rollers, showing them being rinsed under water and scrubbed with a small brush.

Troubleshooting

If you encounter any issues with your refill rollers, consider the following:

- **Roller not fitting securely:** Ensure you are using the correct replacement rollers for model BK-506. These rollers are specifically designed for the CIVYPRO BK-506 and are not compatible with other models like V-601. Double-check that both sides of the roller are properly aligned and pressed firmly until a click is heard during installation.
- **Reduced effectiveness:** If the roller is not removing skin as effectively as before, it may be worn out and require replacement. Ensure the roller is clean and free of debris.

Specifications

Feature	Detail

Brand	CIVYPRO
Model Compatibility	BK-506 Electric Callus Remover
Material	Acrylonitrile Butadiene Styrene (ABS)
Coarseness Levels	Extra Coarse, Regular Coarse, Gentle Coarse
Item Weight (per roller)	Approximately 0.05 Kilograms (1.76 ounces for package of 3)
Package Dimensions	5.51 x 3.19 x 1.22 inches

Support

If you have any questions or require further assistance with your CIVYPRO BK-506 Electric Callus Remover Refill Rollers, please contact the CIVYPRO customer support team. They are available to provide satisfactory solutions to any concerns you may have.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question