

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Rolosar](#) /
- › [Rolosar Q76 Wireless Earbuds User Manual](#)

Rolosar Q76

Rolosar Q76 Wireless Earbuds

USER MANUAL

1. Introduction

Thank you for choosing the Rolosar Q76 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.4 connectivity, ENC noise canceling for clear calls, IP7 waterproof rating, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Figure 1.1: Rolosar Q76 Wireless Earbuds and Charging Case.

2. What's in the Box

- Rolosar Q76 Wireless Earbuds (Left & Right)
- Charging Case
- USB-C Charging Cable
- Ear Tips (S/M/L sizes)
- User Manual

3. Setup

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the charging port on the case and a power source. The LED display on the case will indicate the charging status and battery level.

50H LONG PLAYTIME



Figure 3.1: Battery Life and Charging Information.

- **Earbud Playtime:** Approximately 10 hours on a single charge.
- **Total Playtime (with case):** Up to 50 hours.
- **Earbud Charging Time:** Approximately 1.5 hours.
- **Case Charging Time:** Approximately 2 hours.

3.2 Pairing with Your Device

The Rolosar Q76 earbuds feature one-step auto pairing for convenience.

1. Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Q76" from the list of found devices to complete the pairing process.

2024 Bluetooth 5.4

ONE STEP AUTO PAIRING

Step1: Open the lid (Earbuds auto power on)

Step2: After open the Phone Bluetooth, Click the <Q76> to Pairing



Figure 3.2: Bluetooth Pairing Steps.

3.3 Wearing the Earbuds

For optimal comfort and sound quality, ensure the earbuds are worn correctly. The flexible earhooks provide a secure fit, especially during sports activities.

1. Choose the right size ear tips (S/M/L) for a snug fit.
2. Place the earhook over your ear.
3. Rotate and adjust the earbud to a comfortable angle within your ear canal.

Designed for sports Earhooks Design

Comfortable, firm, not easy to fall off



- 1 Choose the right size ear caps.
- 2 Place the earhook over your ear.
- 3 Rotate and adjust to a comfortable angle.

Figure 3.3: Earbud Wearing Guide.

4. Operating the Earbuds

4.1 Smart Touch Controls

The Rolosar Q76 earbuds feature high-sensitivity smart touch controls located on the upper part of the earphone surface. Refer to the diagram below for specific functions:

SMART TOUCH CONTROL

High-sensitivity smart touch brings easy operation



Figure 4.1: Smart Touch Control Functions.

- **Play/Pause Music:** Single tap on either earbud.
- **Next Song:** Double tap on the right earbud.
- **Previous Song:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold on either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold on either earbud for 3 seconds.
- **Power On/Off:** Earbuds power on automatically when removed from case and off when placed back. Manual power on/off may be available via long press if not connected.

5. Maintenance

5.1 Cleaning

Regular cleaning helps maintain the performance and hygiene of your earbuds.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Use a cotton swab or small brush to carefully clean the charging contacts on both the earbuds and the case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

5.2 Water Resistance (IP7)

The Rolosar Q76 earbuds are rated IP7 waterproof, meaning they can resist sweat, rain, and minor water splashes. They are suitable for workouts and outdoor activities.



Figure 5.1: IPX7 Waterproof Feature.

- Do not submerge the earbuds in water for extended periods.
- Ensure the charging port is dry before charging to prevent damage.

- The charging case is not waterproof.

5.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

6. Troubleshooting

If you encounter any issues with your Rolosar Q76 earbuds, please refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds not pairing	Bluetooth off on device; earbuds not in pairing mode; interference.	Ensure Bluetooth is on. Place earbuds in case, close, then open lid. Move closer to device. Try unpairing and re-pairing.
No sound from one earbud	Low battery; earbud not connected; mono mode.	Charge both earbuds. Re-pair. Check device settings for mono/stereo output.
Charging issue	Dirty charging contacts; faulty cable/adapter.	Clean charging contacts. Try a different USB-C cable and power adapter.
Touch controls unresponsive	Incorrect touch area; temporary glitch.	Ensure you are touching the correct area. Place earbuds back in case, close, then reopen to reset.

6.1 Factory Reset

If issues persist, a factory reset may resolve them. Consult the product's official support page or contact customer service for specific reset instructions, as this can vary by model.

7. Specifications

Detailed technical specifications for the Rolosar Q76 Wireless Earbuds:

Parameter :

Model : Q76
Play Time : 8-10H (Headset) over 50H (Charging Case)
Charging Time : 1.5H (Headset) 2H (Charging Case)
Impedance : 32 Ω
Frequency Range : 2.402-2.480GHz
Wireless Transmit Power : -10~10dbm
Battery : 50MAH (Headset) 500MAH (Charging Case)
Input : 5V/500mA
Output : 5V/50mA*2

标签粘贴区域

Product
Color



Producer Name : Dongguan Huien Electronic Technology Co., Ltd
Address : China,Guangdong ,Dongguan , Changping Town,
Changdong Road, No. 429
Name : Lu Zhonghui
Phone : +86-189-0795-3291

Figure 7.1: Product Parameters from Packaging.

Feature	Detail
Model	Q76
Connectivity Technology	Wireless (Bluetooth 5.4)
Earbud Playtime	Approx. 10 hours
Total Playtime (with case)	Approx. 50 hours
Earbud Charging Time	Approx. 1.5 hours
Case Charging Time	Approx. 2 hours
Waterproof Rating	IP7
Driver Size	14.2mm (Double-layer diaphragm)

Feature	Detail
Microphone	Built-in with ENC Noise Canceling
Control Method	Touch, Voice
Product Dimensions	1.57 x 0.79 x 1.97 inches
Item Weight	5 ounces
Battery Type	Lithium Polymer (included)

8. Warranty and Support

Rolosar provides comprehensive support for its products.

8.1 Warranty Information

Your Rolosar Q76 Wireless Earbuds come with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.



Figure 8.1: Warranty and Customer Service Commitment.

8.2 Customer Support

For technical assistance, warranty claims, or any other inquiries, please contact our customer service team. We aim to provide a **24-hour customer service response**.




Figure 8.2: Regulatory Representative Contact Information.

UK Representative:

CYRUS-Consulting Ltd

Address: 40 Sheepcote Drive, Rugby, England, CV239 FG

E-mail: manager@cyrus-consultingltd.co.uk

Tel: +44 7763 280 902

EC Representative:

eVatmaster Consulting GmbH

Address: Bettinastr.30, 60325 Frankfurt am Main, Germany

Email: contact@evatmaster.com

WARNING!!! Do not disassemble, hit, or burn the device.

8.3 Compliance Information

This device complies with relevant regulatory standards.



Figure 8.3: Regulatory Compliance Markings.

FCC ID: 2A2BYHE-057

IC: 29990-Q76

Made in: China