azwok ARC452A21

azwok Replacement Remote Control User Manual for Daikin Air Conditioners (ARC452A21 Series)

Model: ARC452A21

1. Introduction

This manual provides comprehensive instructions for the azwok ARC452A21 replacement remote control, designed to operate various Daikin air conditioner models. It covers essential information regarding setup, operation, and maintenance to ensure optimal performance and longevity of your remote control.

This remote control is an infrared device and does not support voice control functions.

2. Product Overview

The azwok ARC452A21 is a high-quality replacement remote control that replicates the primary buttons and functions of the original Daikin ARC452A21 remote. It is ready for immediate use upon battery installation, requiring no additional programming.





Figure 1: Front View of the ARC452A21 Remote Control

This image displays the front of the azwok ARC452A21 replacement remote control. The top section features an LCD screen, currently showing 'ON', '76°F', and 'MON'. Below the screen are buttons for 'FAN', 'POWERFUL', 'ON/OFF' (yellow), 'TEMP F/C', 'MODE', 'QUIET', 'COMFORT', 'SWING', 'SENSOR', 'WEEKLY', 'COPY', 'BACK', 'SELECT', 'NEXT', 'OFF', 'ON', 'CANCEL', and 'TIMER'. The remote is white with grey and yellow accents.





Figure 2: Front and Back Views of the ARC452A21 Remote Control

This image presents two views of the azwok ARC452A21 replacement remote control. The left side shows the front of the remote, identical to Figure 1, with its LCD screen and various function buttons. The right side shows the back of the remote, which is plain white and includes a battery compartment cover at the top, indicating where AAA batteries would be inserted.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide the battery compartment cover downwards and remove it.
3. Insert two (2) AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment. Batteries are not included.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

3.2 Initial Configuration (Fahrenheit/Celsius)

Upon initial battery installation, the temperature display may default to Fahrenheit (F). To switch to Celsius (C), press and hold both the **Temperature Up (+)** and **Temperature Down (-)** buttons simultaneously for a few seconds until the display changes.

4. Operating Instructions

This section details the functions of the buttons on your azwok ARC452A21 remote control.

- **ON/OFF Button:** Press the yellow **ON/OFF** button to turn the air conditioner unit on or off.
- **TEMP F/C Buttons:** Use the **Temperature Up (▲)** and **Temperature Down (▼)** buttons to adjust the desired room temperature. Note that temperature adjustments are typically in 1-degree increments.
- **MODE Button:** Press the **MODE** button repeatedly to cycle through the available operating modes (e.g., Auto, Cool, Dry, Fan, Heat).
- **FAN Button:** Press the **FAN** button to adjust the fan speed (e.g., Auto, Low, Medium, High).
- **SWING Button:** Activates or deactivates the automatic vertical airflow swing function.
- **TIMER ON/OFF/CANCEL Buttons:** Use these buttons to set, cancel, or adjust the unit's timer functions for automatic power on or off.
- **POWERFUL Button:** Activates a rapid cooling or heating function for a short period.
- **QUIET Button:** Reduces the operating noise level of the indoor unit.
- **COMFORT Button:** Adjusts airflow to prevent direct drafts on occupants.
- **ECONO Button:** Activates energy-saving operation.
- **SENSOR Button:** May activate an intelligent eye sensor for presence detection and energy saving.
- **WEEKLY, COPY, BACK, SELECT, NEXT Buttons:** These buttons are typically used for advanced timer programming, allowing for weekly schedules and navigation through settings.

5. Compatible Daikin Air Conditioner Models

This azwok ARC452A21 replacement remote control is compatible with a wide range of Daikin air conditioner models, including but not limited to:

- ARC452A10, ARC452A9, ARC452A19, ARC452A20, ARC452A21, ARC452A23, ARC466A36
- FTXS15HVJU, FTXS18HVJU, FTXS24HVJU, FTXS30HVJU, FTXS36HVJU, FTXS60LVMA, FTXS71LVMA, FTXS50KVMA, FTXS60KVMA, FTXS71KVMA, FTXS35LVMA, FTXS46LVMA, FTXS50LVMA, FTXS50JVMA, FTXS60JVMA, FTXS71JVMA, FTXS20LVMA, FTXS25LVMA, FTXS35LVMA, FTXS80HVMA, FTXS90HVMA, FTXS100HVMA, FTXS80KVMA, FTXS90KVMA, FTXS100KVMA, FTXS46KVMA, FTXS25KVMA, FTXS35KVMA, FTXS20KVMA, FTXS25KVMA, FTXS35KVMA, FTXS50FVMA, FTXS60FVMA, FTXS71FVMA, FTXS85LVMA, FTXS95LVMA
- CTXS09HVJU, CTXS12HVJU, CTXS07JVJU, CTXS07LVJU, CTXS09LVJU, CTXS12LVJU, CTXS15LVJU, CTXS18LVJU, CTXS24LVJU, CTXS30LVJU, CTXS36LVJU

- FTXN09KEVJU, FTXN12KEVJU, FTXN15KVJU, FTXN18KVJU, FTXN24KVJU
- FDXS09LVJU, FDXS12LVJU
- CDXS15LVJU, CDXS18LVJU, CDXS24LVJU
- CTXG09QVJUW, CTXG12QVJUW, CTXG18QVJUW, CTXG09QVJUS, CTXG12QVJUS, CTXG18QVJUS
- FTXR09TVJUW, FTXR12TVJUW, FTXR18TVJUW, FTXR09TVJUS, FTXR12TVJUS, FTXR18TVJUS
- FTKS20LVMA, FTKS25LVMA, FTKS35LVMA, FTKS46KVMA
- RXS20LVMA, RXS25LVMA, RXS35LVMA

If your specific Daikin model number is not listed above, or if your original remote control differs significantly in appearance, please contact customer support to confirm compatibility.

6. Troubleshooting

- **Remote Not Responding:**
  - Ensure batteries are correctly installed with the proper polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the air conditioner's receiver.
  - Ensure you are within the effective operating range (up to 10 meters).
- **Incorrect Temperature Display (Fahrenheit/Celsius):**
  - Refer to Section 3.2 for instructions on how to switch between Fahrenheit and Celsius.
- **Specific Functions Not Working:**
  - Some advanced functions may vary slightly depending on your specific Daikin air conditioner model. Consult your air conditioner's original manual for detailed function descriptions.

If issues persist after following these steps, please contact customer support for further assistance.

7. Specifications

Feature	Detail
Brand	azwok
Model Name	ARC452A21
Product Model Number	RM-ARC452A21-DK007
Connectivity Technology	Infrared
Compatible Devices	Air Conditioner
Special Feature	No programming required
Maximum Range	10 Meters
Number of Buttons	15 (visible buttons)
Battery Type	2 x AAA (not included)
Color	White

Country of Origin	China

8. Warranty and Support

8.1 Warranty Information

This azwok replacement remote control comes with a 1-year replacement guarantee. Returns are accepted for refund or exchange if the product does not function with your compatible devices.

8.2 Customer Support

For any questions regarding compatibility, setup, or troubleshooting that are not covered in this manual, please contact azwok customer support. We are available to assist you in finding the correct remote control or resolving any operational issues.

© 2024 azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question