

Luxchoice Loveseat

Luxchoice Inflatable Couch Loveseat User Manual

Model: Loveseat | Brand: Luxchoice

1. INTRODUCTION

Thank you for choosing the Luxchoice Inflatable Couch Loveseat. This manual provides essential information for the safe and efficient use of your new inflatable furniture. Designed for versatility, this loveseat is suitable for various indoor and outdoor activities, offering comfort and durability.

Key Features:

- **Military-Grade Durability:** Constructed with a high-strength PVC inner layer and a 1000D Oxford cloth exterior for tear and scratch resistance.
- **Thoughtful Side Straps:** Integrated side straps for hanging bags, water bottles, or accessories, enhancing convenience and portability.
- **4-Minute Instant Inflation:** Features a removable and rechargeable high-speed pump for quick, one-touch inflation.
- **Portable Design:** Easily foldable for compact storage in a lightweight, large-capacity carry bag.
- **Ergonomic Comfort & Stable:** Dual-layer air chambers provide targeted full-body support for optimal comfort.

For a visual overview of the product, please watch the video below:

Video: Luxchoice Inflatable Sofa Multifunctional Air Couch. This video provides a general overview of the inflatable couch's features and versatility.

2. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure safe operation and longevity of your inflatable couch:

- **Use on Smooth Surfaces:** Always place the couch on smooth surfaces. Avoid sharp objects such as sand, wood chips, pet nails, or pens that could puncture the material.
- **Proper Inflation:** Inflate the couch to a firm but not overfilled state. Excess pressure may damage seams.
- **Temperature Sensitivity:** The inflatable couch may feel softer or less firm in lower temperatures as air contracts. This is normal and not a leak. Simply reinflate to restore firmness.
- **Material Stretching:** The PVC material naturally stretches during the first 2-3 days of use. Reinflate as required to maintain desired firmness.
- **Air Pump Safety:** Always fully charge the air pump before use. Keep the air pump away from open flames or high heat sources.

3. PACKAGE CONTENTS

Your Luxchoice Inflatable Couch Loveseat package includes:

- 1 x Luxchoice Inflatable Couch Loveseat
- 1 x User Guide
- 1 x Carry Bag
- 1 x Repair Patch
- 1 x Built-in Rechargeable Air Pump

4. SETUP INSTRUCTIONS

Follow these steps to quickly set up your Luxchoice Inflatable Couch Loveseat:

1. **Unpack the Couch:** Remove the inflatable couch from its carry bag and lay it flat on a clean, smooth surface.
2. **Inflate the Base:** Locate the built-in air pump on the bottom section of the couch. Ensure the valve is securely closed. Turn on the pump with a one-touch button to begin inflating the base. The base will inflate automatically.
3. **Inflate the Upper Section:** Once the base is firm, remove the detachable air pump. Attach the appropriate air nozzle to the pump. Locate the inflation port for the upper section (backrest and armrests). Insert the pump with the nozzle into the port and inflate until the upper section is firm. Securely close the valve after inflation.

For a detailed visual guide on unboxing and setup, please refer to the video below:

Video: Luxchoice Inflatable Sofa Unboxing and Setup. This video demonstrates the unboxing process and step-by-step instructions for inflating the couch.

Here is a visual guide for the inflation and deflation process:



Image: Inflation/Deflation Guides of Air Couch. This image illustrates the four steps for inflating and deflating the couch using the built-in and detachable pumps.

5. OPERATING INSTRUCTIONS

Your Luxchoice Inflatable Couch Loveseat is designed for versatile use and comfort. Once fully inflated, it provides a stable and comfortable seating solution for various activities.

- **Seating:** The ergonomic design and dual-layer air chambers offer targeted support for sitting or lounging.
- **Versatile Use:** Ideal for camping, backyard gatherings, outdoor movie nights, RV trips, or as extra seating indoors.
- **Portability:** The lightweight design and carry bag make it easy to move and set up wherever needed.

Luxchoice Premium Air Couch— Make Life more easier and pleasant as possible.



Image: Luxchoice Premium Air Couch. This image shows the inflatable couch being used by a couple in a camping environment, highlighting its comfort and outdoor suitability.

6. MAINTENANCE

Proper maintenance will extend the life of your Luxchoice Inflatable Couch Loveseat:

- **Cleaning:** The exterior cover is removable and machine-washable. For minor spills, wipe clean with a dry cloth.
- **Repair Patch:** In case of small punctures, use the included repair patch according to its instructions.



Image: Washable Outer Cover. This image demonstrates the process of removing and washing the outer cover of the inflatable couch.

7. STORAGE

To store your inflatable couch, follow these steps:

1. **Deflation:** Use the air pump to deflate both the upper and lower sections of the couch. The pump can be reversed to extract air for quicker and more complete deflation.
2. **Folding:** Once fully deflated, carefully fold the couch to its original compact size.
3. **Packing:** Place the folded couch into the provided carry bag for easy transport and storage.



Image: Quick Setup, Easy Storage, and Portable. This image shows the inflatable couch in a home setting, highlighting its portability and ease of storage in its carry bag.

8. TROUBLESHOOTING

If you encounter any issues with your Luxchoice Inflatable Couch Loveseat, please refer to the following common solutions:

- **Couch feels soft or less firm:** This is often due to temperature drops, which cause air to contract. Reinflate the couch to your desired firmness. This is normal and does not indicate a leak.
- **Couch loses firmness after initial inflation:** New PVC material may stretch during the first few days of use. Reinflate as needed until the material stabilizes.
- **Air pump not working:** Ensure the air pump is fully charged. Check that the pump is correctly inserted into the valve and the switch is in the 'on' position.

9. SPECIFICATIONS

Feature	Detail
Brand	Luxchoice
Model	Loveseat
Product Dimensions	31.5"D x 65"W x 31.5"H
Item Weight	16 Pounds
Weight Limit	660 Pounds
Seating Capacity	2
Material Type	Outer: 1000D Oxford cloth, Inner: PVC
Upholstery Fabric Type	Oxford Weave, Polyester
Color	Olive Drab
Indoor Outdoor Usage	Indoor, Outdoor
Included Components	User Guide, Carry Bag, Repair Patch, luxury Air sofa with Built in Pump
Assembly Required	No
Is Electric	Yes (Built-in pump)

10. WARRANTY & SUPPORT

Your Luxchoice Inflatable Couch Loveseat comes with a **6-month manufacturer's limited warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Luxchoice customer service through the retailer where you purchased the item. Please have your purchase receipt and product model information ready.

For additional information or to explore other Luxchoice products, visit the official Luxchoice Store: [Luxchoice Store on Amazon](#).

© 2026 Luxchoice. All rights reserved.