

[Manuals.plus](#) /

> [BRECIIOUS](#) /

> BRECIIOUS Slow Masticating Cold Press Juicer User Manual

BRECIIOUS B0CRQWSBCM

BRECIIOUS Slow Masticating Cold Press Juicer

Model: B0CRQWSBCM

1. INTRODUCTION

Thank you for choosing the BRECIIOUS Slow Masticating Cold Press Juicer. This appliance is designed to extract juice from various fruits and vegetables efficiently, preserving nutrients and natural flavors through its cold press technology. This manual provides essential information for safe operation, assembly, maintenance, and troubleshooting to ensure optimal performance and longevity of your juicer.

The BRECIIOUS juicer features an upgraded 7-stage auger for high juice yield, a powerful yet quiet motor (under 60 dB), and multi-function control buttons for different ingredient types.



Image 1.1: The BRECIIOUS Cold Press Juicer in operation, demonstrating juice extraction and pulp separation.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the juicer to prevent injury or damage to the appliance. Keep this manual for future reference.

- Always ensure the juicer is properly assembled before use.
- Do not operate the juicer with damaged cord or plug. Contact customer support if damage occurs.
- Keep hands and utensils out of the feed chute during operation. Use the provided food pusher to guide ingredients.
- The juicer features a 1.8-inch small diameter feed chute for enhanced safety, preventing hands from reaching the auger.
- This appliance is 100% BPA-free and designed without sharp blades, making it safe for family use.
- Unplug the juicer from the power outlet before cleaning, disassembling, or when not in use.
- Do not immerse the motor base in water or other liquids.
- Ensure the juicer is placed on a stable, flat, and dry surface during operation.
- This appliance is for household use only.



Small Feed Chute

Whoever Makes the Juice is Safer (Child, teenager, etc)

Image 2.1: The juicer's small 1.8-inch feed chute, designed for user safety.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your BRECIIOUS Slow Masticating Juicer:

1. Food Pusher
2. Feed Chute
3. Auger (7-stage spiral design)
4. Filter Screen (3-section super filter)
5. Juice Outlet Cover
6. Juice Cup
7. Pulp Container
8. Motor Base with Control Panel
9. Cleaning Brush



Image 3.1: Exploded view illustrating the individual components of the juicer.



7 Update Spiral Auger

High juice yield ensures maximum nutrition

Image 3.2: Detail of the 7-stage spiral auger, a key component for cold press juicing.

4. SETUP GUIDE

Follow these steps to assemble your juicer before first use:

1. Place the motor base on a stable, flat surface.

2. Align the juice outlet cover with the motor base and twist clockwise until it locks into place.
3. Insert the filter screen into the juice outlet cover.
4. Insert the auger into the center of the filter screen, pushing down firmly.
5. Attach the feed chute assembly by aligning it with the motor base and twisting clockwise until it clicks securely.
6. Place the juice cup under the juice spout and the pulp container under the pulp outlet.
7. Ensure all parts are securely locked before plugging in the appliance.



Image 4.1: Visual guide for assembling the juicer components.

5. OPERATING INSTRUCTIONS

Prepare your ingredients and operate the juicer using the following guidelines:

5.1 Ingredient Preparation

- Wash all fruits and vegetables thoroughly.
- Cut ingredients into small pieces (approximately 1.5 inches or smaller) to fit the feed chute and prevent clogging. Remove large seeds, hard pits, and thick peels.
- For leafy greens like celery or spinach, roll them into a tight ball before feeding.

5.2 Using the Control Panel

The juicer features a control panel with dedicated buttons for different functions:

- **OFF:** Turns the juicer off.
- **Soft Mode (85-95 RPM):** Ideal for softer fruits and vegetables such as oranges, kiwis, strawberries, and tomatoes.
- **Hard Mode (95-110 RPM):** Suitable for harder ingredients like celery, carrots, apples, and ginger.
- **REV (Reverse Function):** Use this button to clear clogs. If ingredients get stuck, press and hold 'REV' for a few seconds, then release. Repeat if necessary, then switch back to 'Soft' or 'Hard' mode.



Image 5.1: The control panel showing the operational modes.



Multi-function Button

Hard Mode (95-110RPM)
Suitable for Celery, Carrot, Apple, etc

Soft Mode (85-95RPM)
Suitable for Orange, Kiwi, Strawberry, etc

Image 5.2: Guide for selecting the appropriate juicing mode based on ingredient hardness.

5.3 Juicing Process

1. Plug the juicer into a power outlet.
2. Select the appropriate speed mode ('Soft' or 'Hard') based on your ingredients.

3. Slowly feed prepared ingredients into the feed chute. Use the food pusher to gently guide them down. Do not force ingredients.
4. The juicer will automatically separate juice into the juice cup and pulp into the pulp container.
5. Once finished, press the 'OFF' button and unplug the juicer.

Your browser does not support the video tag.

Video 5.3: Demonstration of the BRECIIOUS Slow Masticating Juicer in operation, showcasing its juice extraction process.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures hygiene and extends the life of your juicer. The BRECIIOUS juicer is designed for easy one-touch disassembly and cleaning.

6.1 Disassembly for Cleaning

1. Ensure the juicer is unplugged.
2. Press the 'Push' button on the side of the feed chute and twist the entire top assembly (feed chute, auger, filter, juice outlet cover) counter-clockwise to detach it from the motor base.
3. Separate the feed chute, auger, filter screen, and juice outlet cover.
4. Empty the juice cup and pulp container.



One Touch Disassemble

Easy to Clean After Using

Image 6.1: One-touch disassembly of the juicer for easy cleaning.

6.2 Cleaning the Components

- Rinse all detachable parts (feed chute, auger, filter screen, juice outlet cover, juice cup, pulp container) under running water immediately after use to prevent pulp from drying.
- Use the provided cleaning brush to thoroughly clean the filter screen, ensuring all mesh holes are clear of pulp.
- All detachable parts are dishwasher safe for added convenience. Place them on the top rack of your dishwasher.
- Wipe the motor base with a damp cloth. Never immerse the motor base in water.
- Ensure all parts are completely dry before reassembling or storing.



Easy to Clean

All Detachable Components can be Placed in the Dishwasher

Image 6.2: Cleaning the filter with a brush and demonstrating dishwasher compatibility for detachable parts.



Less & Drier Pulp

Super Filter Maximizes the silky smoothness of the juice and less pulp

Image 6.3: The 3-section super filter, designed to maximize juice smoothness and minimize pulp.



Image 6.4: The no-dead-angle juice spout design facilitates thorough cleaning and prevents residue buildup.

7. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; not assembled correctly; power outage.	Ensure power cord is securely plugged in. Check if all parts are correctly assembled and locked. Verify power supply.
Juicer stops during operation or gets clogged.	Too much ingredient fed at once; ingredients are too hard or fibrous; pulp buildup.	Press the 'REV' button for a few seconds to clear the clog. If it persists, turn off, unplug, disassemble, and clear manually. Cut ingredients into smaller pieces.
Low juice yield or wet pulp.	Incorrect speed mode selected; ingredients not properly prepared.	Ensure 'Hard' mode is used for hard ingredients and 'Soft' for soft. Cut ingredients to appropriate size.
Loud noise or vibration.	Improper assembly; foreign object inside.	Turn off and unplug. Reassemble all parts correctly. Check for any foreign objects and remove them.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	BRECIIOUS
Model	B0CRQWSBCM
Color	Purple

Feature	Detail
Special Features	BPA Free, Powerful Motor, Quiet Motor (<60 dB)
Product Dimensions (D x W x H)	14.84" x 6.97" x 14.6"
Finish Type	Mirror Satin
Recommended Uses	Celery, Vegetables, Fruits
Product Care Instructions	Dishwasher Safe (detachable parts)
Power Source	Corded Electric
Number of Speeds	2 (Soft, Hard)
Item Weight	8.82 pounds
Construction Material	Acrylonitrile Butadiene Styrene (ABS)
Filter Screen Material	Stainless Steel

9. WARRANTY AND SUPPORT

Your BRECIIOUS Slow Masticating Cold Press Juicer comes with a one-year after-sales service. This warranty covers manufacturing defects and ensures professional support for your purchase.

For warranty claims, technical assistance, or any questions regarding your product, please contact BRECIIOUS customer support through the retailer where you purchased the item or visit the official BRECIIOUS website for contact information.