Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COLAMY XK

COLAMY Ergonomic Mesh Office Chair User Manual

Model: XK | Brand: COLAMY

1. Introduction

Thank you for choosing the COLAMY Ergonomic Mesh Office Chair, Model XK. This chair is designed to provide superior comfort and support for long hours of work or gaming, featuring advanced ergonomic adjustments. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new office chair.





Image 1.1: The COLAMY Ergonomic Mesh Office Chair in Dark Grey, showcasing its high back and mesh design. This chair is built for comfort and durability, supporting up to 300 lbs.



Image 1.2: A user demonstrating the comfortable and supportive posture achieved with the COLAMY Ergonomic Mesh Office Chair during office work.

2. Safety Information

- Do not exceed the maximum weight capacity of **300 pounds**. Overloading the chair can lead to damage or injury.
- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep hands and fingers clear of moving parts during adjustment to prevent pinching.
- Use the chair on a flat, stable surface to prevent tipping.
- Do not stand on the chair or use it as a step stool.
- Keep children and pets away from the chair during assembly and adjustment.

3. Product Features

The COLAMY Ergonomic Mesh Office Chair is equipped with several features designed for enhanced comfort and adaptability:

- **Adjustable Headrest:** Provides support for your neck and head, reducing strain.
- **4D Armrests:** Allows for multi-directional adjustment (height, depth, pivot, width) to support your arms and shoulders.
- **Adjustable Lumbar Support:** Conforms to the natural curve of your spine, offering targeted lower back support.
- **Height Adjustment:** Easily adjust the seat height to find your optimal ergonomic position.
- **4-Position Tilt Lock:** Lock the chair's recline at various angles for different activities.
- **Sliding Seat:** Adjust the seat depth to ensure proper leg and back support.
- **Ventilated Mesh Fabric:** High-end breathable mesh from Korea provides flexibility, durability, and airflow.
- **High-Density Molding Foam:** Thickened and widened seat cushion for robust hip support.
- **Heavy Duty Aluminum Alloy Metal Base:** Ensures great stability and mobility with 360-degree swivel and smooth-rolling casters.



Image 3.1: Overview of the chair's adjustable features including headrest, lumbar support, 4D armrests, seat glide knob, height adjustment/tilt tension knob, and tilt lock knob.

Image 3.2: Detailed view of the skin-friendly, eco-friendly, breathable, and durable mesh material imported from Korea, certified by BIFMA, OEKO-TEX, and Greenguard.

4. Specifications



Image 4.1: Detailed product dimensions including height, width, depth, and weight capacity of 300 lbs.

Specification	Detail
Brand	COLAMY
Model Name	XK
Color	Dark Grey
Product Dimensions	25"D x 28"W x 50"H

Specification	Detail
Maximum Weight Recommendation	300 Pounds
Item Weight	49.6 pounds
Back Style	Solid Back
Special Features	Adjustable Headrest, Adjustable Height, Adjustable Lumbar, Ergonomic, Reclining
Material	Mesh, Foam, Aluminum Alloy
Arm Style	With 4D adjustable arms
Seat Height	16.73 - 21.06 Inches
Seat Depth	15.75 - 17.72 Inches (adjustable)
Chair Backrest Width	18.5 Inches
Reclining Position Count	4 (90°, 105°, 120°, 130°)
Certifications	BIFMA certified, Class 4 gas cylinder verified by SGS

5. Setup (Assembly)

While specific step-by-step instructions are not provided here, general assembly of the COLAMY Ergonomic Mesh Office Chair typically involves the following components and steps. Please refer to the included assembly guide in your product packaging for detailed, illustrated instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify all components are present against the parts list in your assembly guide. Common components include: backrest, seat cushion, armrests, gas lift cylinder, five-star base, and casters.
2. **Attach Casters to Base:** Insert the casters into the holes at the end of each leg of the five-star base. Push firmly until they click into place.
3. **Insert Gas Lift Cylinder:** Place the larger end of the gas lift cylinder into the center hole of the five-star base.
4. **Assemble Armrests:** Attach the armrests to the seat cushion using the provided screws. Ensure they are oriented correctly.
5. **Attach Backrest to Seat:** Secure the backrest to the seat cushion assembly using the designated screws.
6. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, aligning the center mechanism with the top of the cylinder. Press down firmly to secure.
7. **Final Checks:** Ensure all screws are tightened and the chair is stable before use.



Image 5.1: The robust aluminum alloy five-star base, providing stability and durability for the chair.



Image 5.2: The smooth-rolling casters designed for easy and quiet movement across various floor surfaces.

6. Operating Your Chair (Adjustments)

The COLAMY Ergonomic Mesh Office Chair offers a range of adjustments to customize your seating experience:

- **Seat Height Adjustment:** Locate the lever on the right side under the seat. Pull the lever up to raise the seat; release to lock. To lower, sit on the chair and pull the lever up.
- **Seat Depth Adjustment (Slide Seat):** Locate the knob on the left side under the seat. Rotate the knob to unlock the seat, then slide the seat forward or backward to your desired depth. Rotate the knob back to lock. This feature helps ensure proper leg and back support.
- **Recline and Tilt Lock:** The main lever on the right side also controls the recline. Push the lever outwards to unlock the tilt function, allowing the chair to recline. Push the lever inwards to lock the chair in one of the four available recline positions (90°, 105°, 120°, 130°).
- **Tilt Tension Adjustment:** The round knob located under the front of the seat controls the tension of the recline. Turn clockwise to increase tension (making it harder to recline) or counter-clockwise to decrease tension (making it easier to recline).
- **Adjustable Headrest:** The headrest can be adjusted vertically and pivoted to provide optimal neck and head support. Simply grasp the headrest and move it to your preferred position.
- **Adjustable Lumbar Support:** The lumbar support mechanism on the backrest can be moved up or down to align with the natural curve of your lower back.
- **4D Armrests:** These armrests offer four dimensions of adjustment:
  - **Height:** Press the button on the side of the armrest and slide it up or down.
  - **Depth (Forward/Backward):** Slide the armrest pad forward or backward.
  - **Pivot (Angle):** Rotate the armrest pad inwards or outwards.
  - **Width (In/Out):** Slide the entire armrest assembly inwards or outwards (if applicable to your model).



Image 6.1: Visual representation of the chair's multi-functional adjustments, including recline angles (90°, 105°, 120°, 130°), seat height, seat depth, and tilt tension.



Image 6.2: Detailed view of the adjustable headrest, allowing for vertical and pivot adjustments to support the user's head and neck.



Image 6.3: Close-up of the adjustable lumbar support, which can be moved vertically to provide targeted support to the lower back.




Image 6.4: Detailed view of the 4D adjustable armrests, illustrating their ability to move in multiple directions for personalized arm support.

7. Maintenance

Proper care and maintenance will extend the life of your COLAMY office chair:

- **Cleaning:** For general cleaning, wipe the chair with a soft, damp cloth. For spot cleaning, use a mild soap solution and a clean cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the mesh fabric or other materials.
- **Regular Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten any loose fasteners to maintain stability and safety.
- **Caster Care:** Keep the casters clean and free of debris (hair, lint, etc.) to ensure smooth rolling. If casters become stiff, they can be removed and cleaned.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the mesh and fabric to fade or degrade over time.
- **Weight Limit:** Always adhere to the maximum weight recommendation of 300 pounds to prevent structural damage.

8. Troubleshooting

If you encounter any issues with your COLAMY Ergonomic Mesh Office Chair, refer to the common problems and solutions below:

- **Chair Sinks or Does Not Stay Up:**
  Possible Cause: Gas lift cylinder malfunction.
  Solution: The gas lift may need to be replaced. Contact customer support for assistance.
- **Chair Wobbles or Feels Unstable:**
  Possible Cause: Loose screws or improper assembly.
  Solution: Check all assembly screws, especially those connecting the seat, backrest, and armrests, and tighten them securely.

Ensure the gas lift is properly seated in the base.

- **Casters Not Rolling Smoothly:**
  Possible Cause: Debris (hair, lint) caught in casters or damaged casters.
  Solution: Turn the chair over and carefully remove any debris from the caster wheels. If a caster is damaged, it may need to be replaced.
- **Chair Squeaks or Creaks:**
  Possible Cause: Loose connections or friction between parts.
  Solution: Tighten all screws. A small amount of silicone-based lubricant can be applied to moving parts or pivot points, avoiding contact with fabric or mesh.
- **Adjustments (Headrest, Lumbar, Armrests) Are Stiff:**
  Possible Cause: Infrequent use or minor friction.
  Solution: Operate the adjustment mechanisms several times to loosen them. Ensure no obstructions are present. Do not force adjustments.

9. Warranty and Support

COLAMY is committed to providing high-quality products. For any questions, concerns, or to inquire about warranty information and support, please contact COLAMY Customer Support. Details for contacting support are typically found on the product packaging or the official COLAMY website.
Please have your model number (XK) and purchase information ready when contacting support to facilitate a quicker resolution.
Note: No official product videos were provided in the available data for embedding in this manual.

© 2024 COLAMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRQYLD91

More documents and user manuals: **https://manuals.plus/**