

[Manuals.plus](#) /

› [Airposta](#) /

› Airposta Dimmable Floor Lamp User Manual

Airposta 231010A1

Airposta Dimmable Floor Lamp User Manual

Brand: Airposta | Model: 231010A1

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Airposta Dimmable Floor Lamp. This 3-light industrial floor lamp features a blend of farmhouse and vintage styles, designed to enhance various living spaces such as living rooms, bedrooms, and offices. It includes a convenient rotary switch for dimming functionality.



Image: The Airposta Dimmable Floor Lamp, showcasing its three cage-style lights and black metal pole, designed for various indoor settings.

2. SAFETY INFORMATION

- Ensure the lamp is unplugged before assembly, cleaning, or changing bulbs.
- Use only bulbs that comply with the specified wattage and type (E26 base, 40W max).
- Do not expose the lamp to water or excessive moisture. This product is for indoor use only.
- Keep children and pets away from the lamp during assembly and operation to prevent accidents.
- All electrical components (socket, switch, wire, base) comply with UL standards for safety.
- Place the lamp on a stable, level surface to prevent tipping. The heavy metal base is designed for stability.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Lamp Base
- Lower Lamp Pole Section
- Middle Lamp Pole Section with Rotary Switch
- Upper Lamp Pole Section with Branch Arms
- 3 x Metal & Wood Cage Lampshades
- Power Cord (integrated)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the Airposta Dimmable Floor Lamp is designed to be straightforward and requires no additional tools. Follow these steps:

1. Carefully unpack all components and place them on a clean, flat surface.
2. Screw the Lower Lamp Pole Section into the Lamp Base clockwise until secure.
3. Screw the Middle Lamp Pole Section (with the rotary switch) onto the Lower Lamp Pole Section. Ensure the power cord passes freely through the sections.
4. Screw the Upper Lamp Pole Section (with the branch arms) onto the Middle Lamp Pole Section.
5. Attach the three Metal & Wood Cage Lampshades to the lamp holders on the branch arms.
6. Insert three E26 base dimmable bulbs (not included, 40W max) into the sockets.
7. Ensure all connections are tight and the lamp is stable before plugging it into a power outlet.

Dimmable Floor Lamp

E26 Blub: Not Included

Wattage: 40W/per

Voltage: 110-120V

Control Method: Rotate Switch

Power Source: Corded-electric

Material: Iron+ Wood Cage



Image: A diagram illustrating the assembled floor lamp with key dimensions, including its 65-inch height and base diameter.


5. OPERATING INSTRUCTIONS

The Airposta Dimmable Floor Lamp features a rotary switch for easy control of brightness.

- **Turning On/Off:** Rotate the switch clockwise until you hear a click to turn the lamp on. Continue rotating counter-clockwise until you hear a click to turn the lamp off.
- **Adjusting Brightness:** Once the lamp is on, continue rotating the switch clockwise to increase brightness (up to 100%) or counter-clockwise to decrease brightness (down to 0%). This stepless dimming allows for precise light adjustment.



Image: A detailed view of the rotary switch located on the lamp pole, used for turning the lamp on/off and adjusting brightness.



0%-100% Stepless Dimming




Image: An illustration demonstrating the lamp's 0-100% stepless dimming feature, showing varying light levels.

6. BULB REQUIREMENTS

This floor lamp requires three E26 base bulbs. For optimal performance and dimming functionality, use dimmable bulbs.

- **Bulb Type:** Compatible with dimmable LED, CFL, or Incandescent bulbs.
- **Maximum Wattage:** 40W per bulb.
- **Bulbs Not Included:** Bulbs must be purchased separately.



**Compatible with
E26 Dimmable Bulb**

(40w Max, Bulbs Not Included)



Image: An image displaying different types of E26 dimmable bulbs compatible with the floor lamp, including Edison-style and standard LED bulbs.

7. MAINTENANCE

To ensure the longevity and appearance of your floor lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe down the metal pole and wood cage lampshades. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** Always ensure the lamp is unplugged and the bulbs have cooled before attempting to replace them.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.

8. TROUBLESHOOTING

If you encounter issues with your Airposta Dimmable Floor Lamp, refer to the following common problems and solutions:

Problem: Lamp does not turn on.

- Ensure the power cord is securely plugged into a working outlet.
- Check if the rotary switch is fully turned to the 'ON' position.
- Verify that the bulbs are correctly installed and not burnt out. Replace if necessary.
- Check the circuit breaker in your home.

Problem: Dimming function is not working.

- Confirm that you are using dimmable bulbs. Non-dimmable bulbs will not respond to the dimming feature.
- Ensure the bulbs are fully screwed into the sockets.

Problem: Lamp is unstable.

- Ensure all pole sections are tightly screwed together and into the base.
- Place the lamp on a flat, even surface.

9. SPECIFICATIONS

Attribute	Specification
Brand	Airposta
Model Name	dimmable floor lamp
Item Model Number	231010A1
Lamp Type	Floor Lamp
Style	Dimmable rotary switch
Product Dimensions	6"D x 6"W x 6"H (Note: This appears to be for a component, overall height is 65 inches)
Item Weight	12.91 pounds
Material	Metal, Wood
Finish Type	Painted
Color	Black

Number of Light Sources	3
Bulb Base	E26
Wattage	40 watts (max per bulb)
Light Source Type	Dimmable LED, CFL, or Incandescent bulbs
Control Method	Rotary Switch
Power Source	Corded Electric
Voltage	110 Volts
Indoor/Outdoor Usage	Indoor

10. WARRANTY AND SUPPORT

Your Airposta Dimmable Floor Lamp comes with a**2-Year Free Warranty**.

If you encounter any problems with your lamp, or require assistance, please contact Airposta customer support through the buyer-seller message system on the platform where you purchased the product. Please provide your order details and a description of the issue for prompt assistance.

© 2024 Airposta. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question