QCY T13 ANC, HT07 ArcBuds

QCY T13 ANC Earbuds & HT07 ArcBuds User Manual

Model: T13 ANC, HT07 ArcBuds | Brand: QCY

Introduction

This manual provides detailed instructions for the QCY T13 ANC Earbuds and QCY HT07 ArcBuds. Please read this guide thoroughly before using your earbuds to ensure proper operation and to maximize your listening experience. These true wireless earbuds are designed for exceptional sound quality, active noise cancellation, and clear communication.



Image: The QCY T13 ANC and HT07 ArcBuds, shown with their respective charging cases. The earbuds are black and designed for in-ear use.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. The earbuds offer 7 hours of working time per full charge, and the charging case extends that to 30 hours with ANC mode turned off. A quick 10-minute charge provides up to 60 minutes of playtime.



Image: The QCY T13 ANC earbuds and their charging case, illustrating the extended battery life of up to 30 hours with the case.

2. Pairing with Your Device

1. Ensure the earbuds are charged and remove them from the charging case.
2. Go to the Bluetooth settings on your device (smartphone, tablet, computer).
3. Select "QCY T13 ANC" or "QCY HT07 ArcBuds" from the list of available devices.
4. Once connected, you will hear a confirmation tone.

The earbuds utilize advanced Bluetooth 5.3 technology for a stable and fast connection.**Note:** Before pairing, please tear off any insulating film on the earbuds' charging contacts.



Image: An illustration depicting the Bluetooth 5.3 chip, emphasizing its role in providing a faster and more stable wireless connection.

Operating Instructions

Touch Controls

The earbuds feature intuitive touch controls for managing playback, calls, and modes. Refer to the specific model's quick start guide for detailed touch gestures.

Active Noise Cancellation (ANC) and Transparency Mode

These wireless earphones can cancel up to 30dB of background noise, allowing you to focus on your audio. Transparency mode allows you to hear your surroundings without removing the earbuds.



Image: A visual representation of the Active Noise Cancellation feature, showing how it reduces lower frequency noises for a focused listening experience. Icons for ANC Mode, Transparent Mode, and Low Latency Mode are also visible.

Exceptional Sound Quality

The built-in 10mm bio-diaphragm dynamic driver provides natural sound and deep bass, enhancing your music experience.



Image: A cutaway view of an earbud, highlighting the 10mm bio-diaphragm dynamic driver and highly elastic CCAW for exceptional sound production.

Crystal-clear Call Quality

Each earbud is equipped with 2 microphones, totaling 4 professional microphones. These reduce 90% of background noise, ensuring clear voice detection even in noisy environments.




Image: A woman wearing the QCY earbuds while making a phone call, illustrating the clear call quality provided by the 4-microphone Environmental Noise Cancellation (ENC) system.

Gaming Mode

Activate Gaming Mode for ultra-low latency, as low as 68ms, providing a synchronized audio-visual experience for gaming.



Image: The QCY earbuds displayed with a smartphone screen showing a video game, highlighting the 68ms low-latency Gaming Mode.

Exclusive QCY App

Customize your listening experience with the exclusive QCY App. Adjust personalized EQ settings, switch noise canceling modes, and more.




Image: A smartphone displaying the QCY app interface, which allows users to customize sound settings, noise canceling modes, and other personalized EQ options for their earbuds.

Maintenance

Cleaning

- Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth.
- Remove ear tips and clean any earwax or debris from the speaker mesh using a small, soft brush or cotton swab.
- Do not use abrasive cleaners or immerse the earbuds or case in water.

Storage

Store the earbuds in their charging case when not in use to protect them from dust and damage, and to keep them charged.

Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close the lid, then open it again and try re-pairing. Check if insulating film has been removed.
- **Only one earbud working:** Try resetting the earbuds. Ensure both earbuds are properly seated in the charging case.
- **Low volume or poor sound quality:** Clean the speaker mesh and ear tips. Ensure the earbuds are properly seated in your ears. Check your device's volume settings.
- **Charging issues:** Ensure the charging cable and port are clean and undamaged. Try a different charging cable or power source.
- **ANC not effective:** Ensure earbuds are properly sealed in your ear canal. Try different sized ear tips for a better fit.

For further assistance, please refer to the QCY official website or contact customer support.

Specifications

Feature	Detail
Model Name	QCY T13 ANC Earbuds
Connectivity Technology	Wireless (True Wireless)
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Noise Control	Active Noise Cancellation
Microphones	4 (2 per earbud) with ENC
Audio Driver Type	10mm Bio-diaphragm Dynamic Driver
Battery Life (Earbuds)	7 Hours (per charge)
Battery Life (with Case)	Up to 30 Hours (ANC off)
Charging Time (Quick Charge)	10 minutes for 60 minutes playtime
Control Method	Touch
Included Components	Ear Cushions (XS/S/M/L)
Water Resistance Level	Not Water Resistant
Frequency Range	20 Hz - 20,000 Hz
Material	Plastic, Silicone

Warranty and Support

For warranty information and customer support, please visit the official QCY website or contact the seller directly. Keep your proof of purchase for any warranty claims.

QCY Store Link: Visit the QCY Store on Amazon

© 2024 QCY. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question