

Sharper Image 1014851

Sharper Image Road Rage RC Speed Bumper Cars Instruction Manual

Model: 1014851 | Brand: Sharper Image

IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD — Small parts. Not for children under 3 years. Adult supervision is recommended during play.

- Keep away from water or damp conditions.
- Do not operate near electrical outlets or other electrical devices.
- Ensure all battery compartments are securely closed before use.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries from the product when not in use for extended periods.

PACKAGE CONTENTS

- One (1) Red bumper car with ejectable driver figure
- One (1) Blue bumper car with ejectable driver figure
- One (1) Red wireless remote control (2.4GHz)
- One (1) Blue wireless remote control (2.4GHz)




Image: The complete set of Sharper Image Road Rage RC Speed Bumper Cars, including two cars (red and blue), two remote controls, and two ejectable driver figures, displayed with its packaging.

SETUP INSTRUCTIONS

1. Battery Installation for Remote Controls

1. Locate the battery compartment on the back of each remote control.
2. Using a small Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert two (2) AAA batteries (not included) into each remote control, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.



SHARPER IMAGE®

Image: A close-up of the red remote control for the Sharper Image Road Rage RC Speed Bumper Car, showing its design and controls.

2. Battery Installation for Bumper Cars

1. Locate the battery compartment on the underside of each bumper car.
2. Using a small Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert four (4) AAA batteries (not included) into each bumper car, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

**01 2-PLAYER BATTLES**

Play for the win in fast-paced bumper duels against other drivers

02 DRIVER LAUNCHING IMPACTS

Crash into the opponent's car and launch their driver into the air

03 SOUND EFFECTS

Avoid hits or hear your driver yell – make your rival's racer do it instead

04 OMNIDIRECTIONAL STEERING

Turn left and right to dodge, gas it like a pro or throw it in reverse

05 WIRELESS CONTROL

Drive like you mean it and take charge of the action cord-free

06 2.4 GHz CONTROL

Control all the action wirelessly with the powerful remote



Image: The underside of a Sharper Image Road Rage RC Speed Bumper Car, showing the battery compartment and wheels.

3. Driver Placement

- Gently place each driver figure into its respective bumper car. Ensure they are seated securely.



Image: Two Sharper Image Road Rage RC Speed Bumper Cars, one red and one blue, each with its driver figure seated, ready for play.

OPERATING INSTRUCTIONS

1. Power On

- Turn on each bumper car using the ON/OFF switch located on the underside.
- Turn on each remote control using its ON/OFF switch.
- The cars and remotes will automatically pair. Each remote controls its corresponding colored car.

2. Movement and Steering

- Use the joysticks on the remote control to maneuver the car.
- The cars feature omnidirectional steering, allowing movement forward, backward, left, and right.
- Optimal performance is achieved on smooth, flat surfaces such as hardwood or tile. Traction may be limited on carpet.

3. Ejector Feature and Sound Effects

- When a bumper car is hit on its side bumper, the spring-loaded ejector mechanism will launch the driver figure.
- Sound effects will activate upon impact, enhancing the battle experience.



Image: A red Sharper Image Road Rage RC Speed Bumper Car is shown crashing into a blue one, with the red car's driver figure ejecting into the air, illustrating the impact feature.

Your browser does not support the video tag.

Video: An official product video demonstrating the RC Bumper Cars for Kids, showcasing their movement, lights, and the driver ejection feature during play.

GAMEPLAY: 2-PLAYER BATTLE

The Sharper Image Road Rage RC Speed Bumper Cars are designed for head-to-head competition. Engage in exciting duels with a friend to see who can eject the other's driver first.

- Each player selects a car and its corresponding remote control.

- Position the cars on a smooth, flat surface.
- The objective is to strategically maneuver your car to hit your opponent's car on its side bumper, causing their driver to eject.
- The player whose driver remains seated wins the round.
- The 2.4 GHz frequency allows multiple sets to operate simultaneously without interference, enabling larger group play if desired.

Your browser does not support the video tag.

Video: An official product video demonstrating the Sharper Image Road Rage RC Speed Bumper Cars in action, highlighting the head-to-head battle and driver ejection feature.

MAINTENANCE

- **Cleaning:** Wipe the cars and remote controls with a dry, soft cloth. Do not use water or cleaning solutions.
- **Storage:** Store the product in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove all batteries if the product will not be used for an extended period to prevent leakage and damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not move or respond to remote.	Batteries are low or incorrectly installed. Car or remote is not powered on. Car and remote are not paired.	Replace batteries in both car and remote, ensuring correct polarity. Ensure both car and remote are switched to the ON position. Turn both devices off and then on again to re-establish pairing.
Driver does not eject upon impact.	Impact was not direct on the side bumper. Driver figure is not properly seated.	Ensure direct impact on the side bumper. Press the driver figure firmly into its seat until it clicks into place.
Interference with other RC devices.	Operating too close to other 2.4 GHz devices.	Move to an area with less interference or ensure other devices are off.

PRODUCT SPECIFICATIONS

- **Model Number:** 1014851
- **Product Dimensions:** 14.75 x 7.68 x 8 inches

- **Item Weight:** 2.05 pounds
- **Manufacturer Recommended Age:** 6 years and up
- **Car Battery Requirements:** 4 AAA batteries (not included) per car
- **Remote Control Battery Requirements:** 2 AAA batteries (not included) per remote
- **Wireless Frequency:** 2.4 GHz
- **Manufacturer:** MerchSource
- **Release Date:** March 20, 2021

WARRANTY AND SUPPORT

For product support or inquiries regarding your Sharper Image Road Rage RC Speed Bumper Cars, please refer to the contact information provided with your purchase or visit the official Sharper Image website. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question