

Foreman FO1623-10L

Foreman FO1623-10L Industrial Wet & Dry Vacuum Cleaner 1000W - User Manual

Model: FO1623-10L | Brand: Foreman

1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the power cord from the electrical outlet before cleaning or servicing the vacuum cleaner.
- Do not use the vacuum cleaner on wet surfaces unless specifically designed for wet pickup. This model supports both wet and dry use.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

2. PRODUCT OVERVIEW

The Foreman FO1623-10L is a versatile 1000W industrial wet and dry vacuum cleaner with a 10-liter capacity, designed for various cleaning tasks including solids and liquids. It features a robust construction and a user-friendly design.

Key Features:

- **Powerful 1000W Motor:** Provides strong suction for efficient cleaning.
- **10L Capacity:** Ample capacity for extended cleaning sessions.
- **Wet & Dry Functionality:** Capable of vacuuming both solid debris and liquids.
- **Blower Function:** Can be used to blow away debris from hard-to-reach areas.
- **Washable Cloth Filter:** Durable and reusable filter for dry vacuuming.
- **Compact Design:** Easy to store and maneuver.
- **360° Swivel Wheels:** Enhances mobility and ease of movement.



Image 2.1: The Foreman FO1623-10L Industrial Wet & Dry Vacuum Cleaner shown with its included accessories.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or

damaged, contact customer support.

- Foreman FO1623-10L Vacuum Unit
- Flexible Hose (1.5 meters)
- 3 Plastic Extension Tubes
- Floor Brush
- Round Brush
- Crevice Nozzle
- Washable Cloth Filter
- Power Cord (3.5 meters)
- 4 Swivel Wheels



Image 3.1: A close-up view of the various brushes, nozzles, and extension tubes included with the vacuum cleaner.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Foreman FO1623-10L vacuum cleaner before first use.

1. **Unpack Components:** Remove all parts from the packaging.

2. **Install Swivel Wheels:** Turn the vacuum canister upside down. Insert the four swivel wheels into the designated slots on the base of the canister. Push firmly until they click into place.
3. **Install Filter:** For dry vacuuming, ensure the washable cloth filter is securely installed over the motor housing inside the canister. For wet vacuuming, remove the cloth filter.
4. **Attach Hose:** Connect the flexible hose to the suction inlet on the front of the vacuum canister. Twist clockwise to secure.
5. **Assemble Extension Tubes and Nozzle:** Connect the plastic extension tubes to the end of the flexible hose. Attach the desired cleaning nozzle (floor brush, round brush, or crevice nozzle) to the end of the extension tubes.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the assembly process of the Foreman Industrial Handheld Vacuum Cleaner, including installing wheels, connecting the hose, and attaching extension tubes and nozzles.



Image 4.1: Detail showing the washable cloth filter and the large, accessible power switch.

5. OPERATING INSTRUCTIONS

5.1 Dry Vacuuming

1. Ensure the washable cloth filter is securely installed.
2. Connect the hose and desired dry cleaning attachment (e.g., floor brush for general debris, crevice nozzle for tight spaces).
3. Plug the power cord into a suitable electrical outlet (120V).
4. Press the power switch to turn on the vacuum cleaner.
5. Guide the nozzle over the dry surface to pick up dust, dirt, and debris.
6. After use, turn off the vacuum and unplug it.

5.2 Wet Vacuuming

1. **Remove the cloth filter** before wet vacuuming. The filter is not designed for wet use and can be damaged.
2. Connect the hose and a suitable wet cleaning attachment (e.g., floor brush without bristles for liquid pickup).
3. Plug the power cord into a suitable electrical outlet (120V).
4. Press the power switch to turn on the vacuum cleaner.
5. Guide the nozzle over the liquid spill to suction it into the canister.
6. **Do not overfill the canister.** The vacuum has a float mechanism that will shut off suction when the liquid reaches its maximum level. If this occurs, turn off the vacuum, unplug it, and empty the canister.
7. After use, turn off the vacuum and unplug it. Empty and clean the canister immediately.

5.3 Blower Function

The vacuum cleaner can also function as a blower to clear debris from surfaces.

1. Disconnect the flexible hose from the suction inlet.
2. Locate the blower port on the top of the motor housing (usually opposite the suction inlet).
3. Insert the flexible hose into the blower port and twist to secure.
4. Plug the power cord into an electrical outlet.
5. Press the power switch to turn on the vacuum cleaner. Air will now exit through the hose, allowing you to blow away debris.
6. After use, turn off the vacuum and unplug it.

FOREMAN

SOPLADOR

aspira en **seco** y **húmedo**

GRAN MOVILIDAD



**MANIJA
TRANSPORTABLE**



RUEDAS 360°



Image 5.1: The vacuum cleaner configured for blower operation, highlighting its portability features like the handle and swivel wheels.



Image 5.2: The vacuum cleaner in use for dry cleaning, showing its maneuverability.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your vacuum cleaner.

6.1 Emptying the Canister

Empty the canister regularly, especially after wet vacuuming or when it is full, to maintain suction power and prevent odors.

1. Turn off and unplug the vacuum cleaner.
2. Unlatch the clips securing the motor housing to the canister.
3. Carefully lift the motor housing off the canister.
4. Dispose of collected debris or liquids.
5. Clean the inside of the canister with water and mild detergent if necessary, then dry thoroughly.
6. Replace the motor housing and secure the clips.

6.2 Cleaning the Cloth Filter

The washable cloth filter should be cleaned periodically to prevent clogging and maintain suction.

1. Turn off and unplug the vacuum cleaner.
2. Remove the motor housing and carefully detach the cloth filter.
3. Shake off loose dust and debris.
4. Rinse the filter under running water until clean. Do not use harsh detergents.
5. Allow the filter to air dry completely before re-installing it. **Do not use the vacuum with a wet filter.**

6.3 General Care

- Inspect the hose and attachments for blockages or damage before each use.
- Wipe the exterior of the vacuum cleaner with a damp cloth. Do not use abrasive cleaners.
- Store the vacuum cleaner in a dry, cool place.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	No power supply; Power switch off; Damaged cord/plug	Check power outlet; Ensure switch is ON; Inspect cord/plug for damage (contact service if damaged).
Loss of suction	Canister full; Clogged hose/nozzle; Dirty filter; Filter missing (for dry use)	Empty canister; Clear blockages; Clean/replace filter; Ensure filter is installed for dry use.
Liquid overflow shut-off	Canister is full of liquid	Turn off, unplug, and empty the canister.
Motor overheating	Blocked airflow; Prolonged heavy use	Check for blockages in hose/filter. Allow the unit to cool down for 30 minutes before restarting.

8. SPECIFICATIONS

Detailed technical specifications for the Foreman FO1623-10L Industrial Wet & Dry Vacuum Cleaner.

- **Model:** FO1623-10L
- **Brand:** Foreman
- **Power:** 1000 Watts
- **Voltage:** 120 Volts
- **Capacity:** 10 Liters
- **Noise Level:** 80 Decibels
- **Filter Type:** Cloth (Washable)
- **Hose Length:** 1.5 meters
- **Power Cord Length:** 3.5 meters
- **Dimensions (Package):** 37 x 37 x 32 cm
- **Product Weight:** 1.45 kg

- **Special Feature:** Compact, Blower Function
- **Surface Recommendation:** All floors

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Foreman customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Foreman website or contact their authorized service centers.